

2006 VOLVO XC90

VOLVO
for life



2006

Introduction

Welcome to the world-wide family of Volvo owners. We trust that you will enjoy many years of safe driving in your Volvo, an automobile designed with your safety and comfort in mind. To help ensure your satisfaction with this vehicle, we encourage you to familiarize yourself with the equipment descriptions, operating instructions and maintenance requirements/recommendations in this manual. We also urge you and your passengers to wear seat belts at all times in this (or any other) automobile. And, of course, please do not operate a vehicle if you may be affected by alcohol, medication or any impairment that could hinder your ability to drive.

Your Volvo is designed to meet all applicable safety and emission standards, as evidenced by the certification labels attached to the driver's door opening and on the left wheel housing in the engine compartment.

For further information please contact your retailer, or:

In the USA:

Volvo Cars of North America

Customer Care Center

P.O. Box 914

Rockleigh, New Jersey 07647-0914

1-800-458-1552

<http://www.volvocars.us>

In Canada:

Volvo Cars of Canada Ltd.
National Customer Service
175 Gordon Baker Road
North York, Ontario M2H 2N7
1-800-663-8255

<http://www.volvocanada.com>

2005 © Volvo Cars of North America, LLC

General information

Shiftlock (automatic transmission)

When your vehicle is parked, the gear selector is locked in the **(P)**ark position. To release the selector from this position, turn the ignition key to position II (or start the engine), depress the brake pedal, press the button on the front side of the gear selector and move the selector from **(P)**ark.

Keylock (automatic transmission)

When you switch off the ignition, the gear selector must be in the **(P)**ark position before the key can be removed from the ignition switch.

Anti-lock Brake System (ABS)

The ABS system in your vehicle performs a self-diagnostic test when the vehicle first reaches the speed of approximately 12 mph (20 km/h). The brake pedal will pulsate several times and a sound may be audible from the ABS control module. This is normal.

Fuel filler door

The fuel filler door, located on the right rear fender, is connected to your vehicle's central locking system. Press the button on the light switch panel (see illustration on [page 29](#)) when the vehicle is at a standstill to unlock the fuel filler door. Please note that the fuel filler door will remain unlocked until the vehicle begins to move forward. An audible click will be heard when the fuel filler door relocks.

Fuel filler cap

After refueling, close the fuel filler cap by turning it clockwise until it clicks into place. If this cap is not closed tightly or if the engine is running when the vehicle is refueled, the Malfunction Indicator Lamp ("Check Engine" light) will illuminate.

Important information

Before you operate your vehicle for the first time, please familiarize yourself with the new engine oil consumption information on [page 86](#). You should also be familiar with the information in chapters one, two and eight of this manual.

Information contained in the balance of the manual is extremely useful and should be read after operating the vehicle for the first time.

The manual is structured so that it can be used for reference. For this reason, it should be kept in the vehicle for ready access.

Do not export your Volvo to another country before investigating that country's applicable safety and exhaust emission requirements. In some cases it may be difficult or impossible to comply with these requirements. Modifications to the emission control system(s) may render your Volvo not certifiable for legal operation in the U.S., Canada and other countries.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication. Please note that some vehicles may be equipped differently, depending on special legal requirements. Optional equipment described in this manual may not be available in all markets.

Volvo reserves the right to make model changes at any time, or to change specifications or design without notice and without incurring obligation.



WARNING!

CALIFORNIA Proposition 65 Warning

Engine exhaust, some of its constituents, and certain vehicle components contain or emit chemicals known to the state of California to cause cancer, and birth defects or other reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer, and birth defects or other reproductive harm.

Volvo and the environment

Volvo is committed to the well being of its customers. As a natural part of this commitment, we care about the environment in which we all live. Caring for the environment means an everyday involvement in reducing our environmental impact.

Volvo's environmental activities are based on a holistic view, which means we consider the overall environmental impact of a product throughout its complete life cycle. In this context, design, production, product use, and recycling are all important considerations.

In production, Volvo has partly or completely phased out several chemicals including chlorofluorocarbons (CFCs), lead chromates, naphthanates, asbestos, mercury and cadmium; and reduced the amount of chemicals used in our plants 50% since 1991.

Volvo was the first in the world to introduce into production a three-way catalytic converter with Lambda Sond, now called oxygen sensor, in 1976. The current version of this highly efficient system reduces emissions

of harmful substances (CO, HC, NOx) from the exhaust pipe by approximately 95% and the search to eliminate the remaining emissions continues. Volvo is the only automobile manufacturer to offer CFC-free retrofit kits for the air conditioning system of all models as far back as the 1975 Volvo 240. Advanced electronic engine controls, refined purification systems and cleaner fuels are bringing us closer to our goal.

After Volvo vehicles and parts have fulfilled their use, recycling is the next critical step in completing the life cycle. The metal content is about 75% of the total weight of a vehicle, which makes the vehicle among the most recycled industrial products. In order to have efficient and well controlled recycling, many Volvo variants have printed dismantling manuals, indicating the weight and material of individual components. For Volvo, all homogeneous plastic parts weighing more than 1.7 oz. (50 grams) are marked with international symbols that indicate how the component is to be sorted for recycling.

In addition to continuous environmental refinement of conventional gasoline-powered internal combustion engines, Volvo is actively looking at advanced technology alternative-fuel vehicles.

When you drive a Volvo, you become our partner in the work to lessen the vehicle's impact on the environment.

To reduce your vehicle's environmental impact, you can:

- Maintain proper air pressure in your tires. Tests have shown decreased fuel economy with improperly inflated tires.
- Follow the recommended maintenance schedule in your Warranty and Service Records Information booklet.
- Drive at a constant speed.
- See an authorized Volvo retailer as soon as possible for inspection if the check engine (malfunction indicator) lamp illuminates, or stays on after the vehicle has started.
- Properly dispose of any vehicle-related waste such as used motor oil, used batteries, brake pads, etc.
- When cleaning your vehicle, use Volvo's own vehicle care products, all of which have systematically been adapted to the environment.

For additional information regarding the environmental activities in which Volvo Cars of North America, LLC and Volvo Car Corporation are involved, visit our Internet home page at:


<http://www.volvocars.us>

PremAir®

On the surface of the radiator in the engine compartment, there is a special coating called PremAir®. PremAir® works as a catalytic converter, converting most of the ground-level ozone passing through the radiator into oxygen, thereby reducing harmful ground-level ozone.

PremAir is a registered trademark of Engelhard Corporation.

Instruments, switches and controls



Control panel in driver's door (controls 34-37)

- [1. Headlights/Parking lights 29](#)
- [2. Instrument lighting 29](#)
- [3. Panel vents 52](#)
- [4. Text window 26](#)
- [5. Temperature gauge 22](#)
- [6. Odometer/Trip odometer/Cruise control indicator 22, 38](#)
- [7. Speedometer iv](#)
- [8. Turn signal indicator lights 22](#)

- [9. Tachometer 22](#)
- [10. Ambient temperature gauge, clock, gear indicator 22](#)
- [11. Fuel gauge 22](#)
- [12. Indicator and warning symbols 23](#)
- [13. Panel vents 52](#)
- [14. Glove compartment 69](#)
- [15. Hazard warning flashers 36](#)
- [16. Audio system 183](#)
- [17. Switches in the center console 27](#)
- [18. Climate system controls 53](#)
- [19. Windshield wiper/washer lever 33](#)
- [20. Audio control buttons in steering wheel 185](#)
- [21. Instrument panel 22](#)
- [22. Horn iv](#)
- [23. Cruise control buttons in steering wheel 38](#)
- [24. Turn signals, High/low beams 32](#)
- [25. Front fog lights, Rear fog light 29](#)
- [26. Parking brake pedal 41](#)
- [27. Parking brake release handle 41](#)
- [28. Button for unlocking fuel filler door 29](#)
- [29. Hood open lever 41](#)
- [30. Reading lights 65](#)
- [31. Courtesy light 65](#)
- [32. Moonroof control \(option\) 46](#)
- [33. Seat belt reminder 25](#)
- [34. Rearview mirror 44](#)
- [35. Central locking button 79](#)
- [36. Lockout switch for rear seat power windows 43](#)
- [37. Power window controls 42](#)
- [38. Sideview mirror controls 44](#)



WARNING!

If your vehicle is involved in an accident, unseen damage may affect your vehicle's driveability and safety.

Contents

Contents

[Safety](#)

[Instruments and controls](#)

[Climate control](#)

[Interior](#)

[Locks and alarm](#)

[Starting and driving](#)

[Wheels and tires](#)

[Vehicle care](#)

[Maintenance](#)

[Specifications](#)

[Audio](#)

[Index](#)

[Back Cover](#)



[Top of Page](#)

2006 VOLVO XC90

Safety

pg. 1 Safety

[Occupant safety, Reporting safety defects](#) [2](#)

[Seat belts](#) [3](#)

[Supplemental Restraint System \(SRS\)](#) [5](#)

[Front airbags](#) [6](#)

[Occupant Weight Sensor \(OWS\)](#) [9](#)

[Side impact \(SIPS\) airbag](#) [12](#)

[Volvo Inflatable Curtain \(VIC\)](#) [13](#)

[Inspecting SRS Ssystem components](#) [14](#)

[Whiplash Protection System \(WHIPS\)](#) [15](#)

[Child safety](#) [17](#)

pg. 2 Safety

Occupant safety, Reporting safety defects

Volvo Concern for Safety

Safety is the Volvo cornerstone. Our concern dates back to 1927 when the first Volvo rolled off the production line. Three-point seat belts (a Volvo invention), safety cages, and energy-absorbing impact zones were designed into Volvo cars long before it was fashionable or required by government regulation. We will not compromise our commitment to safety. We continue to seek out new safety features and to refine those already in our cars. You can help. We would appreciate hearing your

suggestions about improving automobile safety. We also want to know if you ever have a safety concern with your car. Call us in the U.S. at: 800-458-1552 or in Canada at: 800-663-8255.

Occupant safety

How safely you drive doesn't depend on how old you are, but rather on:

- How well you see.
- Your ability to concentrate.
- How quickly you make decisions under stress to avoid an accident.

The tips listed below are suggestions to help you cope with the ever changing traffic environment.

- Never drink and drive.
- If you are taking any medication, consult your physician about its potential effects on your driving abilities.
- Take a driver-retraining course.
- Have your eyes checked regularly.
- Keep your windshield and headlights clean.
- Replace wiper blades when they start to leave streaks.
- Take into account the traffic, road, and weather conditions, particularly with regard to stopping distance.

Reporting Safety Defects in the U.S.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Volvo Cars of North America. If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your retailer, or Volvo Cars of North America. To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-800-424-9393 (or 202-366-0123 in Washington, D.C. area) or write to: NHTSA, U. S. Department of Transportation, Washington D.C. 20590. You can also obtain other information about motor vehicle safety from the Hotline.

Volvo strongly recommends that if your vehicle is covered under a service campaign, safety or emission recall or similar action, it should be completed as soon as possible. Please check with your local retailer or Volvo Cars of North America, LLC if your vehicle is covered under these conditions.

NHTSA can be reached at:

Internet:

<http://www.nhtsa.dot.gov>

Telephone:


1-888-DASH-2-DOT (1-888-327-4236) (toll free)

1-800-424-9393 (toll free)

1-202-366-0123 (in Washington DC area)

pg. 3 Safety

Seat belts



Adjusting the seat belt

Using seat belts

Volvo, the inventor of the three-point seat belt, urges you and all occupants of your vehicle to wear seat belts and ensure that children are properly restrained, using an infant, car, or booster seat determined by age, weight and height.

Volvo also believes no child should sit in the front seat of a vehicle.

Most states and provinces make it mandatory for occupants of a vehicle to use seat belts.

Seat belt tensioners

The seat belts are equipped with tensioners that reduce slack in the belts. These tensioners are triggered in situations where the airbags deploy. The front seat belts also include a tension reducing device which, in the event of a collision, limits the peak forces exerted by the seat belt on the occupant.

Buckling a seat belt

Pull the belt out far enough to insert the latch plate into the receptacle until a distinct click is heard. The seat belt retractor is normally "unlocked" and you can move freely, provided that the shoulder belt is not pulled out too far.

The retractor will lock up as follows:

- if the belt is pulled out rapidly
- during braking and acceleration

- if the vehicle is leaning excessively
- when driving in turns

When wearing the seat belt remember:

- The belt should not be twisted or turned.
- The lap section of the belt must be positioned low on the hips (not pressing against the abdomen).
- Make sure that the shoulder belt is rolled up into its retractor and that the shoulder and lap belts are taut.

Unbuckling the seat belt

To remove the seat belt, press the red section on the seat belt receptacle. Before exiting the vehicle, check that the seat belt retracts fully after being unbuckled. If necessary, guide the belt back into the retractor slot.



Sample label found on all seat belts with tensioners

Seat belt reminder

The seat belt reminder consists of an audible signal, an indicator light above the rearview mirror, and a symbol in the instrument panel that alert the driver and front seat passenger if their seat belts are not fastened.

Seat belt maintenance

Check periodically that the seat belts are in good condition. Use water and a mild detergent for cleaning. Check seat belt mechanism function as follows: attach the seat belt and pull rapidly on the strap.



WARNING!

- Never use a seat belt for more than one occupant.
- Never wear the shoulder portion of the belt under the arm, behind the back or otherwise out of position. Such use could cause injury in the event of an accident.
- Seat belts lose much of their strength when exposed to violent stretching and should be replaced after any collision, even if they appear to be undamaged.
- Never repair the belt yourself; have this work done by an authorized Volvo service technician only.
- Any device used to induce slack into the shoulder belt portion of the three-point belt system will have a detrimental effect on the amount of protection available to you in the event of a collision.
- The seat back should not be tilted too far back. The shoulder belt must be taut in order to function properly.
- Do not use child safety seats or child booster cushions/backrests in the front passenger's seat. We also recommend that children who have outgrown these devices sit in the rear seat with the seat belt properly fastened.



Seat belt use during pregnancy

Seat belt use during pregnancy

The seat belt should always be worn during pregnancy. But it is crucial that it be worn in the correct way. The diagonal section should wrap over the shoulder then be routed between the breasts and to the side of the belly. The lap section should lay flat over the thighs and as low as possible under the belly. It must never be allowed to ride upward. Remove all slack from the belt and insure that it fits close to the body without any twists.

As a pregnancy progresses, pregnant drivers should adjust their seats and steering wheel such that they can easily maintain control of the vehicle as they drive (which means they must be able to easily operate the foot pedals and steering wheel). Within this context, they should strive to position the seat with as large a distance as possible between their belly and the steering wheel.

Child seats

Please refer to [page 19](#) for information on securing child seats with the seat belts.

pg. 5 Safety


Supplemental Restraint System (SRS)



SRS warning light

Supplemental Restraint System

As an enhancement to the three-point seat belts, your Volvo is equipped with a Supplemental Restraint System (SRS). Volvo's SRS consists of seat belt tensioners, front airbags, side impact airbags, the occupant weight sensor, and inflatable curtains. All of these systems are monitored by the SRS control module. An SRS warning light in the instrument panel (see the illustration above) illuminates when the ignition key is turned to position I, II, or III, and will normally go out after approximately 7 seconds if no faults are detected in the system.

Where applicable, a text message will also be displayed when the SRS warning light illuminates. If this warning symbol is not functioning properly, the general warning symbol  illuminates and a text message will be displayed.

WARNING!

- If the SRS warning light stays on after the engine has started or if it illuminates while you are driving, have the vehicle inspected by a trained and qualified Volvo service technician as soon as possible.
- Never try to repair any component or part of the SRS yourself. Any interference in the system could cause malfunction and serious injury. All work on these systems should be performed by an authorized Volvo service technician.



WARNING!


If your vehicle has been subjected to flood conditions (e.g. soaked carpeting/standing water on the floor of the vehicle) or if your vehicle has become flood-damaged in any way, do not attempt to start the vehicle or put the key in the ignition before disconnecting the battery (see below). This may cause airbag deployment which could result in personal injury. Have the vehicle towed to a trained and qualified Volvo service technician for repairs.

Automatic transmission:

Before attempting to tow the vehicle, use the following procedure to override the shiftlock system to move the gear selector to the neutral position:

- Switch off the ignition for at least 10 minutes and disconnect the battery
- Wait at least one minute.
- Insert the key in the ignition and turn it to position II.
- Press firmly on the brake pedal.
- Move the gear selector from (P)ark to the (N)eutral position.

Front airbags



The front airbag system

The front airbags supplement the three-point seat belts. For these airbags to provide the protection intended, seat belts must be worn at all times.

The front airbag system includes gas generators (1) surrounded by the airbags (2) and a deceleration sensor (3) that activates the gas generators, causing the airbags to be inflated with nitrogen gas.

As the movement of the seats' occupants compresses the airbags, some of the gas is expelled at a

controlled rate to provide better cushioning. Both seat belt tensioners also deploy, minimizing seat belt slack. The entire process, including inflation and deflation of the airbags, takes approximately one fifth of a second.



Passenger side airbag - above glove compartment

The location of the front airbags is indicated by "SRS AIRBAG" embossed on the steering wheel pad and above the glove compartment, and by decals on both sun visors and on the front and far right side of the dash.

- The driver's side front airbag is folded and located in the steering wheel hub.
- The passenger's side front airbag is folded behind a panel located above the glove compartment.



WARNING!

- The airbags in the vehicle are designed to be a **SUPPLEMENT** to-not a replacement for-the three-point seat belts. For maximum protection, wear seat belts at all times. Be aware that no system can prevent all possible injuries that may occur in an accident.
- Never drive a vehicle with a steering wheel-mounted airbag with your hands on the steering wheel pad/airbag housing.
- The front airbags are designed to help prevent serious injury. Deployment occurs very quickly and with considerable force. During normal deployment and depending on variables such as seating position, one may experience abrasions, bruises, swellings, or other injuries as a result from deployment of one or both of the airbags.
- When installing any accessory equipment, make sure that the front airbag system is not damaged. Any interference in the system could cause malfunction.

Front airbags

Front airbag deployment

- The front airbags are designed to deploy during certain frontal or front-angular collisions, impacts, or decelerations, depending on the crash severity, angle, speed and object impacted. The airbags may also deploy in certain non-frontal collisions where rapid deceleration occurs.
- The SRS sensors, which trigger the front airbags, are designed to react to both the impact of the collision and the inertial forces generated by it, and to determine if the intensity of the collision is sufficient for the seat belt tensioners and/or airbags to be deployed.

However, not all frontal collisions activate the front airbags.

- If the collision involves a nonrigid object (e.g., a snow drift or bush), or a rigid, fixed object at a low speed, the front airbags will not necessarily deploy.
- Front airbags do not normally deploy in a side impact collision, in a collision from the rear or in a rollover situation.
- The amount of damage to the bodywork does not reliably indicate if the airbags should have deployed or not.

NOTE:

- Deployment of front airbags occurs only one time during an accident. In a collision where deployment occurs, the airbags and seat belt tensioners activate. Some noise occurs and a small amount of powder is released. The release of the powder may appear as smoke-like matter. This is a normal characteristic and does not indicate fire.
- Volvo's dual-threshold, dual-stage front airbags use special sensors to control deployment. The point at which the airbag deploys is determined by whether or not the seat belt is being used, as well as the severity of the collision.
- Collisions can occur where only one of the airbags deploys. If the impact is less severe, but severe enough to present a clear injury risk, the dual-stage airbags are triggered at 70-80% of their total capacity. If the impact is more severe, the dual-stage airbags are triggered at full capacity.

Should you have questions about any component in the SRS system, please contact a trained and qualified Volvo service technician or Volvo Customer Support:

In the USA:

Volvo Cars of North America
 Customer Care Center
 P.O. Box 914
 Rockleigh, New Jersey 07647-0914
 1-800-458-1552
<http://www.volvocars.us>

In Canada:

Volvo Cars of Canada Ltd.
 National Customer Service
 175 Gordon Baker Road
 North York, Ontario M2H 2N7

1-800-663-8255

<http://www.volvocanada.com>**WARNING!**

- Do not use child safety seats or child booster cushions/backrests in the front passenger's seat. We also recommend that occupants under 4 feet 7 inches (140 cm) in height who have outgrown these devices sit in the rear seat with the seat belt fastened^a.
- Never drive with the airbags deployed. The fact that they hang out can impair the steering of your vehicle. Other safety systems can also be damaged.
- The smoke and dust formed when the airbags are deployed can cause skin and eye irritation in the event of prolonged exposure.

a. See also the Occupant Weight Sensor information on [page 9](#).

pg. 8 Safety

Front airbags (contd)



Airbag decal on outside of both sun visors



Airbag decal on the passenger's dashboard



SRS decal at far right of the passenger's dashboard

WARNING!


- Children must never be allowed in the front passenger's seat. Volvo recommends that ALL occupants (adults and children) shorter than 4 feet 7 inches (140 cm) be seated in the back seat of any vehicle with a passengerside front airbag. See [page 19](#) for guidelines.
- Occupants in the front passenger's seat must never sit on the edge of the seat, sit leaning toward the instrument panel or otherwise sit out of position.
- The occupant's back must be as upright as comfort allows and be against the seat back with the seat belt properly fastened.
- Feet must be on the floor, e.g., not on the dash, seat or out of the window.

WARNING!

- No objects or accessory equipment, e.g. dashboard covers, may be placed on, attached to, or installed near the air bag hatch (the area above the glove compartment) or the area affected by airbag deployment (see the illustration on [page 6](#)).
- There should be no loose articles, e.g. coffee cups, on the floor, seat, or dashboard area.
- Never try to open the airbag cover on the steering wheel or the passenger's side dashboard. This should only be done by a trained and qualified Volvo service technician.

Failure to follow these instructions can result in injury to the vehicle occupants.

Occupant Weight Sensor (OWS)



Occupant Weight Sensor (OWS) indicator light

Disabling the passenger's side front airbag

Volvo recommends that ALL occupants (adults and children) shorter than four feet seven inches (140 cm) be seated in the back seat of any vehicle with a front passenger side airbag, and be properly restrained for their size and weight. See also the child safety recommendations on [page 19](#).

The passenger's side front airbag is automatically enabled/disabled by the Occupant Weight Sensor (OWS), a system that monitors the weight of the person or object in the front passenger's seat. The system consists of a silicone-filled bag located under the padding in the front passenger's seat cushion, a control module located under this seat, and a seat belt tension sensor, located on the outboard side of the seat.

The OWS system continuously monitors the pressure on the front passenger's seat cushion and the tension applied to the seat belt. Based on this data, OWS assesses the weight of the occupant or object in the front passenger's seat. This information is transmitted to the SRS system control module, which enables or disables the passenger's side front airbag accordingly, as indicated in the table below.

If the system is functioning normally, the status of the front passenger's side airbag (enabled/ disabled) will be shown by the OWS indicator light as explained in the table to the right. The OWS indicator light is separate and in addition to the SRS warning light in the instrument panel.

NOTE: When the ignition is switched on, the OWS indicator light will go on for up to 10 seconds while the system performs a selfdiagnostic test and then go out. However, if a fault is detected in the system:

- The OWS indicator light will stay on
- The SRS warning light (see [page 5](#)) will come on and stay on
- The message PASS. AIRBAG OFF SERVICE URGENT will be displayed in the information display.

Passenger's seat occupancy status	OWS indicator light status	Passenger's side front airbag status
Seat unoccupied/ person or object weighing less than approx. 15 lbs (7 kg) on seat	OWS indicator light <small>PASS AIRBAG OFF</small> is not lit	Passenger's side front airbag disabled
Seat occupied by a person or object weighing up to approx. 55-65 lbs (25-30 kg)	OWS indicator light <small>PASS AIRBAG OFF</small> lights up	Passenger's side front airbag disabled
Seat occupied by a person or object weighing more approx. than 55-65 lbs (25-30 kg)	OWS indicator light <small>PASS AIRBAG OFF</small> is not lit	Passenger's side front airbag enabled

(contd. on following page)

pg. 10 Safety

Occupant Weight Sensor (OWS)



WARNING!

If a fault in the system is detected and indicated as explained on the previous page, be aware that the passenger's side front airbag will not deploy in the event of a collision.

In this case, the safety systems and Occupant Weight Sensor should be inspected by an authorized Volvo retailer as soon as possible.

Modifications

If you are considering modifying your vehicle in any way to accommodate a disability, for example by altering or adapting the driver's or front passenger's seat(s) and/or airbag systems, please contact Volvo at:

In the USA:

Volvo Cars of North America
Customer Care Center
P.O. Box 914
Rockleigh, New Jersey 07647-0914
1-800-458-1552

In Canada:

Volvo Cars of Canada Ltd.
National Customer Service
175 Gordon Baker Road
North York, Ontario M2H 2N7
1-800-663-8255



WARNING!

- No objects that add to the total weight on the seat should be placed on the front passenger's seat. If a child is seated in the front passenger's seat with any additional weight, this extra weight could cause the OWS system to enable the airbag, which might cause it to deploy in the event of a collision, thereby injuring the child.
- The seat belt should never be wrapped around an object on the front passenger's seat. This could interfere with the OWS system's function.
- The front passenger's seat belt should never be used in a way that exerts more pressure on the passenger than normal. This could increase the pressure exerted on the weight sensor by a child, and could result in the airbag being enabled, which might cause it to deploy in the event of a collision, thereby injuring the child.

**WARNING!**

- Never try to open, remove, or repair any components in the OWS system. This could result in system malfunction. Maintenance or repairs should only be carried out by an authorized Volvo service technician.
- The front passenger's seat should not be modified in any way. This could reduce pressure on the seat cushion, which might interfere with the OWS system's function.

pg. 11 Safety

Occupant Weight Sensor (OWS) (contd)

**WARNING!**

Keep the following points in mind with respect to the OWS system. Failure to follow these instructions could adversely affect the system's function and result in serious injury to the occupant of the front passenger's seat:

- The full weight of the front seat passenger should always be on the seat cushion. The passenger should never lift him/herself off the seat cushion using the armrest in the door or the center console, by pressing the feet on the floor, by sitting on the edge of the seat cushion, or by pressing against the backrest in a way that reduces pressure on the seat cushion. This could cause OWS to disable the front passenger's side airbag.
- Do not place any type of object on the front passenger's seat in such a way that jamming, pressing, or squeezing occurs between the object and the front seat, other than as a direct result of the correct use of the ALR/ ELR seat belt (see [page 19](#)).
- No objects should be placed under the front passenger's seat. This could interfere with the OWS system's function.

pg. 12 Safety


Side impact (SIPS) airbag



Location of the side impact (SIPS) airbag

Side impact airbags - front seats only As an enhancement to the structural side impact protection built into your car, the car is also equipped with Side Impact Protection System (SIPS) airbags.

The SIPS airbag system is designed to help increase occupant protection in the event of certain side impact collisions. The SIPS airbags are designed to deploy only during certain side impact collisions, depending on the crash severity, angle, speed and point of impact.



NOTE: SIPS airbag deployment (one airbag) occurs only on the side of the vehicle affected by the impact. The airbags are not designed to deploy in all side impact situations.

Components in the SIPS airbag system

This SIPS airbag system consists of a gas generator (2), the side airbag modules built into the outboard sides of both front seat backrests (3), and electronic sensors/wiring (1).




WARNING!

- The SIPS airbag system is a supplement to the structural Side Impact Protection System and the three-point seat belt system. It is not designed to deploy during collisions from the front or rear of the car or in rollover situations.
- The use of seat covers on the front seats may impede SIPS airbag deployment.
- No objects, accessory equipment or stickers may be placed on, attached to or installed near the SIPS airbag system or in the area affected by SIPS airbag deployment.
- Never try to open or repair any components of the SIPS airbag system. This should be done only by a trained and qualified Volvo service technician.
- In order for the SIPS airbag to provide its best protection, both front seat occupants should sit in an upright position with the seat belt properly fastened.
- Failure to follow these instructions can result in injury to the occupants of the vehicle in the event of an accident.



[Contents](#) | [Top of Page](#)

Volvo Inflatable Curtain (VIC)




7-seat model shown

Volvo Inflatable Curtain (VIC)

This system consists of Inflatable Curtains located along the sides of the roof liners, stretching from the front side windows to the rear edge of the rear side windows. It is designed to help protect the heads of the occupants of the front seats and the occupants of the outboard rear seating positions, including the outboard passenger in the optional third row of seats in certain side impact collisions.

The Inflatable Curtains in the Volvo XC90 are also designed to help protect the occupants of the vehicle in a roll-over situation, and to help prevent them from being thrown from the vehicle if a roll-over occurs.



NOTE: In 5-seat models, the Inflatable Curtains extend to protect both rows of seats. In 7-seat models, they extend to protect all three rows.

By design, the IC system deploys only on the side of the vehicle affected by the impact.

However, in certain side impacts, or in a rollover situation, **BOTH** the Inflatable Curtains (IC) and the Side Impact Airbag System (SIPS-bag) will deploy, whereas, in some cases, **ONLY** the Inflatable Curtain (IC) will deploy. In cases where **BOTH** the IC and the SIPS-bag deploy, deployment will occur

simultaneously.

NOTE: If the Inflatable Curtain deploys, it remains inflated for approximately 5 seconds.



WARNING!

- The VIC system is a supplement to the Side Impact Protection System. It is not designed to deploy during collisions from the front or rear of the car or in rollover situations.
- Never try to open or repair any components of the VIC system. This should be done only by a trained and qualified Volvo service technician.
- In order for the VIC to provide its best protection, both front seat occupants and both outboard rear seat occupants should sit in an upright position with the seat belt properly fastened; adults using the seat belt and children using the proper child restraint system. Only adults should sit in the front seats. Children must never be allowed in the front passenger seat. See [page 19](#) for guidelines. Failure to follow these instructions can result in injury to the vehicle occupants in an accident.

pg. 14 Safety

Inspecting SRS system components


Inspection date

1. Driver's side airbag
2. Passenger's side airbag
3. Side airbag on the driver's side
4. Side airbag on the passenger's side
5. Driver's side inflatable curtain
6. Passenger's side inflatable curtain




WARNING!

There is no owner maintenance that can be performed on the SRS system. The month and year shown on the decal to the right (located on door pillar) indicate when you should contact your Volvo retailer for specific servicing or replacement of SRS system components. This service must be performed by a trained and qualified Volvo service technician.



This is a sample of the decal located in the left rear door opening

Whiplash Protection System (WHIPS)



Whiplash Protection System (WHIPS) - front seats only

The WHIPS system consists of specially designed hinges and brackets on the front seat backrests designed to help absorb some of the energy generated in a collision from the rear (when the vehicle is "rear-ended").


In the event of a collision of this type, the hinges and brackets of the front seat backrests are designed to change position slightly to allow the backrest/head restraint to help support the occupant's head before moving slightly rearward. This movement helps absorb some of the forces that could result in whiplash.



WARNING!

- The WHIPS system is designed to supplement the other safety systems in your car. For this system to function properly, the three-point seat belt must be worn. Please be aware that no system can prevent all possible injuries that may occur in an accident.
- The WHIPS system is designed to function in certain collisions from the rear, depending on the crash severity, angle and speed.
- Occupants in the front seats must never sit out of position. The occupant's back must be as upright as comfort allows and be against the seat back with the seat belt properly fastened.

(contd. on following page)



WARNING!

- Boxes, suitcases, etc. wedged behind the front seats could impede the function of the WHIPS system.
- If the rear seat backrests are folded down, cargo must be secured to prevent it from sliding forward against the front seat backrests in the event of a collision from the rear. This could interfere with the action of the WHIPS system.
- If your car has been involved in a rear-end collision, the front seat backrests must be inspected by a trained and qualified Volvo service technician, even if the seats appear to be undamaged. Certain components in the WHIPS system may need to be replaced.
- Do not attempt to service any component in the WHIPS system yourself.
- Any contact between the front seat backrests and the folded rear seat could impede the function of the WHIPS system. If the rear seat is folded down, the occupied front seats must be adjusted forward so that they do not touch the folded rear seat.

Child safety

Children should be seated safely

Volvo recommends the proper use of restraint systems for all occupants including children. Remember that, regardless of age and size, a child should always be properly restrained in a car.

Your car is also equipped with ISOFIX/ LATCH attachments, which make it more convenient to install child seats.

Some restraint systems for children are designed to be secured in the vehicle by lap belts or the lap portion of a lap-shoulder belt. Such child restraint systems can help protect children in cars in the event of an accident only if they are used properly. However, children could be endangered in a crash if the child restraints are not properly secured in the vehicle. Failure to follow the installation instructions for your child restraint can result in your child striking the vehicle's interior in a sudden stop.

Holding a child in your arms is NOT a suitable substitute for a child restraint system. In an accident, a child held in a person's arms can be crushed between the vehicle's interior and an unrestrained person. The child could also be injured by striking the interior, or by being ejected from the vehicle during a sudden maneuver or impact. The same can also happen if the infant or child rides unrestrained on the seat. Other occupants should also be properly restrained to help reduce the chance of injuring or increasing the injury of a child.

All states and provinces have legislation governing how and where children should be carried in a car. Find out the regulations existing in your state or province. Recent accident statistics have shown that children are safer in rear seating positions than front seating positions when properly restrained. A child restraint system can help protect a child in a vehicle. Here's what to look for when selecting a child restraint system:

- It should have a label certifying that it meets applicable Federal Motor Vehicle Safety Standards (FMVSS 213) - or in Canada, CMVSS 213.
- Make sure the child restraint system is approved for the child's height, weight and development - the label required by the standard or regulation, or instructions for infant restraints, typically provide this information.
- In using any child restraint system, we urge you to carefully look over the instructions that are provided with the restraint. Be sure you understand them and can use the device properly and safely in this vehicle. A misused child restraint system can result in increased injuries for both the infant or child and other occupants in the vehicle.

When a child has outgrown the child safety seat, you should use the rear seat with the standard seat belt fastened. The best way to help protect the child here is to place the child on a cushion so that the seat belt is properly located on the hips (see the illustration on [page 18](#)). Legislation in your state or province may mandate the use of a child seat or cushion in combination with the seat belt, depending on the child's age and/or size. Please check local regulations.

A specially designed and tested booster cushion (not available in Canada) can be obtained from your Volvo retailer for children weighing 33 - 80 lb. (15 - 36 kg) and 38-54 inches (97 - 137 cm) in height.



WARNING!

- Do not use child safety seats or child booster cushions/backrests in the front passenger's seat. We also recommend that children under 4 feet 7 inches (140 cm) in height who have outgrown these devices sit in the rear seat with the seat belt fastened.
- On hot days, the temperature in the vehicle interior can rise very quickly. Exposure to these high temperatures for even a short period of time can cause heat-related injury or death. Small children are particularly at risk.

pg. 18 Safety

Child safety (contd)



Integrated child booster cushion (option)

Volvo's own integrated booster cushion has been specially designed to help safeguard a child seated in the rear seat. When using an integrated booster cushion, the child must be secured with the vehicle's three-point seat belt.

Use this booster cushion only with children who weigh between 33 and 80 lbs (15 and 36 kg) and whose height is between 38 and 54 in (97 and 137 cm).


The child should be properly seated on the booster cushion. The hip section of the three-point seat belt must fit snugly across the child's hips, not across the stomach. The shoulder section of the three-point seat belt should be positioned across the chest and shoulder (see illustration). The shoulder belt must never be placed behind the child's back or under the arm.



WARNING!

- **DEATH or SERIOUS INJURY** can occur
- Follow all instructions on the booster cushion and in the vehicle's owner's manual.
- **MAKE SURE THE BOOSTER CUSHION IS SECURELY LOCKED BEFORE THE CHILD IS SEATED.**
- Use this booster cushion only with children who weigh between 33 and 80 lbs (15 and 36 kg) and whose height is between 38 and 54 in (97 and 137 cm).
- In the event of a collision while the integrated booster cushion was occupied, the entire booster cushion and seat belt must be replaced. The booster cushion should also be replaced if it is badly worn or damaged in any way. This work should be performed by an authorized Volvo retailer only.

Canada only: This cushion may be referred to as a built-in booster cushion.



Raising

- Pull the handle at the front of the cushion (1) forward.
- Move the seat belt latch aside before raising the cushion.
- With both hands push the cushion rearward (2).
- Push the cushion until it locks in place.

Lowering

- Pull the handle at the front of the cushion (1) forward.
- Pull the seat forward and press it down until it locks in place.

The booster cushion must be pressed down before the backrest can be folded down.

Automatic Locking Retractor/ Emergency Locking Retractor

To make child seat installation easier, each seat belt (except for the driver's belt) is equipped with a locking mechanism to help keep the seat belt taut.

When attaching the seat belt to a child seat:

- Attach the seat belt to the child seat according to the child seat manufacturer's instructions.
- Pull the seat belt out as far as possible.
- Insert the seat belt latch plate into the buckle (lock) in the usual way.
- Release the seat belt and pull it taut around the child seat.

A sound from the seat belt retractor will be audible at this time and is normal.

The belt will now be locked in place.

This function is automatically disabled when the seat belt is unlocked and the belt is fully retracted.

**WARNING!**

Do not use child safety seats or child booster cushions/backrests in the front passenger's seat. We also recommend that children who have outgrown these devices sit in the rear seat with the seat belt properly fastened.

Volvo's recommendations


Why does Volvo believe that no child should sit in the front seat of a car? It's quite simple really. A front airbag is a very powerful device designed, by law, to help protect an adult. Because of the size of the airbag and its speed of inflation, a child should never be placed in the front seat, even if he or she is properly belted or strapped into a child safety seat. Volvo has been an innovator in safety for over seventy-five years, and we'll continue to do our part. But we need your help. Please remember to put your children in the back seat, and buckle them up.

Volvo has some very specific recommendations:

- Always wear your seat belt.
- Airbags are a SUPPLEMENTAL safety device which, when used with a three-point seat belt can help reduce serious injuries during certain types of accidents. Volvo recommends that you do not disconnect the airbag system in your vehicle.
- Volvo strongly recommends that everyone in the vehicle be properly restrained.
- Volvo recommends that ALL occupants (adults and children) shorter than 4 feet 7 inches (140 cm) be seated in the back seat of any vehicle with a front passenger side airbag.

Drive safely!

pg. 20 Safety



Child restraint anchorages

Child restraint anchorages

Volvo vehicles are equipped with child restraint top tether anchorages in the rear seats (second row of seats in seven-seat models). Refer to the child seat manufacturer's instructions for information on securing the child seat.



WARNING!

- Child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts or harnesses. The anchorages are not able to withstand excessive forces on them in the event of collision if full harness seat belts or adult seat belts are installed to them. An adult who uses a belt anchored in a child restraint anchorage runs a great risk of suffering severe injuries should a collision occur.
- Do not install rear speakers that require the removal of the top tether anchors or interfere with the proper use of the top tether strap.
- Top tether straps should be routed beneath the head restraints.

*ISOFIX/LATCH symbols**ISOFIX/LATCH anchors*

ISOFIX/LATCH anchors

Lower anchors for ISOFIX-equipped child seats are located in the second row outboard seats, hidden below the backrest cushions. Symbols on the seat back upholstery mark the anchor positions as shown. To access the anchors, kneel on the seat cushion and locate the anchors by feel. Always follow your child seat manufacturer's installation instructions, and use both ISOFIX lower anchors and top tethers whenever possible.



[Contents](#) | [Top of Page](#)


2006 VOLVO XC90

Instruments and controls

pg. 21 Instruments and controls

<u>Instrument panel</u>	<u>22</u>
<u>Indicator and warning symbols</u>	<u>23</u>
<u>Switches in center console</u>	<u>27</u>
<u>Lighting panel</u>	<u>29</u>
<u>Manually unlocking the fuel filler door</u>	<u>30</u>
<u>Steering wheel adjustment</u>	<u>31</u>
<u>Left-side steering wheel lever</u>	<u>32</u>
<u>Right-side steering wheel lever</u>	<u>33</u>
<u>Tailgate wiper/washer</u>	<u>35</u>
<u>Hazard warning flashers, rear window/sideview mirror defroster, heated front seats</u>	<u>36</u>
<u>Trip computer (option)</u>	<u>37</u>
<u>Cruise control</u>	<u>38</u>
<u>Opening the tailgate, Auxiliary 12-volt sockets</u>	<u>40</u>
<u>Parking brake, Opening/closing the hood</u>	<u>41</u>
<u>Electrically operated windows</u>	<u>42</u>
<u>Rearview mirror/power folding sideview mirror</u>	<u>44</u>
<u>Power moonroof (option)</u>	<u>46</u>

Instrument panel



1. Turn signal indicators - right - left

2. Text window

The text window displays information and warning messages.

3. Temperature gauge

The pointer should be approximately midway on the gauge when driving. **Do not drive the vehicle if the warning light is on.** The text window will provide you with additional information. If the engine temperature remains high, check coolant level - see [page 146](#).

4. Trip odometer

The trip odometers are used for measuring shorter distances. The right-hand digit gives tenth of a mile/kilometer. Press the button for more than 2 seconds to reset. Change between trip odometers 1 and 2 using one short press on the button.

5. Odometer

6. Speedometer

7. Warning symbol

8. High beam indicator

9. Tachometer

The tachometer shows engine speed in thousands of revolutions per minute (rpm). Do not drive continuously with the needle in the red area of the dial, which indicates maximum allowable engine rpm range. Instead, shift to a higher gear or slow the vehicle down. The engine management system will automatically prevent excessively high engine speeds. This will be noticeable as a pronounced unevenness in engine speed.

10. Gear and driving mode indicator

The currently selected driving mode is displayed here. If you use the Geartronic function on the automatic transmission, the currently selected gear will be displayed.

11. Ambient temperature gauge

This display indicates the air temperature outside your vehicle. A "snowflake" symbol in the text window is displayed when the temperature is in the range of 23 - 36° F (-5 - +2° C). Please note that this symbol does not indicate a fault with your vehicle. At low speeds or when the vehicle is not moving, the temperature readings may be slightly higher than the actual ambient temperature.

12. Clock/set button

Turn the button to set the clock.

13. Fuel gauge


The fuel tank holds approximately 21.1 US gals. (80 liters).

When a warning light in the gauge comes on, there are approximately 2.1 US gal. (8 liters) of fuel remaining in the tank.

14. Indicator and warning symbols

pg. 23 Instruments and controls

Indicator and warning symbols

The indicator and warning symbols light up when you turn the ignition key to the driving position (position II) before starting. This shows that the symbols are functioning. When the engine starts, all symbols go out. If the engine is not started within 5 seconds, all symbols except **CHECK ENGINE** and  go out. The symbol for the parking brake goes out when the parking brake is released.


Warning symbol in center of instrument panel

This symbol shines as a red or yellow light depending on the severity of the fault that has been detected.

Red symbol -Stop the vehicle as soon as possible in a suitable location and read the message shown in the text window. The symbol and accompanying text will remain on until the fault has been corrected.

Yellow symbol -Follow the instructions shown in the text window. The text can be erased by pressing the READ button (see [page 26](#)), or will disappear automatically after two minutes.

NOTE: When the message "TIME FOR REGULAR SERVICE" is displayed, the text can be erased and the yellow symbol light can be turned off by pressing the READ button. The text will disappear and the symbol light will go out automatically after two minutes.



Anti-lock brake system ABS

If the warning light comes on, there is a malfunction of the ABS system (the standard braking system will still function). The vehicle should be driven to a Volvo retailer for inspection. See [page 97](#) for additional information.

pg. 24 Instruments and controls

Indicator and warning symbols (contd)

BRAKE Brake failure warning light

If the light comes on while driving or braking, stop immediately, open the hood and check the brake fluid level in the reservoir. See [page 147](#) for reservoir position and [page 151](#) for instructions.



Canadian models are equipped with this warning light.


If the BRAKE and ABS warning lights come on at the same time, this could indicate a fault in the brake system.

- Stop the vehicle in a suitable place and switch off the engine.
- Restart the engine.
- If both warning lights go off, no further action is required.

- If both lights are still on after the engine has been restarted, switch off the engine again and check the brake fluid level (see [page 147](#) for the location of the brake fluid reservoir).

WARNING!

The If the fluid level is below the MIN mark in the reservoir or if a "Brake failure - Service urgent" message is displayed in the text window: **DO NOT DRIVE**. Have the vehicle towed to an authorized Volvo retailer and have the brake system inspected.



- If the brake fluid level is above the MIN mark, drive carefully to an authorized Volvo retailer and have the brake system inspected.

DSTC

The Dynamic Stability and Traction Control system (DSTC) is explained in greater detail on [pages 98 and 99](#).

pg. 25 Instruments and controls

Supplemental Restraint system (SRS)

If this light comes on while the car is being driven, or remains on for longer than approximately 10 seconds after the car has been started, the SRS system's diagnostic functions have detected a fault in a seat belt lock or tensioner, a front airbag, side impact airbag, and/or an inflatable curtain. Have the system(s) inspected by a trained and qualified Volvo service technician as soon as possible.

Generator warning light

If the light comes on while the engine is running, have the charging system checked.



Seat belt reminder

This symbol lights up to indicate that the driver has not fastened his/her seat belt.



Tire pressure monitoring light

See [page 117](#) for more information on this function.

PARK BRAKE PARKING BRAKE

This light will be on when the parking brake is applied. The parking brake pedal is located on the left side of the driver's footwell.



Canadian models are equipped with this symbol.



Rear fog light

This light indicates that the fog light is on.



Turn signal indicator - trailer (certain models)

If you are towing a trailer, this light will flash simultaneously with the turn signals on the trailer. If the light does not flash when signaling, neither the trailer's turn signals nor the vehicle's turn signals are functioning.



Oil pressure warning light

If the light comes on while driving, stop the vehicle and then stop the engine immediately and check the engine oil level See [page 149](#). If the light stays on after restart, have the vehicle towed to the nearest authorized Volvo retailer. After hard driving, the light may come on occasionally when the engine is idling. This is normal, provided it goes off when the engine speed is increased.

CHECK ENGINE Malfunction indicator light

On-Board Diagnostics II (OBDII): As you drive, a computer called "OBDII" monitors your vehicle's engine, transmission, electrical and emission systems. The CHECK ENGINE light will light up if the computer senses a condition that potentially may need correcting. When this happens, please have your vehicle checked by a Volvo retailer as soon as possible.

A CHECK ENGINE light may have many causes. Sometimes, you may not notice a change in your vehicle's behavior. Even so, an uncorrected condition could hurt fuel economy, emission cleanliness, and driveability. Extended driving without correcting the cause could even damage other components in


your vehicle.



Canadian models are equipped with this warning light.

pg. 26 Instruments and controls

Indicator and warning symbols (contd)



Messages in the text window

When a warning light in the instrument panel comes on, a message is also displayed in the text window. After you have read the message, you can erase it by pressing button A (see illustration).

NOTE: Certain messages cannot be erased until the condition has been corrected.

If a warning message is displayed when e.g. you are using the trip computer, this message must be erased before you can access the function of your choice. Press button A to erase the warning message.

You can scroll through the stored messages by pressing button A (see illustration). The text window can be cleared (the message will be returned to memory) by pressing button A again.

Message

STOP SAFELY:

STOP ENGINE:

Meaning:


Stop and switch off the engine - to help prevent serious risk of damage.

Stop and switch off the engine - to help prevent serious risk of damage.

SERVICE URGENT:	Take your car to a trained and qualified Volvo service technician for inspection immediately.
SEE MANUAL:	Refer to your owner's manual. For additional information, please contact your Volvo retailer.
SERVICE REQUIRED:	Take your car to an authorized Volvo retailer for inspection at your convenience (but preferably before the next scheduled maintenance service).
FIX NEXT SERVICE:	Have the system affected inspected at the next scheduled maintenance.
TIME FOR REGULAR SERVICE	This message will be displayed at 7,500 mile (12,000 km) intervals, after 750 hours of driving or after 12 months, whichever occurs first, to remind the driver that the service interval has been exceeded. The message will be displayed for 2 minutes each time the vehicle is started until reset by the servicing retailer.
OIL LEVEL LOW - FILL OIL^a	Check the oil level and top up if necessary. See page 149 .
OIL LEVEL LOW - STOP SAFELY^b	Stop as soon as possible and switch off the engine, check the oil level and top up if necessary. See page 149 .
OIL LEVEL LOW - STOP ENGINE^b	Stop as soon as possible and switch off the engine, check the oil level and top up if necessary. See page 149 .
OIL LEVEL LOW - SEE MANUAL^b	Stop as soon as possible and switch off the engine, check the oil level and top up if necessary. See page 149 .

- a. The yellow warning symbol also lights up (see [page 23](#))
b. The red warning symbol also lights up (see [page 23](#))

Switches in center console





Dynamic Stability Traction Control system (DSTC)

This button is used to switch off DSTC's stability Control function. See [pages 98 and 99](#) for additional information.



WARNING!

Please be aware that the vehicle's handling characteristics may be affected if the Stability Control function is switched off.



Rear seat air conditioning (option)

This button controls the optional rear seat air conditioning system on seven-seat models.



Folding sideview mirrors (option)

Press the button and release it to fold the sideview mirrors in or out. On certain models, when the button is pressed, there may be a long pause before the mirrors move.

Pressing the button again during this pause may erase your first button press. If this happens, wait ten seconds and press the button one more time.

The mirrors cannot be adjusted during the first ten seconds after they have been folded out.

NOTE: If the sideview mirrors have been inadvertently pushed out of position (in a car wash, parking lot, etc.) manually return them to normal position. If mirror adjustment does not seem to operate after manual folding, reset the folding mirrors as follows:

- Turn the ignition key to position II.
- Manually fold the mirror(s) to the normal position.
- Press the button to fold both mirrors in.
- Press the button again to fold the mirrors out to their normal position.

**Park Assist (option/accessory as available)**

This system provides an audible warning when the vehicle is being parked or if it is driven close to a person or object. See [page 100](#) for more information.

NOTE: The system activates automatically when the engine is started, and can be deactivated by pressing this button (e.g. when towing a trailer) or reactivated if necessary.

**Temporarily disconnecting the alarm sensors (option)**

See [page 83](#) for more details.

pg. 28 Instruments and controls

**Auxiliary lights**

This button is used to switch on auxiliary lights (if installed). An LED in the switch will light up to indicate that the auxiliary lights are illuminated.



12 volt socket

This 12 volt socket can be used to plug in certain accessories such as cellular telephones, etc. The ignition key must be in position 1 (or higher) for the auxiliary socket to function.

NOTE: The auxiliary sockets can also be used for cigarette lighters, which are available as accessories at your Volvo retailer.




Power child locks (option)

[See page 81](#) for more information on this function.

pg. 29 Instruments and controls

Lighting panel




Lighting panel

1. Headlight/parking light switch
2. Front fog lights

3. Rear fog light
4. Instrument panel lighting
5. Fuel filler door unlock button


Parking lights

The front and rear parking lights can be turned on even when the ignition is switched off.

- Turn switch 1 to position  .

The license plate lights also illuminate when the parking lights are switched on.

Headlights

- Turn the ignition key to position II.
- The low beam headlights (daytime running lights) illuminate automatically, except when the light switch (1) is in position  ¹.

See [page 32](#) for information on switching between high and low beams.

NOTE: Bi-Xenon headlights (option): Turn the headlight switch to position 0 to activate a daylight sensor, which automatically switches the low beams on or off, depending on ambient light conditions. When driving in daylight, the headlights will switch off and the daytime running lights will come on. In darkness, the daytime running lights will switch off and the Bi-Xenon headlights will switch on.

Foglights

Front fog lights (option)

The front fog lights can be used in combination with either the headlights or the parking lights.

- Turn the ignition key to position II.
- Press button 2 to turn on the front fog lights.

An indicator light in the button illuminates when the front fog lights are on.

Rear fog light

The single rear fog light is located in the driver's side tail light cluster.



The rear fog light will only function in combination with the high/low beam headlights or the optional front fog lights.

- Turn the ignition key to position II.
- Press button 3 to turn on the rear fog light.

An indicator light in the button illuminates when the rear fog light is on.

NOTE: The rear fog light is considerably brighter than the normal tail lights and should be used only when conditions such as fog, rain, snow, smoke or dust reduce visibility for other vehicles to less than 500 ft. (150 meters).

Instrument panel lighting

The instrument panel lighting illuminates when the ignition key is in position II and the light switch (1) is in either position  or .

- Move the thumb wheel (4) up to increase brightness or down to decrease brightness.

Unlocking the fuel filler door

Press button 5 when the car is at a standstill to unlock the fuel filler door. Please note that the fuel filler door will remain unlocked until the car begins to move forward. An audible click will be heard when the fuel filler door relocks.


NOTE: If the fuel filler door does not unlock after the button has been pressed, drive the car

1. On Canadian models, the daytime running lights will remain on with the light switch in this position.

pg. 30 Instruments and controls

Manually unlocking the fuel filler door

NOTE: at a speed of at least 5 mph (8 km/h), stop the car, and press the button again. See the information to the right on unlocking the fuel filler door manually.




Panel on passenger's side of cargo area

Manually unlocking the fuel filler door


1. Open the upper and lower sections of the tailgate, and fold up the rear section of the cargo area floor.

2. If the vehicle is equipped with the optional grocery bag holder, detach the holder's bands.
3. Remove the corner panel (1) from the floor of the cargo area.
4. Open the cover (2) in the side panel by pulling the tab (3) upward/outward.



5. Pull down the insulating material (4) to access the fuel filler door motor (5).
6. Move the catch (6) rearward to unlock the fuel filler door lock, or move it forward to lock the filler door.

pg. 31 Instruments and controls



Steering wheel adjustment

Both the height and the reach of the steering wheel can be adjusted to a comfortable position for the driver. Pull down the lever on the left of the steering column. Adjust the steering wheel to a suitable position and press the lever back into place to lock the steering wheel in the new position. Check that the

steering wheel is locked in the new position.




WARNING!

The Never adjust the steering wheel while driving.

pg. 32 Instruments and controls

Left-side steering wheel lever



Lever positions

1. Turn signals, lane change position
2. Turn signals, position for normal turns
3. High beam flash
4. Toggle between high and low beams, Home Safe lighting

Turn signals

When turning

Move the lever as far up or down as possible (to position 2) to start the turn signals. The turn signals will be cancelled automatically by the movement of the steering wheel, or the lever can be returned to its initial position by hand.


When changing lanes

The driver can flash the turn signals by moving the turn signal lever up or down to position 1 and releasing it. The turn signals will flash until the lever has been released.

NOTE: If the turn signal indicator flashes faster than normal, check for a burned-out turn signal bulb.

High/low beam headlights

Continuous high beams

- Turn the ignition key to position II.
- With the light switch (1) in position , (see [page 29](#)) pull the turn signal lever toward the steering wheel (position 4) to toggle between high and low beams (this also applies on models equipped with the optional Bi-Xenon headlights).

High beam flash

- Turn the ignition key to position II.
- Pull the turn signal lever to position 3. The high beams will remain on until the lever is released.

Home safe lighting

When you leave your car at night, you can make use of the home safe lighting function to illuminate the area in front of the car.


- Remove the key from the ignition switch.
- Pull the direction indicator lever as far as possible towards the steering wheel (to position 4) and release it.
- Exit the car and lock the doors.

The headlights and parking lights will illuminate and remain on for 30¹, 60 or 90 seconds. The time interval can be changed by an authorized Volvo retailer.

1. Factory setting

pg. 33 Instruments and controls

Right-side steering wheel lever



Windshield wipers

**Windshield wipers off**

If the lever is in the 0 position and you move it upwards, the wipers will sweep one stroke at a time for as long as you hold the lever up.

**"Single sweep" position**

Move the lever slightly upward from the 0 position for one sweep of the wipers. The lever return automatically to 0 when released.

**Intermittent wiper function**

With the lever in this position, you can set the wiper interval by twisting ring (1) upward to increase wiper speed or downward to decrease the speed.

Rain sensor (option)

The rain sensor automatically regulates wiper speed according to the amount of water on the windshield. The sensitivity of the sensor can be adjusted by twisting ring 1 up (the wipers will sweep the windshield more frequently) or down (the wipers will sweep the windshield less frequently).

Activating the rain sensor :

1. Turn the ignition key to at least position I and put the windshield wiper lever in position 0.
2. Press button 2. An LED in the button will light up to indicate that the rain sensor is active.

Deactivating the rain sensor:

- Press button 2. or
- Move the windshield wiper lever down to another position.

Moving the lever up will not deactivate the rain sensor. Doing so will cause the wipers to sweep the windshield until the lever is released, at which time the wipers return to rain sensor mode.

The rain sensor is also deactivated when the key is removed from the ignition.

CAUTION

The rain sensor should be deactivated when washing the car in an automatic car wash, etc. If the rain sensor function is left on, the wipers will start inadvertently in the car wash and could be damaged.

**Continuous wiper function****Wipers operate at "high" speed**

pg. 34 Instruments and controls**Windshield washer/headlight washer (certain models)**

Pull the lever toward you and release it. High pressure jets mounted in the bumper will spray the headlights.

CAUTION

Use ample washer fluid when washing the windshield to avoid scratching the glass.

NOTE:

- To conserve washer fluid in driving conditions where the windshield washers are used frequently, the headlights will only be washed once for every five times the windshield is washed within a 10- minute period.
- When approximately 1 US quart (1 liter) remains in the washer fluid reservoir, the rear window and headlights will not be washed when the lever is pulled to conserve washer fluid for the windshield.



[Contents](#) | [Top of Page](#)

Tailgate wiper/washer



Tailgate wiper/washer

A - Intermittent wiping

B - Normal wiping

Move the lever forward to start the tailgate washer.

Tailgate wiper and reverse gear

If the front wipers are on and the car is put into reverse gear, then the tailgate wiper will go into intermittent wiping function*.

If the tailgate wiper is already in normal wiping function, the normal wiping function will continue.

* Consult your Volvo retailer if you would like to have this function deactivated.


Hazard warning flashers, rear window/sideview mirror defroster, heated front seats



Hazard warning flashers

The four-way flasher should be used to indicate that the vehicle has become a traffic hazard. To activate the flashers, press the triangular button in the center dash. Press the button again to turn off the flashers.

NOTE: Regulations regarding the use of the hazard warning flasher may vary, depending on where you live.



Sideview mirror and rear window defroster

Press the switch to start heating the rear window and sideview mirrors to remove ice or condensation. An LED in the switch will light up.

A timer automatically switches off the heating to the sideview mirrors after approximately 4 minutes and to the rear window after approximately 12 minutes. The LED will go out correspondingly.




Heated front seats (option)

- The front seat heating can be switched on and off as required.
- Press the switch once for maximum seat heating. Both LED's in the switch will be lit.
- Press the switch a second time for comfort heating. One LED in the switch will be lit.
- Press the switch a third time to turn the heating off completely.

The seat heating for the passenger seat should be switched off when the seat is not occupied.

pg. 37 Instruments and controls

Trip computer (option)



The trip computer stores information gathered from several systems in your vehicle and has four menus that can be displayed in the text window.

- Driving distance on current fuel reserve
- Average fuel consumption
- Current fuel consumption
- Average speed
- Current speed in mph (Canadian models only)

NOTE: Warning messages from the vehicle's monitoring systems will override the trip computer function. If a warning message is displayed in the text window while you are using the trip computer, you must acknowledge the message by pressing button A. Press button A again to return to the trip computer function.

Trip computer controls and functions.

The four* trip computer functions can be accessed by twisting control B one step at a time in either direction. Twisting a fifth** time returns you to the original function.

The trip computer can be reset (current data will be erased from system memory) by pressing RESET

(button C).

1. Driving distance on current fuel reserve

This function shows the approximate distance that can be driven on the fuel remaining in the tank. This calculation is based on average fuel consumption during the last 12 miles (20 km) of driving and the amount of fuel remaining in the tank when the reading was taken.

When the driving distance on current fuel reserve is less than 12 miles (20 km), "----" will be displayed in the text window.

2. Average fuel consumption

This value indicates fuel consumption since the last time the trip computer was reset (by pressing RESET, button C). When the engine is switched off, information on fuel consumption is stored and remains in system memory until the RESET (button C) is pressed again.

3. Current fuel consumption

This value indicates the current fuel consumption, based on readings taken once per second. When the vehicle is not moving, "----" will be displayed.

4. Average speed

This value indicates average speed since the last time the trip computer was reset (by pressing RESET, button C). When the engine is switched off, information on average speed is stored and remains in system memory until the RESET (button C) is pressed again.

5. Current speed in miles per hour (Canadian models only)


This function provides the driver with an instantaneous conversion of the vehicle's current speed from km/h to mph.

NOTE: Trip computer readings may vary slightly depending on the circumference of the tires on the vehicle.

* Five functions on Canadian models

** A sixth time on Canadian models

Cruise control



Cruise control

The cruise control panel is located on the left side of the steering wheel hub.


Engaging cruise control

Press the CRUISE button. CRUISE will be displayed in the information window in the instrument panel.

NOTE: This does not set the vehicle's speed.

Setting speed

Press + or - to set the current speed. CRUISE ON will be displayed in the information window in the instrument panel.




Increasing or decreasing speed

Use + or - in the following ways to increase or decrease the vehicle's speed:

- Press and hold down + or - until the vehicle reaches the desired speed.
- Press + or - for approximately a half second and release the button to increase or decrease vehicle speed by approximately 1 mph (1.6 km/h).

NOTE: Cruise control will not function at speeds below approximately 20 mph (30 km/h).

Braking

- Cruise control is automatically disengaged when the brake pedal is depressed. The currently set speed is stored in memory.
- Pressing resume  will return the vehicle to the previously set speed.

Acceleration

Momentary acceleration, such as when passing another vehicle, does not affect cruise control operation. The vehicle will automatically return to the previously set speed when you release the accelerator pedal.

Disengaging cruise control

To disengage cruise control, press the CRUISE button. CRUISE or CRUISE-ON will no longer be displayed in the information window in the instrument panel.


NOTE: Cruise control is automatically disengaged if:

- the engine is switched off
- the gear selector is placed in (N)eutral
- the wheels start to spin or lock
- if an increase in speed is maintained for more than one minute
- if the vehicle's speed falls below approximately 20 mph (30 km/h).

Temporarily disengaging cruise control

- Press 0 to temporarily disengage cruise control. CRUISE will be displayed in the information window in the instrument panel.
- Press the brake pedal.

pg. 39 Instruments and controls

Press "resume"  to return to the previously set speed.




WARNING!

The Cruise control should not be used in heavy traffic or when driving on wet or slippery roads, or when driving on unpaved or uneven road surfaces. Cruise control may not maintain set speed on steep downgrades.

pg. 40 Instruments and controls


Opening the tailgate, Auxiliary 12-volt sockets



Opening the tailgate

To open the upper section of the tailgate, pull the handle (A) downward.

To fold down the lower section of the tailgate, pull handle (B) upward.



12-volt socket at the rear of the center console (option)

Auxiliary 12-volt sockets


These 12 volt sockets can be used to plug in certain accessories such as cellular telephones, etc.

12-volt socket in the cargo compartment

Fold down the lid to use the socket.

NOTE!

- If the 12-volt sockets are used while the engine is not running, there is a risk that the vehicle's battery will be discharged.



12-volt socket in the cargo compartment

If the ignition is switched off and a device drawing more than 0.1A is connected to a socket, a battery warning will be displayed in the text window.

- The covers should be kept on when the auxiliary sockets are not in use.
- Maximum current from the sockets is 15A.


Ashtrays/cigarette lighter

The auxiliary sockets can also be used for cigarette lighters.

Ashtrays and lighters are available as accessories. Please contact your Volvo retailer.

pg. 41 Instruments and controls

Parking brake, Opening/closing the hood




Parking brake

- To apply the parking brake, press the pedal (C). The brake is applied to the rear wheels. The indicator light in the instrument panel will light up to indicate that the parking brake is applied.

NOTE: There is also an audible signal that will sound if the car is driven with the parking brake engaged.

- Release the parking brake pulling out the lower edge of the release handle (A).
- If you inadvertently pull the plastic cover (B), it can be pressed back into place.



Opening the hood



WARNING!

Always use the parking brake when parking. On hills, also turn the front wheels toward the curb. The indicator light in the instrument panel will light up even if the parking brake is applied only slightly. Be sure to press down on the pedal sufficiently.

Opening/closing the hood

1. Pull the lever (1) located under the left side of the dashboard to release the hood lock.
2. Lift the hood slightly.
3. Press up the release control (2) located under the front edge of the hood and lift.

To close the hood, place your hand on it and press down until the hood locks in the closed position.



WARNING!

- Do not grasp the ribs in the grille when closing the hood. If your fingers protrude through the grille, they could be injured on components in the engine compartment as the grille closes. We recommend pressing down on the hood to close it.
- Check that the hood locks properly when closed!

Electrically operated windows

The electrically operated windows are controlled by buttons in the arm rests.

- The ignition switch must be ON* (ignition key in position I, II or the engine running) for the electrically operated windows to function.
- To lower: Press down the front edge of the button to the first detent ("stop").
- To raise: Lightly pull up the front edge of the button to the first detent ("stop").


* The electrically operated windows will also function after the ignition has been switched off as long as neither of the front doors has been opened.

Auto up/down function (front doors only):

Either front door window can be opened or closed automatically.

Auto down: Press the front part of the button as far down as possible and release it immediately. To stop the window at any time, pull the button up.

Auto up: Pull the front part of the button up as far as possible and release it immediately. To stop the window at any time, press the button down.



A - front windows, B - rear windows


NOTE: If a window is obstructed during auto-up, it will automatically reverse direction and return to its starting position. If a window is repeatedly obstructed during auto-up operation, an overload protection circuit breaker will temporarily halt window function. The window will return to normal function after a brief cool-down period.



WARNING!

- Always remove the ignition key when the vehicle is unattended.
- Make sure that children's hands are clear before raising the windows.
- Never leave children unattended in the vehicle.

pg. 43 Instruments and controls




Lockout switch for rear windows

Lockout switch for rear windows

The electrically operated rear door windows can be disabled by a switch located on the driver's door (see illustration).

If the light in the switch is OFF: The rear door windows can be raised or lowered with the buttons on the rear door armrests or with the buttons on the driver's door armrest.

If the light in the switch is ON: The rear door windows can only be raised or lowered with the buttons on the driver's door armrest.



Electrically operated window in the front passenger's seat

The control for the electrically operated window in the front passenger's seat operates that window only.




Electrically operated windows in the rear doors.

The rear door windows can be operated with the control on each door and the switch on the driver's door. If the light in the switch for blocking electrically operated windows in the rear doors (located in the driver's door control panel) is on, the rear door windows can only be operated from the driver's door.

pg. 44 Instruments and controls

Rearview mirror/power folding sideview mirrors



Rearview mirror


A Normal position

B Night position, reduces glare from following headlights

Autodim function (option)

The autodim function reacts to headlights from following traffic and automatically reduces glare.

NOTE: The autodim function is automatically switched off when the gear selector is placed in the Reverse position.



Electrically operated sideview mirrors

The mirror control switches are located on the driver's door armrest.

Driver's side: Press the L button (a light in the switch will go on) to activate the adjustment control. Use this control to adjust the driver's door mirror.

Passenger's side: Press the R switch (a light in the switch will go on) to activate the adjustment control.

Use this control to adjust the passenger's door mirror.

CAUTION:

Use the mirror heating function (see [page 54](#)) to remove ice or snow from the mirrors. An ice scraper could damage the surface of the mirror.

After you have adjusted the mirror(s), press the L or R switch again (the LED will go out) to deactivate the adjustment control.

**WARNING!**

The mirrors should always be adjusted prior to driving. Objects seen in the passenger's side wide-angle sideview mirror are closer than they appear to be.

Mirror memory function (with the central locking system) - option

If you lock the vehicle and later unlock it with the **same** remote control and open the driver's door, the sideview mirrors (and the driver's seat) will automatically move to the position they were in when you left the vehicle. This feature will work in the same way with all of the remote control transmitters (up to 3) that you use with your vehicle. This feature will not function if you lock your vehicle with the key.

pg. 45 Instruments and controls

Water repellent glass-option


The sideview mirrors and side door windows can be treated with a water repellent coating. The optional laminated side windows always have this coating.

The coating improves vision by causing the water to run off quickly. See [page 137](#) for information on cleaning this type of glass.

CAUTION

- Use only suitable plastic scrapers to remove ice or snow from the mirrors. Using a metal ice scraper could damage the water repellent coating.
- Use the heating function to remove ice, snow, or mist from the mirrors

Power moonroof (option)



Power moonroof


To operate the moonroof, turn the ignition key to position I or II, or start the engine. The moonroof can be operated in two ways:

- A.** Tilt position
- B.** Sliding moonroof

A. Tilt position

Open: With the moonroof closed, push up the rear edge of the switch (position 5 in the illustration below).

Close: Pull down and hold the rear edge of the switch (position 6 in the illustration below) until the moonroof has closed completely.



B. Sliding moonroof

Manual open: Pull the switch rearward to position 3 and hold it until the moonroof has opened to the position of your choice.

Auto open: Pull the switch as far back as possible (position 4) and release it to automatically slide open the moonroof to the "comfort"* position. Pull the switch rearward again to open the moonroof completely.

Manual close: Push the switch to position 2 and hold it until the moonroof has closed completely or to the position of your choice.

Auto close: Push the switch forward as far as possible (position 1) and release it to automatically close the moonroof.

CAUTION

- Remove ice and snow before opening the moonroof.
- Do not operate the moonroof if it is frozen closed.
- Never place heavy objects on the moonroof.




WARNING!

- Never open/close the moonroof if it is obstructed in any way when in operation.
- Never allow a child to operate the moonroof.
- Never extend any object or body part through the open moonroof, even if the vehicle's ignition is completely switched off.
- Never leave a child alone in a vehicle.

* A position where the moonroof is not quite fully open, which helps alleviate "rumbling" wind noise.

pg. 47 Instruments and controls

If the moonroof is obstructed during auto-close operation, it will automatically reverse direction and return to its starting position. If the moonroof is repeatedly obstructed during auto-close operation, an overload circuit breaker will temporarily halt moonroof function. The moonroof will return to normal function after a brief cool-down period.



Visor

The optional moonroof also features a sliding visor. The visor slides open automatically when the moonroof is opened, and must be closed manually.

pg. 48 Instruments and controls



[Contents](#) | [Top of Page](#)

2006 VOLVO XC90

Climate control

pg. 49 Climate control

[Climate control system-general information](#) [50](#)

[Air distribution](#) [52](#)

[Electronic Climate Control \(ECC\)](#) [53](#)

pg. 50 Climate control

Climate control system-general information

Condensation on the inside of the windows

Keeping the insides of the windows clean will help reduce the amount of condensation that forms on the windows. Use a commercial window cleaning agent to clean the windows.

Ice and snow

Always keep the air intake grille at the base of the windshield free of snow.

Cabin air filter

Replace the cabin air filter with a new one at the recommended intervals. Please refer to your Warranty and Service Records Information booklet, or consult your Volvo retailer for these intervals. The filter should be replaced more often when driving under dirty and dusty conditions. The filter cannot be cleaned and therefore should always be replaced with a new one.

Sensors

The sunlight sensor on the dashboard and passenger compartment temperature sensor in the ECC control panel should not be covered in any way as this could cause incorrect information to be sent to the ECC system.

Parking the vehicle in warm weather

If your vehicle has been parked in the sun in warm weather, opening the windows and moonroof (option) for

several minutes before driving will help release the warm air from the passenger compartment. When the engine is running, close the windows and moonroof and use the recirculation function for several minutes to enable the air conditioning to cool the compartment as quickly as possible.

Windows and optional moonroof

The ECC system will function best if the windows and optional moonroof are closed. If you drive with the moonroof open, we recommend that you manually adjust the temperature and blower control (the LED in the AUTO switch should be off).

Acceleration

The air conditioning is momentarily disengaged during full-throttle acceleration.

Climate system maintenance

Special tools and equipment are required to maintain and carry out repairs on the climate system. Work of this type should only be done by a trained and qualified Volvo service technician.

Refrigerant

Volvo cares about the environment. The air conditioning system in your vehicle contains a CFC-free refrigerant - R134a (HFC134a). This substance will not deplete the ozone layer. The system contains 2.2 lbs (1000 g) R134a and uses PAG oil.

Climate system blower

The climate system blower will be automatically switched off when the engine is not running (even if the ignition key is in position I or II) to avoid unnecessary battery drain. To activate the blower, turn the control to the desired setting.

Passenger compartment blower

Approximately 50 minutes after the ignition is turned off, the blower may come on automatically, and run for seven minutes, to remove condensation in the A/C evaporator.

Blower function to reduce battery drain

The climate system's blower functions normally while the engine is running.

However, when the engine is switched off (even if the ignition is switched to positions I or II), the blower control will be automatically switched off to avoid unnecessary battery drain.

The following points pertain if the *ignition key is on* but the *engine is not running*:

- To restart the blower, turn the control knob to the setting of your choice.
- After approximately 2 minutes, the blower speed will be reduced to avoid battery drain.

You can reset the blower speed at any time. Please be aware that the system has been


pg. 51 Climate control

designed to reduce the blower's speed again after 2 minutes, until the engine is started. If the battery becomes drained:

- LOW BATTERY, FAN IS REDUCED will be displayed in the text window in the instrument panel.
- The yellow warning light in the instrument panel (see [page 23](#)) will also light up.


pg. 52 Climate control

Air distribution



Air distribution

The incoming air is distributed through the ventilation points in the passenger compartment shown above.




Air vents in the dash

- A Open
- B Closed
- C Horizontal air flow

D Vertical air flow

- Direct the outer air vents toward the side windows to defrost.



Air vents in the door pillars

A Open

B Closed


C Horizontal air flow

D Vertical air flow

- Direct the outer air vents toward the side windows to defrost.

pg. 53 Climate control

Electronic Climate Control (ECC)



pg. 54 Climate control

Electronic Climate Control (ECC) (contd)



AUTO

This function automatically regulates the Electronic Climate Control system so that the selected temperatures are maintained. The blower, heating, air distribution (air flow) and air conditioning are controlled.

If you prefer to manually set any of these functions, the remaining functions will still be controlled automatically. Pressing the AUTO button overrides any settings that were previously made manually.



Rear window and sideview mirror defrosters

This function defrosts/de-ices the rear window and sideview mirrors. The LED in the switch will light up to indicate that the heating function is engaged. See [page 36](#) for additional information on this function.

Never use ice scrapers made of metal as the can easily scratch the mirror surface.



Temperature

These controls are used to individually set the temperature for both sides of the passenger compartment. Please note that the compartment will not be heated or cooled faster by setting the temperature higher or lower than necessary.

Set the control to the temperature you prefer.



Defroster

This function defrosts/de-ices the windshield and front side windows. The LED in the switch will light up to indicate that the defrost function is engaged. Blower speed increases automatically and the air in the passenger compartment is dehumidified. Recirculation will not function while defrost is engaged.



Blower control*

Turn the control clockwise to increase or counterclockwise to decrease the blower speed. Pressing the AUTO switch will automatically regulate blower speed and override manual adjustment.

NOTE: Turning the blower control counterclockwise until an orange LED comes on will turn both the blower and the air conditioning off.

* See also [page 50](#).



Blower control for rear climate system (option)

Turn the control to increase or decrease blower speed.

Electronic Climate Control (ECC) (contd)

Air distribution



Air flow to windows

Air through panel vents

Air through floor vents

Press **AUTO** to automatically regulate air flow or press any combination of the controls shown in the illustration to manually adjust air flow. An LED in the switch will light up if an air flow control has been pressed.



Heated front seats (option)

- Press the switch once for maximum seat heating. Both LEDs in the switch will be lit.
- Press the switch a second time for comfort heating. One LED in the switch will be lit.
- Press the switch a third time to turn the heating off completely. The LED will go off.

The seat heating for the passenger seat should be switched off when the seat is not occupied.



A/C - ON/OFF

Press the switch to turn the air conditioning on or off. The "ON" or "OFF" LED will light up to indicate if the system is switched on or off. Other functions will still be regulated automatically (if the **AUTO** switch is on).

- The air conditioning functions only at temperatures above 32° F (0° C).
- While the Defroster function is selected, the air conditioning is temporarily activated to dehumidify the air, even if you have manually switched the air conditioning off. This will only function if the blower is not switched off.



Recirculation

Press this switch to engage the recirculation function (air in the passenger compartment recirculates - no fresh air enters the compartment). The LED in the switch will light up to indicate that the function is engaged.

- Use this function if the outside air is contaminated with exhaust gases, smoke, etc or to heat/cool the vehicle quickly.
- Recirculation should not be used for more than 15 minutes. *If your windows begin to fog or mist, make sure that the recirculation function is switched off.*
- Selecting **Defroster** automatically switches recirculation off.

Timer mode activation: (Vehicles equipped with the Interior Air Quality System have no timer mode) Press and hold the recirculation button for at least 3 seconds to activate a recirculation timer mode. The amber LED in the recirculation button will flash 5 times to show that the timer mode is being activated. In timer mode, each time the recirculation button is pressed, the climate control system will recirculate the air in the passenger compartment for 5-12 minutes, depending on the outside air temperature, and then revert back to fresh air.

- **Timer mode deactivation:** Press and hold the recirculation button for 3 seconds. The amber LED in the recirculation button will illuminate steadily for 5 seconds to show a return to "normal" mode.


pg. 56 Climate control

- In normal mode, when the recirculation button is pressed, the climate control system will recirculate the air in the passenger compartment until the recirculation button is pressed again.
- **Timer mode memory:** If the vehicle is turned off while timer mode is active, timer mode will still be active when the vehicle is restarted.



Interior Air Quality sensor (option)


Some vehicles are equipped with a multifilter and air quality sensor. The filter separates gases and particles, thereby reducing the amounts of odors and contaminants entering the vehicle. The air quality sensor detects increased levels of contaminants in the outside air. When the air quality sensor detects contaminated outside air, the air intake closes and the air inside the passenger compartment is recirculated, i.e. no outside air enters the vehicle. The filter also cleans recirculated passenger compartment air.

When the ECC system is in the AUTO mode, the green LED will be on .

Operation

Press  to operate the Air Quality sensor (normal setting).

Or:

Select one of the following three functions by pressing  1, 2 or 3 times.

1. The AUT LED lights. The Air Quality sensor is now activated.
2. No LED lights. Recirculation is not activated unless needed to cool the passenger compartment in a warm climate.
3. The MAN LED lights. Recirculation is now activated.

Keep in mind the following:

- Make it a rule to have the Air Quality sensor activated at all times.
- Recirculation is limited in cold climates to avoid fogging.
- If window fogging occurs, you should deactivate the Air Quality sensor.
- If fogging occurs, use the defroster functions for the windshield, side windows and rear window. See [page 54](#).
- The filter should be changed at the intervals recommended in the maintenance schedule. However, if the vehicle is used in a severely contaminated environment, it may be necessary to change the filter more frequently.



[Contents](#) | [Top of Page](#)

2 0 0 6 VOLVO XC90

Interior

pg. 57 Interior

[Front seats](#) [58](#)

[Rear seats](#) [62](#)

[Interior lighting](#) [65](#)

[Floor mats](#) [66](#)

[Storage compartments](#) [67](#)

[Securing cargo](#) [71](#)

pg. 58 Interior

Front seats




Manually adjusted front seats

1. Front-rear adjustment: lift the bar and move the seat to the position of your choice.
2. Raise/lower the front edge of the seat cushion (option): use the control to pump the front edge of the cushion up or down.
3. Raise/lower seat height: pump the seat up or down.
4. Lumbar support: turn the control for firmer or softer lumbar support.
5. Backrest tilt: turn the control to adjust the angle of the backrest.
6. Control panel for optional power seat (see [page 60](#) for more information).



WARNING!

- Do not adjust the seat while driving. The seat should be adjusted so that the brake pedal can be depressed fully. In addition, position the seat as far rearward as comfort and control allow.
- Check that the seat is securely locked into position after adjusting.



Folding the backrests in the front seat

The front passenger seat backrest can be folded to a horizontal position to make room for a long load. Fold the backrest as follows:

- Move the seat as far back as possible.
- Adjust the backrest to the upright position.
- Lift the catches on the rear of the backrest.
- Without releasing the catches, push the backrest forward.
- Move the seat as far forward as possible so that the head restraint slides under the glove compartment.



WARNING!

Cover sharp edges on the load to help prevent injury to occupants. Secure the load to help prevent shifting during sudden stops.

pg. 60 Interior

Front seats (contd)

Power seat Operation

Driver's seat: The seat can be adjusted if the ignition key is in position I, II or if the engine is running. It can also be adjusted as follows **with the ignition off:**

- Within approximately 4 minutes after the driver's door has been unlocked from the outside and has been opened and remains open.
- Within 40 seconds, if the driver's door has just been closed.

- Within 40 seconds, if the driver's door has not been opened after the ignition has been switched off.

Passenger seat: The seat can only be adjusted if the ignition key is in position I, II or if the engine is running.

Seat adjustment

Adjust the power seat(s) with the two controls at the side of the seat as follows:

- 1 - Front edge of seat (raise/lower)
- 2 - Forward - rearward
- 3 - Rear edge of seat (raise/lower)
- 4 - Backrest tilt


Power seat adjustment controls

The power seats have an overload protector that activates if a seat is blocked by any object. If this occurs, switch off the ignition (key in position 0) and wait about 20 seconds before operating the seat again.

Emergency stop

If the seat accidentally begins to move, press any of the buttons to stop the seat.

NOTE: Please refer to the following page for information on programming the memory function in the driver's seat.



Power seat adjustment controls

Remote keyless entry system and driver's seat

The remote control transmitter also controls the electrically operated driver's seat in the following way:

- Adjust the seat to your preferences.
- When you leave your vehicle, lock it using the remote control.

The position of the seat is now stored in the remote control.

Automatic seat adjustment

To move the seat to the position in which you left it:

1. Unlock the driver's door with the same remote control (the one used to lock the doors)
2. Open the driver's door within 2 minutes. The driver's seat will automatically move to the position in which you left it.


NOTE:

- The seat will move to this position even if someone else has moved it to a different seating position and locked the car with a different remote control.
- This feature will work in the same way with all of the remote control transmitters (up to 3) that you use with your vehicle.
- This feature will not function if you lock your vehicle with the key.

pg. 61 Interior

**WARNING!**

- Because the driver's seat can be adjusted with the ignition off, children should never be left unattended in the vehicle.
- Movement of the seat can be STOPPED at any time by pressing any button on the power seat control panel.
- Do not adjust the seat while driving.
- The seat should be adjusted so that the brake pedal can be depressed fully. In addition, position the seat as far rearward as comfort and control allow.
- The seat rails on the floor must not be obstructed in any way when the seat is in motion.

**Programming the memory**

Three different seating and door mirror positions can be stored in the driver seat's memory.

The following example explains how button 1 can be programmed.

Buttons 2 and 3 can be programmed in the same way.

To program (store) a seat position in button 1:

1. Move the seat to the desired position using the seat adjustment controls (see the previous page).
2. Press and hold down the MEM (memory) button.
3. With the MEM button depressed, press button 1 briefly to store the seat's current position.

To move the seat to the position that it was in when button 1 was programmed:

Press and hold down button 1 until the seat stops moving.

As a safety precaution, the seat will stop automatically if the button is released before the seat has reached the preset position.

pg. 62 Interior

Rear seats



Entering the optional third row of seats

Tilting the outboard backrests in the second row of the seats:

Pull up the handle (1), hold it up, and tilt the backrest forward to move the seat. Return the backrest to the upright position to slide the seat back to its original position.

Forward/rearward seat adjustment

Lift the adjustment bar (2) to move the seat forward or rearward.



Removing the center console (seven-seat models only)

In order to make it possible to move the center seat in the second row of seats as far forward as possible (seven-seat models only), the rear section of the center console can be removed.

- Pull the handle (see illustration above) and lift out the console.
- To return the console to its original position, slide it back into position until it clicks into place.



Sliding center seat - second row (seven-seat models only)

The center seat in the second row can be moved farther forward than the outboard seats. This makes it possible for a child seated in this position to sit closer to the people in the front seats.

pg. 63 Interior



Head restraint - second row, center position

The head restraint in the center position can be adjusted to 4 different heights.

To raise - pull the restraint up until it clicks into one of the four heights positions.

To lower - press the button at the base of the support (see illustration above) and press the head restraint down.




WARNING!

- Please note that the lowest head restraint position is only intended for use when the backrest is to be folded down, or when the seat is not occupied.
- The head restraint is intended to help protect the head/neck in a collision. Ensure that it is properly adjusted for the occupant of the seat.


pg. 64 Interior

Rear seats (contd)



Folding the backrests - second row of seats

1. Move the seat(s) to their rearmost position (seven-seat models only).
 2. Pull the loop (A) to fold down an outboard head restraint. Press down the center head restraint if necessary (see [page 63](#)).
 3. Pull the handle (B) outward to release the backrest. The backrests are designed to lock at a 45 degree angle. Pull the handle again to continue pressing it down until it locks in the horizontal position.
- To return the backrests to the upright position, pull handle B and pull the backrest up.



Folding the backrests - third row of seats (option)

Folding down the backrest

If necessary, fold in the load anchorage eyelets before folding down the backrests.

1. Move the seats in the second row forward, see [page 62](#).
2. Pull up the handle in illustration 1 above.
3. Push the seat cushion firmly rearward, under the backrest.
4. Fold down the backrests* (the head restraints fold down automatically) to the horizontal position.


Returning the backrest to the upright position

- Fold up the backrest to the upright position.
- Grasp the strap (see illustration 3 above) and pull the seat cushion out until it locks in place. This also locks the backrest in the upright position.

* Please note that the head restraints in this row cannot be vertically adjusted.

pg. 65 Interior

Interior lighting



Reading light Courtesy light Reading light

Courtesy light/front reading lights

The courtesy/reading lights can be turned on or off by pressing the respective buttons.

The courtesy light has a timer function which turns the light¹ on for 30 seconds if:

- You unlock the vehicle from the outside with the key or remote control.
- You switch off the ignition (turn the key to position 0).

The courtesy light stays on for 10 minutes if one of the doors is left open after the vehicle is unlocked.

The courtesy light switches off if:


- The engine is started.
- The vehicle is locked from the outside with the key or remote control.

The courtesy light can be switched off or on in all situations by briefly pressing the button.

When you switch the light on, it remains lit for 10 minutes.

You can disconnect the automatic function by pressing the courtesy light button for more than 3 seconds. Briefly pressing the courtesy light button again automatically reconnects the function.


The courtesy light timer periods can be changed. Contact your Volvo retailer.



Rear reading lights

- The reading lights can be switched on or off by pressing the respective buttons.
- **Seven-seat models:** Both reading lights for the third row of seats will switch on if one of the buttons is pressed.
- The reading lights switch off automatically after 10 minutes if the engine is not running.
- The lights can be switched off at any time by pressing the button.

1. In dark conditions



Vanity mirror

The light comes on when you open the cover.

Floor Mats

Volvo offers floor mats specially manufactured for your vehicle. They must be properly placed and secured in the mat clips.




WARNING!

An extra mat on the driver's floor can cause the accelerator pedal to catch. Check that the movement of the accelerator pedal is not impeded. No more than one protective floor covering may be used at one time.




[Contents](#) | [Top of Page](#)

Storage compartments




Storage compartments (contd)



Storage compartment in the center console

To open the lid on the storage compartment, press the lower edge of the opening latch (see illustration above). This lid can be folded back to form a small table area for rear seat passengers.

Lift the tray under the lid to expose the deep storage bin with slots for CD storage.



Cup holders for the front seats


Two cup holders are provided for the front seat occupants. Press lightly on the rear edge of the cover to open it.

Ashtray (accessory)

An ashtray insert is available from your Volvo retailer. This insert slides into either of the cup holders.

Pen holder

There is a pen holder in the center console, in front of the gear selector.




Storage compartment in rear side of center console

Grasp the upper edge of cover and pull to open this compartment.

Ashtray (accessory)

An ashtray insert is available from your Volvo retailer.



Cup holders for the rear seats

- Grasp the lower edge of the panel to pull out the cup holders in the rear side of the center console.
- The cup holder insert can be removed to provide space for a large plastic bottle. Pull the insert straight up to remove it. Press down to reinsert it.



Glove compartment

The glove compartment can be used to store things such as the owner's manual, maps, pens, etc.

Storage compartments (contd)



Coat hanger

Use the coat hanger for light jackets, etc. `



Storage space between rear seats (seven-seat models) - option

This storage space provides compartments for pens or other small items.



Rear side storage compartments and cup holders (seven-seat models)

Lift the lid to access the storage compartment.

Securing cargo



Securing cargo

As a safety precaution, all cargo in your vehicle should be securely anchored to keep it from being thrown forward in the event of sudden braking, etc. The vehicle is equipped with eyelets in the cargo space to which straps or other cargo restraints can be attached.



WARNING!

The eyelets are not to be used as passenger restraints or as anchorages for child restraints.

Consult your Volvo retailer about suitable accessories for this purpose.

Remember that an object weighing 44 lbs (20 kg) produces a force of 2,200 lbs (1,000 kg) in a head-on collision at 30 mph (50 km/h)!

Keep the following in mind when loading the vehicle:

- The load carrying capacity of your vehicle is determined by factors such as the number of passengers, the amount of cargo, the weight of any accessories that may be installed, etc. See the section "Vehicle loading" in the chapter "Wheel and tires" for more detailed information.
- Load the cargo **against** the backrest.
- Load heavy cargo as low as possible.
- If no one is sitting in the outboard rear seat(s), reinforce the backrest by fastening the seat belts.
- Never load cargo above the backrest without a cargo net.



WARNING!

When the rear backrest(s) are folded down, the vehicle should not be loaded to a level higher than 2 in. (5 cm) below the upper edge of the rear side windows. Objects placed higher than this level could impede the function of the Inflatable Curtain.



Attachment bracket

Nylon cargo net (option)


The Volvo XC90 can be equipped with a cargo net made of strong nylon fabric.

This net can be installed in two places:

- Behind the rear seat backrests (the second row of seats in seven-seat models)
- Behind the front seat backrests if the rear seat backrests (the second row of seats in seven-seat models) have been folded down.

If the vehicle is equipped with the cargo area cover, lift the cover out of the vehicle before installing the cargo net.

1. The upper and lower rods of the cargo net are hinged. Position the rods so that they are straight and lock in position.



Attachment eyelet in front seat rail

2. Insert the end of the upper rod in one of the attachment brackets (see illustration above).
3. Insert the other end of the rod in the attachment bracket on the opposite side of the vehicle.
4. Attach the lower straps to the eyelets on the floor if the net has been installed in the rear attachment brackets. Use the eyelets in the front seat rails if the net has been installed in the forward attachment brackets.

NOTE: On seven-seat models: When using the net in the rear attachment brackets, be sure it is installed in front of the side armrests.

5. Adjust the straps to pull the net taut.



Folding and storing the cargo net

Press the release buttons on the hinges (1 in the illustration above) and fold the net. The cargo net can be stored under the floor of the cargo area on five-seat models.




WARNING!

Be sure the cargo net is properly inserted in the attachment brackets and the straps are correctly attached to the eyelets and pulled taut.

Do not use the net if it is damaged in any way.

When it is not in use, store the net so that it cannot be thrown forward in the event of sudden braking, etc.

pg. 73 Interior




Steel grid (accessory)

To install the grid:

Upper attachments

1. Lift in the grid through the tailgate or through one of the rear passenger doors (in this case, fold down the rear seat backrests/backrests in second row of seats in seven-seat models).
2. Insert one of the grid's upper attachments into an attachment bracket above one of the rear passenger doors (see illustration above).
3. Push the grid's attachment into the forward position in the attachment bracket (see inset illustration above) to lock the attachment in place.
4. Insert the grid's other upper attachment in the attachment bracket above the opposite rear passenger door, and press the attachment into the forward position in the attachment bracket to lock it in place.



Lower attachments

1. Insert the lower attachment bracket through the steel grid's lower mount from underneath.
2. Install the spring on the attachment bracket and tighten the knob.
3. Secure the attachment bracket hook in the lower cargo eyelet. Turn the knob to tension the attachment bracket in the cargo eyelet.
4. Repeat the operation on the opposite side.
5. Tighten both attachment brackets alternatively.
6. Place the protective caps on the threads above the knobs.




WARNING!

Seven-seat models:

- The backrests of the optional third row seats must be folded down when installing the steel grid.
- The steel grid is installed behind the second row of seats in seven-seat models. To avoid the risk of injury, no one should be allowed to sit in the third row of seats when the steel grid is in place in the vehicle.

pg. 74 Interior

Securing cargo (contd)



Cargo area cover (option)


Installing the cargo area cover:

Press the end pieces of the cargo area cover down in the holders.

Pull out the cargo area cover and hook it in the holes in the rear cargo area pillars (see illustration above).

Removing the cargo area cover:

Press the end pieces of the cover inward. Pull up and lift out.



Grocery bag holder

1. Fold down the lower section of the tailgate.
2. Fold up the rear section of the cargo compartment floor.
3. Hang or secure your grocery bags by means of the straps or holders.



[Contents](#) | [Top of Page](#)

2 0 0 6 VOLVO XC90

Locks and Alarms

pg. 75 Locks and Alarms

[Keys and remote controls](#) [76](#)


[Locking and unlocking](#) [79](#)

[Child safety locks](#) [81](#)

[Alarm](#) [82](#)

pg. 76 Locks and Alarms

Keys and remote controls



Keys

Two types of keys are provided with your vehicle; master keys and a service (valet) key. The master key, the remote control, and the central locking button may all be used to lock and unlock all of your vehicle's locks.

The service key will operate only the driver's door and the ignition switch. It is intended to help deter unwanted entry into the glove compartment.

To use your keys:

- Turn the key once to unlock the **driver's door only**.
- Turn the key again (within 10 seconds) to unlock all doors and the tailgate.
- One turn with the key towards lock in the drivers door locks all doors, tailgate.
- Use the switch on the driver's door armrest to lock/unlock the vehicle from the inside.

**WARNING!**

If the doors are locked while driving, this may hinder rapid access to the occupants of the vehicle in the event of an accident. (Also see information on "Child safety locks").

NOTE: To help prevent accidentally locking the keys in the vehicle, the central locking system is designed to unlock the doors immediately if the key is left in the ignition switch, the vehicle is locked using the lock button on the door and the door is then closed. A sound from the lock will be audible at this time.

Please note that this function will not unlock the doors if the engine is running.

Immobilizer (start inhibitor)

Each of the keys supplied with your vehicle contains a coded transmitter. The code in the key is transmitted to an antenna in the ignition switch where it is compared to the code stored in the start inhibitor module. The vehicle will start only with a properly coded key.

Each key has a unique code, which your Volvo retailer uses if new keys are required. A maximum of six remote controls/keys can be programmed and used for one car.

If you misplace a key, take the other keys to an authorized Volvo retailer for reprogramming as an anti-theft measure.

If two of the keys to your vehicle are close together, e.g., on the same key ring, when you try to start the vehicle, this could cause interference in the immobilizer system and result in the vehicle not starting. If this should occur, remove one of the keys from the key ring before trying to start the vehicle again.

NOTE: This device complies with part 15 of the FCC rules. Operation is subject to the following condition: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Remote controls

Your vehicle is equipped with two coded remote control transmitters with integrated ignition keys called Key Integrated Remote (KIR). These transmitters use a radio frequency that will enable you to lock/unlock all doors and the tailgate from a distance of 10-15 feet (3-5 meters).

The transmitters will also activate or allow "keyless" entry into the passenger compartment or the tailgate. They will also activate or deactivate the vehicle's alarm system(s). The car can also be locked/unlocked with the key.

If one of the transmitters is misplaced, contact your nearest authorized Volvo retailer for replacement.



Buttons in remote control:

*1 - Fold key in/out, 2 - Lock, 3 - Approach lighting,
4 - "Panic" function, 5 - Unlock tailgate, 6 - Unlock*

Using the remote control

Button 1: Press to extend the key. This button must also be pressed when the key is folded back into the slot in the side of the remote control unit.

Button 2 (Lock): Press once to lock all doors, and the tailgate.

Button 3 (Approach lighting): Press this button when approaching the car at night to light up the interior courtesy light, parking lights, license plate lights and the lights in the sideview mirrors.

Button 4 (Panic): See [page 82](#) for more information on this function.

Button 5 (Tailgate unlock): Press this button twice within 3 seconds to unlock the tailgate (without unlocking the other doors).

Button 6 (Unlock): Press this button once to unlock the driver's door only. Wait for at least 1 second and press the button again (within 10 seconds) to unlock all doors, and the tailgate.

NOTE:

- If an airbag deploys, your vehicle's SRS control module will attempt to automatically unlock all doors.
- The keys may also be used to lock and unlock the doors, and to activate and deactivate the alarm system.
- To avoid leaving your keys in the vehicle, make a habit of always locking the vehicle with the remote control.

Automatic re-locking If the doors are unlocked, the locks will automatically reengage (re-lock) and the alarm will rearm after 2 minutes unless a door or the tailgate has been opened.

Automatic locking (option)

The doors lock automatically when the vehicle's speed exceeds approximately 5 mph (7 km/h) and remain locked a door is opened from the inside or until the car is unlocked with the remote.

pg. 78 Locks and Alarms

- FCC ID:LQNP2T-APU This device complies with part 15 of the FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Canadian 2306104388 Model 504 2927 by Donnelly Operation is subject to the following conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- Canadian 2306104388A Model 509 977 by Connaught Electronics Operation is subject to the following conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.



WARNING!

Never use the transmitter to lock the doors from inside the vehicle.


Doing so would **ACTIVATE**:

- the break-in alarm, which would sound if one of the doors were opened
- the optional interior motion and inclination alarm sensors.

Doing so would **DEACTIVATE**:

- the moonroof and interior courtesy light controls.
- the central locking buttons on the front door armrests, although the interior door handles would still function to allow occupants to leave the vehicle.

Disabled features would remain disabled until the remote were used again to unlock the vehicle. In addition, locking an occupied vehicle would hinder rapid access to the occupants in an accident or emergency.



Replacing the battery in the remote control

If the range of the transmitter is noticeably reduced, this indicates that the battery is weak and should be replaced.

To replace the battery

1. Carefully pry open the rear edge of the cover with a small screwdriver.
2. Insert a new 3-volt, CR2032 battery, with the battery's plus side up. Avoid touching the contact surfaces of the battery with your fingers.
3. Press the cover back into place. Ensure that the rubber seal is correctly positioned to help keep out moisture.

NOTE: The old battery should be disposed of properly at a recycling center or at your Volvo retailer.

Locking and unlocking



Locking and unlocking the vehicle from the inside

The switch on the driver's door armrest can be used to lock or unlock all doors and the tailgate, and to set the alarm.



Locking the glove compartment

The glove compartment can be locked with the master key.

Locking and unlocking (contd)



Unlocking the tailgate

The tailgate lock is incorporated in the central locking system and is locked or unlocked when all doors are locked/unlocked.


The tailgate can be unlocked by:

- Pressing UNLOCK on the remote control twice.
- Using the central locking button on the driver's door.
- Pressing **twice** on the remote control's tailgate unlock button (see illustration above).
- Relock the tailgate using the remote's "Lock" button.

Automatic relocking:

- If you use the tailgate unlock button to unlock the tailgate without opening it, it will automatically relock after approximately 2 minutes.

Note: If you open the tailgate and close it again, it will remain unlocked and the alarm will not be rearmed. Press the lock button on the remote control to relock the tailgate and rearm the alarm.




Child safety locks in the rear doors

Child safety locks

Manual child safety locks - rear doors/tailgate

The controls are located on the rear door jambs and at the lower edge of the tailgate. Use a key or small screwdriver to adjust these controls.

- A The door/tailgate cannot be opened from the inside. The door/tailgate can be opened from the outside.
- B The door/tailgate locks function normally.




Child safety lock in the tailgate



WARNING!

Remember, in the event of an accident, the rear seat passengers cannot open the doors from the inside with the buttons in position A.



Power child locks (option)

To prevent the rear doors from being opened from the inside:

1. Turn the vehicle's ignition key to at least position 1.
2. Press the button shown above.

Indicator light in the button ON: the doors cannot be opened from the inside. Normal operation from the outside.

Indicator light in the button OFF: the doors can be opened from the inside.

pg. 82 Locks and Alarms

Alarm

Alarm

The alarm is automatically armed whenever you lock your vehicle.

When armed, the alarm continuously monitors a number of points on the vehicle. The following conditions will set off the alarm:

- The hood is forced open.
- The tailgate is forced open.
- A door is forced open.
- The ignition switch is tampered with.
- If there is movement in the passenger compartment (if the vehicle is equipped with the optional

movement sensor).

- The vehicle is lifted or towed (if the vehicle is equipped with the optional inclination sensor).
- The battery is disconnected (while the alarm is armed).
- The siren is disconnected when the alarm is disarmed.

Arming the alarm

Press the LOCK button on the remote control, lock the vehicle using the key in the driver's door or press the central lock button on driver's doors with the door open. One long flash of the turn signals will confirm that the alarm is armed.

Disarming the alarm

Press the UNLOCK button on the remote control or unlock the doors with the key.

Turning off (stopping) the alarm

If the alarm is sounding, it can be stopped by pressing the UNLOCK button on the remote control or by unlocking the driver's door with the key.

Audible/visual alarm signal

An audible alarm signal is given by a battery powered siren. The alarm cycle lasts for 25 seconds.

The visual alarm signal is given by flashing all turn signals and turning on the interior lighting for approximately 5 minutes.

"Panic" button

In an emergency situation, this feature can be used to attract attention.

Activate the "panic" button by pressing the red button on the remote control (see illustration on [page 77](#)) for at least 3 seconds or by pressing this button twice within 3 seconds. The turn signals will flash, and the vehicle's horn will sound.

The function can be turned off by pressing any of the buttons on the remote control or will stop automatically after 25 seconds. When a button is pressed, there is a 5 second delay before the panic alarm is deactivated.

NOTE: This button will NOT unlock the vehicle.



Temporarily turning off the inclination and movement alarm sensor(s) - accessory

This button will only be found in vehicles equipped with the accessory inclination and/or movement sensors.

FCC ID: MAYDA5823

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canadian IC: 4405A-DA5823

Movement sensor DA5823 by Dynex

Operation is subject to the following conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

In certain situations it may be desirable to turn off the accessory inclination and movement alarm sensors if, for example, you drive your vehicle onto a ferry where the rocking of the boat could trigger the alarm or if a pet is left in the vehicle with the doors locked.

To temporarily turn off the inclination and movement alarm sensors from the alarm system:

From the time the ignition key is turned from the Drive position (position II) until you lock the vehicle, you can press the button in the center console. The LED in the switch will light up and a message will be displayed in the text window to indicate that the sensors are disconnected.

The vehicle can then be locked in the usual way to set the alarm.

NOTE:

- This function will not turn off the vehicle's standard alarm.
- The optional sensors are automatically reconnected to the alarm system the next time the vehicle is unlocked and then locked again.

LED alarm status signals

The status of the alarm system is indicated by the red LED at the top of the dash:

- LED off - the alarm is not armed
- LED flashes once per second - the alarm is armed
- LED flashes rapidly before the ignition is switched on - the alarm has been triggered
- **Fault in the alarm system:** If a fault has been detected in the alarm system, a message will be displayed in the text window. Contact your Volvo retailer.

Automatic re-lock/re-arm system

If the vehicle is unlocked with the remote, the vehicle will re-lock and the alarm will re-arm after 2 minutes unless a door or the tailgate has been opened.

pg. 84 Locks and Alarms

This page intentionally left blank



[Contents](#) | [Top of Page](#)

2006 VOLVO XC90

Starting and driving

pg. 85 Starting and driving

[Refueling](#) [86](#)

[Starting the vehicle](#) [89](#)

[General information](#) [91](#)

[Automatic transmission with Geartronic](#) [93](#)

[All Wheel Drive](#) [95](#)

[Brake system](#) [96](#)

[Dynamic Stability Traction Control \(DSTC\)](#) [98](#)

[Park assist](#) [100](#)

[Towing](#) [101](#)

[Jump starting](#) [103](#)

[Towing a trailer](#) [104](#)

[Detachable trailer hitch - installing/
removing](#) [106](#)

[Load carriers](#) [107](#)

[Cold weather precautions](#) [108](#)

[Before a long distance trip](#) [109](#)

Refueling

ENGINE OIL

Although some oil consumption occurs during normal engine operation, more oil is consumed when the engine is new as the internal parts generate higher friction while wearing-in to each other. From the time the engine is new until the first maintenance is performed, the oil consumption could be higher than normal. For this reason, it is especially important to check the oil every time you refuel your vehicle during this period. See [page 149](#).

Fuel requirements

Octane rating

Volvo engines are designed for optimum performance on unleaded premium gasoline with an AKI octane rating of 91 or above. AKI (ANTI KNOCK INDEX) is an average of the Research Octane Number, RON, and the Motor Octane Number, MON. $((RON + MON)/2)$. The minimum octane requirement is AKI 87 (RON 91).

Deposit control gasoline (detergent additives)

Volvo recommends the use of detergent gasoline to control engine deposits. Detergent gasoline is effective in keeping injectors and intake valves clean. Consistent use of deposit control gasolines will help ensure good driveability and fuel economy. If you are not sure whether the gasoline contains deposit control additives, check with the service station operator.

NOTE: Volvo does not recommend the use of external fuel injector cleaning systems.

Unleaded fuel

Each Volvo has a three-way catalytic converter and must use only unleaded gasoline. U.S. and Canadian regulations require that pumps delivering unleaded gasoline be labelled "UNLEADED". Only these pumps have nozzles which fit your vehicle's filler inlet. It is unlawful to dispense leaded fuel into a vehicle labelled "unleaded gasoline only". Leaded gasoline damages the three-way catalytic converter and the heated oxygen sensor system. Repeated use of leaded gasoline will lessen the effectiveness of the emission control system and could result in loss of emission warranty coverage. State and local vehicle inspection programs will make detection of misfueling easier, possibly resulting in emission test failure for misfueled vehicles.

NOTE: Some U.S. and Canadian gasolines contain an octane enhancing additive called methylcyclopentadienyl manganese tricarbonyl (MMT). If such fuels are used, your Emission Control System performance may be affected, and the Check Engine Light (malfunction indicator lamp) located on your instrument panel may light. If this occurs, please return your vehicle to an authorized Volvo retailer for maintenance.

Gasoline containing alcohol and ethers

"Oxygenated fuels"

Some fuel suppliers sell gasoline containing "oxygenates" which are usually alcohols or ethers. In some areas, state or local laws require that the service pump be marked indicating use of alcohols or ethers. However, there are areas in which the pumps are unmarked. If you are not sure whether there is alcohol or ethers in the gasoline you buy, check with the service station operator. To meet seasonal air quality standards, some areas require the use of "oxygenated" fuel.

Volvo allows the use of the following "oxygenated" fuels; however, the octane ratings listed on this page must still be met.

Alcohol - Ethanol: Fuels containing up to 10% ethanol by volume may be used. Ethanol may also be referred to as Ethyl alcohol, or "Gasohol".

Ethers - MTBE: Fuels containing up to 15% MTBE may be used.

pg. 87 Starting and driving

Carbon Monoxide - Important Warning

Carbon monoxide is a poisonous, colorless, and odorless gas. It is present in all exhaust gases. If you ever smell exhaust fumes inside the vehicle, make sure the passenger compartment is ventilated, and immediately return the vehicle to your retailer for correction.

Fuel Formulations

Do not use gasoline that contains lead as a knock inhibitor, and do not use lead additives. Besides damaging the exhaust emission control systems on your vehicle, lead has been strongly linked to certain forms of cancer.

Many fuels contain benzene as a solvent. Unburned benzene has been strongly linked to certain forms of cancer. If you live in an area where you must fill your own gas tank, take precautions. These may include:

- standing upwind away from the filler nozzle while refueling
- refueling only at gas stations with vapor recovery systems that fully seal the mouth of the filler neck during refueling
- wearing neoprene gloves while handling a fuel filler nozzle.

Use of Additives

With the exception of gas line antifreeze during winter months, do not add solvents, thickeners, or other store-bought additives to your vehicle's fuel, cooling, or lubricating systems. Overuse may damage your

engine, and some of these additives contain organically volatile chemicals. Do not needlessly expose yourself to these chemicals.

pg. 88 Starting and driving



Fuel filler door

Press the button on the light switch panel (see illustration on [page 29](#)) when the vehicle is at a standstill to unlock the fuel filler door. Please note that the fuel filler door will remain unlocked until the vehicle begins to move forward. An audible click will be heard when the fuel filler door relocks.

If you intend to leave your vehicle while it is being refueled, this feature enables you to lock the doors/tailgate while leaving the fuel filler door unlocked.

You can also keep the vehicle locked if you remain inside it during refueling. The central locking button does not lock the fuel filler door.

Be sure the fuel filler door is not obstructed and is completely closed after refueling.

Open the fuel filler cap slowly during hot weather.

NOTE: During a transitional period, a small number of service stations may still have fuel nozzles that are not compatible with the fuel filler neck on vehicles equipped with the evaporative control system.

Refueling

Fuel tank capacity:

The fuel tank's capacity is 21.1 US gals. (80 liters) with sufficient volume left over to accommodate possible expansion of the fuel in hot weather. Be aware that the "usable" tank capacity will be somewhat less than the specified maximum. When the fuel level is low, such factors as ambient temperature, the fuel's "Reid vapor pressure" characteristics, and terrain can affect the fuel pump's ability to supply the

engine with an adequate supply of fuel. Therefore, it is advisable to refuel as soon as possible when the needle nears the red zone, or when the fuel warning light comes on.



WARNING!

Never carry a cell phone that is **switched on** while refueling your vehicle. If the phone rings, this may cause a spark that could ignite gasoline fumes, resulting in fire and injury.

CAUTION

- Do not refuel with the engine running *. Turn the ignition off or to position I. If the ignition is on, an incorrect reading could occur in the fuel gauge
- After refueling, close the fuel filler cap by turning it clockwise until it clicks into place*.
- Allow for fuel expansion by not overfilling the tank. Overfilling could also cause damage to the emission control systems.
- Avoid spilling gasoline during refueling. In addition to causing damage to the environment, gasolines containing alcohol can cause damage to painted surfaces, which may not be covered under the New Vehicle Limited Warranty.
- Do not use gasolines containing methanol (methyl alcohol, wood alcohol). This practice can result in vehicle performance deterioration and can damage critical parts in the fuel system. Such damage may not be covered under the New Vehicle Limited Warranty.

* If the fuel filler cap is not closed tightly or if the engine is running when the vehicle is refueled, the Check Engine Light (malfunction indicator lamp) may indicate a fault. However, your vehicle's performance will not be affected. Use only Volvo original or approved fuel filler caps.

pg. 89 Starting and driving

Starting the engine

1. Fasten the seat belt.



WARNING!

Before starting, check that the seat, steering wheel and mirrors are adjusted properly. Make sure the brake pedal can be depressed completely. Adjust the seat if necessary. See [pages 58, 60](#).

2. Apply the parking brake if not already set. The gear selector is locked in the **(P)**ark position (Shiftlock).

Manual transmission: the clutch must be fully depressed.

3. Without touching the accelerator pedal, turn the ignition key* to the starting position. Allow the starter to operate for up to 10 seconds. Release the key as soon as the engine starts. If the engine fails to start, repeat this step.

NOTE:

- On certain models, when the vehicle is started, idle speed may be noticeably higher than normal for a short period, depending on the temperature of the engine.

This has been done to help bring components in the emission control system to their normal operating temperature as quickly as possible, which enables them to function normally.

- For cold starts at altitudes above 6000 ft (1800 meters), depress the accelerator pedal halfway and turn the key to the starting position. Release the pedal slowly when the engine starts.

4. To release the gear selector from the **(P)**ark position, the engine must be running (or the ignition key must be in position II) and the brake pedal must be depressed.

5. Select the desired gear. The gear engages after a very slight delay which is especially noticeable when selecting R.

NOTE: Your vehicle is equipped with a Keylock system. When the engine is switched off, the gear selector must be in the **(P)**ark position before the key can be removed from the ignition switch.

When starting in cold weather, the transmission may shift up at slightly higher engine speeds than normal until the automatic transmission fluid reaches normal operating temperature.

Do not race a cold engine immediately after starting. Oil flow may not reach some lubrication points fast enough to prevent engine damage.

* If two of the keys to your vehicle are close together, e.g., on the same key ring, when you try to start the vehicle, this could cause interference in the immobilizer system and result in the vehicle not starting. If this should occur, remove one of the keys from the key ring before trying to start the vehicle again.

CAUTION**Automatic transmission**

The engine should be idling when you move the gear selector. Never accelerate until after you feel the transmission engage! Accelerating immediately after selecting a gear will cause harsh engagement and premature transmission wear.

Selecting **P** or **N** when idling at a standstill for prolonged periods of time will help prevent overheating of the automatic transmission fluid.



WARNING!

Always place the gear selector in Park and apply the parking brake before leaving the vehicle. Never leave the vehicle unattended with the engine running.

Always open garage doors fully before starting the engine inside a garage to ensure adequate ventilation. The exhaust gases contain carbon monoxide, which is invisible and odorless but very poisonous.

pg. 90 Starting and driving

Starting the vehicle (cont'd)

Ignition switch and steering wheel lock

0 Locked position: Remove the key to lock the steering wheel *.



WARNING!

Never turn the key to position 0 while driving or when the vehicle is being towed.


I Intermediate position** -

“radio position”: Certain accessories, radio, etc. on, daytime running lights off.

II Drive position: The key position when driving. The vehicle's entire electrical system is connected.

III Start position: Release the key when the engine starts. The key returns automatically to the Drive position.

A chime will sound if the key is left in the ignition and the driver's door is opened.



Autostart (V8 AWD only)

This function makes it possible to start the vehicle without holding the key in the start position (position III) until the engine starts. Turn the key to position III and release it. The starter motor will then operate automatically (for up to ten seconds) until the engine starts.

Steering wheel lock

The steering wheel lock might be under tension when the vehicle is parked.

Turn the steering wheel slightly to free the ignition key.

In order to help reduce vehicle theft, make sure the steering wheel lock is engaged before leaving the vehicle.



WARNING!

Never switch off the ignition (turn the ignition key to position 0) or remove the key from the ignition switch while the vehicle is in motion. This could cause the steering wheel to lock, which would make the vehicle impossible to steer.

* The gear selector must be in the **(P)**ark position (automatic transmission).

** Please be aware that leaving the key in this position will increase battery drain.

pg. 91 Starting and driving

General information

Economical driving conserves natural resources

Better driving economy may be obtained by thinking ahead, avoiding rapid starts and stops and adjusting the speed of your vehicle to immediate traffic conditions. Observe the following rules:

- Bring the engine to normal operating temperature as soon as possible by driving with a light foot on the accelerator pedal for the first few minutes of operation. A cold engine uses more fuel and is subject to increased wear.
- Whenever possible, avoid using the vehicle for driving short distances. This does not allow the engine to reach normal operating temperature.
- Drive carefully and avoid rapid acceleration and hard braking.
- Use the transmission's **(D)**rive position as often as possible and avoid using "kickdown" to help improve fuel economy.
- Do not exceed posted speed limits.
- Avoid carrying unnecessary items (extra load) in the vehicle.
- Maintain correct tire pressure. Check tire pressure regularly (when tires are cold).

- Remove snow tires when threat of snow or ice has ended.
- Note that roof racks, ski racks, etc, increase air resistance and also fuel consumption.
- At highway driving speeds, fuel consumption will be lower with the air conditioning on and the windows closed than with the air conditioning off and the windows open.
- Using the onboard trip computer's fuel consumption modes can help you learn how to drive more economically.

Other factors that decrease gas mileage are:

- Dirty air cleaner
- Dirty engine oil and clogged oil filter
- Dragging brakes
- Incorrect front end alignment

Some of the above mentioned items and others are checked at the standard Maintenance intervals.

Weight distribution affects handling

At the specified curb weight your vehicle has a tendency to understeer, which means that the steering wheel has to be turned more than might seem appropriate for the curvature of a bend. This ensures good stability and reduces the risk of rear wheel skid. Remember that these properties can alter with the vehicle load. The heavier the load in the cargo area, the less the tendency to understeer.



WARNING!

Driving with the tailgate open: Driving with the tailgate open could lead to poisonous exhaust gases entering the passenger compartment. If the tailgate must be kept open for any reason, proceed as follows

- Close the windows
- Set the ventilation system control to air flow to floor, windshield and side windows and blower control to its highest setting.

CAUTION

Drive slowly and carefully if going through standing water (i.e. flooded roadways, etc.). Damage to the engine could result if excess water is drawn in through the air intake system. Never drive the vehicle in water deeper than 18 inches (48 cm).

pg. 92 Starting and driving

General information (contd)

Handling, roadholding

Vehicle load, tire design and inflation pressure all affect vehicle handling. Therefore, check that the tires are inflated to the recommended pressure according to the vehicle load. See "Tire pressure" section.

Loads should be distributed so that capacity weight or maximum permissible axle loads are not exceeded.

Driving on rough/unpaved surfaces

The Volvo XC90 is designed primarily for onroad driving, and it has excellent handling characteristics on very rough or unpaved roads.

When driving on poorly maintained or unpaved roads, please keep the following in mind:

- Reduce speed on rough surfaces to minimize possible damage to the vehicle's underbody.
- When driving on soft surfaces such as dry sand or snow, try to avoid stopping if at all possible.



WARNING!

Avoid driving diagonally across steep inclines as this could increase the risk of a roll-over. Try to drive straight up or down the slope.

If the road is very steep, avoid turning the vehicle around to help avoid the risk of rolling over. Back the vehicle up or down the incline instead.

NOTE: Avoid driving on steep inclines if the fuel tank is nearly empty. If the flow of fuel to the engine is interrupted due to the vehicle's angle of inclination, this could result in damage to the three-way catalytic converter. We recommend keeping the fuel tank at least half full when driving on steep inclines.

Driving through water

- The vehicle should not be driven through water that is deeper than 18 inches (48 cm). Driving through deeper water could result in damage to transmission components or the differential, or to the engine if excess water is drawn in through the air intake system.
- Drive slowly and avoid stopping when driving through water.
- After having driven through water, apply the brakes lightly several times to remove water, mud, etc from the brake discs.
- Never allow the vehicle to stand in water above the door sills. This could result in damage to the electrical system.

Conserving electrical current

Keep the following in mind to help minimize battery drain:

- When the engine is not running, avoid turning the ignition key to position II (see [page 90](#)). Many electrical systems (the audio system, the optional infotainment/navigation systems, power windows, etc) will function with the ignition key in position I. This position reduces drain on the battery.
- Please keep in mind that using systems, accessories, etc that consume a great deal of current when the engine is not running could result in the battery being completely drained.

NOTE: A warning message will be displayed in the text window in the instrument panel when the battery charge is low.

pg. 93 Starting and driving

Automatic transmission with Geartronic



P Park

Use this position when starting the engine or parking the vehicle.

Never use P while the vehicle is in motion.

The parking brake should also be set whenever the vehicle is parked.

The gear selector is mechanically locked in the P position (SHIFTLOCK). To release the gear selector from this position, the engine must be running (or the ignition key must be in position II) and the brake pedal must be depressed.

N (Neutral)

Neutral - no gear engaged. Use the parking brake.



WARNING!


Never leave the vehicle unattended when the engine is running. If, by mistake, the gear selector is moved from P, the vehicle may start moving.

R (Reverse)

Never engage **R** while the vehicle is moving forward.

D (Drive)

D is the normal driving position and should be used as often as possible to help improve fuel economy. The vehicle should not be moving when shifting from **R** to the **D** position.



Shiftgate positions

NOTE:

- 5-cylinder turbo engine: 5 forward speeds.
- 8-cylinder engine: 6 forward speeds.

Automatic transmission - shift gate positions

Depress the button on the front of the gear selector knob to move between the R, N, D, and P positions.

Kickdown

Automatic shift to a lower gear (kickdown) is achieved by depressing the accelerator pedal fully and briskly. An upshift will occur when approaching the top speed for a particular gear or by releasing the accelerator pedal slightly. Kickdown can be used for maximum acceleration or when passing at highway speeds.

NOTE: The gear selector must be in the D (Drive) position for kickdown to function.

pg. 94 Starting and driving

Automatic transmission with Geartronic (contd)**Manual shifting - Geartronic**

You can move the gear selector freely between the (**MAN**)ual and (**D**)rive positions while driving.

- Models equipped with a 5-cylinder turbo engine have five forward speeds, and models with the V8 engine have 6 forward speeds.

- A "lock-up" feature ¹ reduces engine speed and help saves fuel.

The currently selected gear will be displayed in the instrument panel (see [page 22](#)).

- To access the **(MAN)ual** shifting position from **(D)rive**, move the gear selector to the left to **MAN**.
- To return to the **(D)rive** position from **MAN**, move the gear selector to the right.

While driving

If you select the **(MAN)ual** position while driving, the gear that was being used in the **(D)rive** position will also initially be selected in **(MAN)ual** position.

- Move the gear selector forward (toward "+") to shift to a higher gear or rearward (toward "-") to shift to a lower gear.
- If you hold the gear selector toward "-", the transmission will downshift one gear and will utilize the braking power of the engine. If the current speed is too high for using a lower gear, the downshift will not occur until the speed has decreased enough to allow the lower gear to be used.
- If you slow down to a very low speed, the transmission will automatically shift down.
- When starting in the **(MAN)ual** position, 3rd gear is the highest gear that may be selected.

¹ Five-speed transmission: gears 3, 4, and 5

Six-speed transmission: gears 2, 3, 4, 5, and 6.



5-cylinder turbo and V8 models

W - Winter/Wet driving mode - enhanced vehicle traction

- Mode W will only function if the gear selector is in the **(D)rive** position.
- Press the button at the base of the gear selector to engage/disengage this driving mode (see illustration).
- When the W driving mode is engaged, this is displayed in the instrument panel (see [page 22](#)).

This mode may be selected for starting/moving off on slippery roads.

All Wheel Drive

All Wheel Drive (AWD) - general information

Your Volvo can be equipped with permanent All Wheel Drive (option), which means that power is distributed automatically between the front and rear wheels. Under normal driving conditions, most of the engine's power is directed to the front wheels. However, if there is any tendency for the front wheels to spin, an electronically controlled coupling distributes power to the wheels that have the best traction.

Tire dimensions

Volvo recommends that you always drive on tires of the same brand, size, construction (radial), tread pattern, load-, speed-, traction-, temperature-, and treadwear rating. Never drive on mixed tires, except for brief periods when the temporary spare tire is in use.

Always use properly inflated tires of correct dimensions. Tire size and inflation pressures are shown on the tire inflation pressure placards, located on the driver's side B-pillar (the structural member at the side of the vehicle, at the rear of the driver's door opening), or on the inside of the fuel filler door on Canadian models.

Temporary Spare

The temporary spare tire is for temporary, lowspeed, short-distance use only. Replace it with a full-sized tire as soon as possible. Do not drive on the temporary spare at speeds above 50 m.p.h. (80km/h) or for distances greater than 50 miles (80 km).

Never install snow chains on a temporary spare.



[Contents](#) | [Top of Page](#)

Brake system

BRAKE Brake circuit malfunction

The brake system is a hydraulic system consisting of two master cylinders and two separate brake circuits. If a problem should occur in one of these circuits, it is still possible to stop the vehicle with the other brake circuit.

If the brake pedal must be depressed farther than normal and requires greater foot pressure, the stopping distance will be longer.

A warning light in the instrument panel will light up to warn the driver that a fault has occurred.

If this light comes on while driving or braking, stop immediately and check the brake fluid level in the reservoir.

NOTE: Press the brake pedal hard and maintain pressure on the pedal - do not pump the brakes.



WARNING!

If the fluid level is below the MIN mark in the reservoir or if a "Brake failure - Service urgent" message is displayed in the text window: **DO NOT DRIVE**. Have the vehicle towed to a Volvo retailer and have the brake system inspected.

NOTE: When the vehicle is at a standstill and the engine is idling, e.g. at a traffic light and the brake pedal is depressed, the pedal may go down slightly. This is a normal function of the power-assisted brake system.

Power brakes function only when the engine is running

The power brakes utilize vacuum pressure which is only created when the engine is running. Never let the vehicle roll to a stop with the engine switched off.

If the power brakes are not working, the brake pedal must be pressed approximately four times harder than usual to make up for the lack of power assistance. This can happen for example when towing your vehicle or if the engine is switched off when the vehicle is rolling. The brake pedal feels harder than usual.

Water on brake discs and brake pads affects braking

Driving in rain and slush or passing through an automatic car wash can cause water to collect on the brake discs and pads. This will cause a delay in braking effect when the pedal is depressed. To avoid such a delay when the brakes are needed, depress the pedal occasionally when driving through rain, slush, etc. This will remove the water from the brakes. Check that brake application feels normal. This should also be done after washing or starting in very damp or cold weather.

Severe strain on the brake system

The brakes will be subject to severe strain when driving in mountains or hilly areas, or when towing a trailer. Vehicle speed is usually slower, which means that the cooling of the brakes is less efficient than when driving on level roads. To reduce the strain on the brakes, shift into a lower gear and let the engine help with the braking. Do not forget that if you are towing a trailer, the brakes will be subjected to a greater than normal load.

pg. 97 Starting and driving

Brake system (contd)



Anti-lock brakes (ABS)

If the warning lamp lights up there is a malfunction of the ABS system (the standard braking system will however function) and the vehicle should be driven cautiously to a Volvo retailer for inspection. The Anti-lock Braking System (ABS) helps to improve vehicle control (stopping and steering) during severe braking conditions by limiting brake lockup. When the system "senses" impending lockup, braking pressure is automatically modulated in order to help prevent lockup, which could lead to a skid.

This system performs a self-diagnostic test when the engine is started and when the vehicle first reaches a speed of approximately 12 mph (20 km/h). The brake pedal will pulsate several times and a sound may be audible from the ABS control module. This is normal.

To obtain optimal effect from the ABS system, constant pressure should be kept on the brake pedal. Do not pump the brake pedal.

The switching of the ABS modulator will be audible and the brake pedal will pulsate during braking. Please be aware that ABS does not increase the absolute braking potential of the vehicle. While control will be enhanced, ABS will not shorten stopping distances on slippery surfaces.

ABS with EBD (Electronic Brake Force Distribution)

EBD is an integrated part of the ABS system. EBD regulates the hydraulic pressure to the rear brakes to help provide optimal braking capacity. The brake pedal will pulsate during braking, which is normal.

If the BRAKE and ABS warning lights come on at the same time, this could indicate a fault in the brake system.

- Stop the vehicle in a suitable place and switch off the engine.
- Restart the engine.
- If both warning lights go off, no further action is required.
- If both lights are still on after the engine has been restarted, switch off the engine again and check the brake fluid level (see [page 147](#) for the location of the brake fluid reservoir).
- If the brake fluid level is above the MIN mark, drive carefully to an authorized Volvo retailer and have the brake system inspected.



WARNING!

If the fluid level is below the MIN mark in the reservoir or if a "Brake failure - Service urgent" message is displayed in the text window: **DO NOT DRIVE**. Have the vehicle towed to a Volvo retailer and have the brake system inspected.

Emergency Brake Assistance (EBA)

EBA is designed to provide full brake effect immediately in the event of sudden, hard braking. The system is activated by the speed with which you depress the brake pedal.

NOTE:

- When the EBA system is activated, the brake pedal will go down and pressure in the brake system immediately increases to the maximum level. You must maintain full pressure on the brake pedal in order to utilize the system completely. EBA is automatically deactivated when the brake pedal is released.
- When the vehicle has been parked for some time, the brake pedal may sink more than usual when the engine is started. This is normal and the pedal will return to its usual position when it is released.

pg. 98 Starting and driving

Dynamic Stability Traction Control (DSTC)



The DSTC system on the Volvo XC90 consists of a number of functions:

1. Traction control (TC)

This function is designed to help reduce wheel spin by transferring power from a drive wheel that begins to lose traction to the wheel on the opposite side of the vehicle (on the same axle). TC monitors and compares the rotational speed of the drive wheels. If one of the drive wheels shows a tendency to spin,

the difference in speed is immediately detected. This triggers the Anti-lock Brake System, which brakes the spinning wheel until the difference in rotational speed is corrected.

TC is most active at low speeds, and a pulsating sound will be audible when the system is regulating wheel spin. This is quite normal.

This is one of the DSTC system's permanent functions and is not affected when the DSTC button on the center control panel is pressed.

2. Spin control (SC)

The spin control function is designed to help prevent the drive wheels from spinning while the vehicle is accelerating. This is done by temporarily reducing engine torque to the drive wheels, which helps improve tractive force.

Under certain circumstances, such as when driving with snow chains, or driving in deep snow or loose sand, it may be advisable to temporarily switch off this function for maximum tractive force. This is done by pressing the DSTC button on the center control panel for at least a half a second.

When the SC function has been switched off:

- The text window will briefly display "DSTC SPIN CONTROL OFF"
- The LED in the DSTC button will be off.

3. Active Yaw Control (AYC)

This function helps maintain directional stability, for example when cornering, by braking one or more of the wheels if the vehicle shows a tendency to skid or slide laterally. This is done by activating the Anti-lock Braking System. A pulsating sound will be audible when the function is active, which is quite normal. If you apply the brakes while this function is active, the brake pedal will feel stiffer than usual.

This is also one of the DSTC system's permanent functions and is not affected when the DSTC button on the center control panel is pressed.

4. Roll Stability Control (RSC)

RSC utilizes a gyro-sensor to monitor the vehicle's angle of inclination, and the rate at which this angle changes. If necessary, RSC activates the Anti-lock Brake System to brake one or more of the wheels to help maintain stability. A pulsating sound will be audible when the function is active, which is quite normal. If you apply the brakes while this function is active, the brake pedal will feel stiffer than usual.

This is one of the DSTC system's permanent functions and is not affected when the DSTC button on the center control panel is pressed.

The DSTC button

The DSTC button in the center control panel is used to switch the Spin Control (SC) function on or off.

The button must be pressed for at least a half second to prevent SC from being switched off inadvertently.

When the system has been switched off, the green indicator lamp in the button will go out and "DSTC SPIN CONTROL OFF" will be displayed in the text window.

All DSTC functions are (re)activated each time the engine is started.

pg. 99 Starting and driving

Dynamic Stability Traction Control (DSTC) (contd)



The Stability Control indicator light

The Stability Control indicator light will come on for approximately 2 seconds when the ignition is switched on as the system performs a self-diagnostic test.

The Stability Control indicator light will flash when:

- Traction Control is actively functioning to help avoid drive-wheel spin.
- Spin Control is actively functioning to help avoid loss of traction during acceleration.
- Active Yaw Control is actively functioning to help avoid skids or lateral slides.
- Roll Stability Control is actively functioning to help avoid a roll-over situation.

The warning symbol in the instrument panel


A steady yellow glow indicates:

- That the system has been automatically disengaged due to a fault. "ANTI SKID SERVICE REQUIRED" will be displayed in the text window. If this occurs, stop the vehicle in a suitable place, switch off and restart the engine. If the light remains on, an authorized Volvo retailer should check the system.
- In the event of high brake temperature, "TRACTION CONTROL TEMPORARILY OFF" will be displayed in the text window.

The system will automatically switch on again when the brakes have cooled.

pg. 100 Starting and driving

Park assist



A-front (accessory as available), B-rear (option)

Front/rear park assist

The park assist system(s) are designed to assist you when driving into parking spaces, garages, etc. They utilize ultrasound sensors located in the bumpers to measure the distance to a vehicle or other object, or a person who may be close to the front or rear of the vehicle.

When is park assist active?

Front: the system is active from the time the engine is started until the car exceeds a speed of approximately 10 mph (15 km/h).

Rear: when the engine is running and reverse gear is selected.

NOTE:

- If the vehicle is equipped with front and rear park assist, both systems will either be activated or deactivated together. They cannot be used separately.
- The indicator light in the button (see the illustration on [page 27](#)) will light up to indicate that park assist system(s) are activated.

When park assist is actively working:

1. The audio system's volume will be reduced.
2. An intermittent signal will be audible from the speakers to indicate that you are approaching a person, object, parked vehicle, etc.

The signals begin when the distance between the bumper and the object is:

Rear: approximately 5 feet (1.5 meters)

Front: approximately 2.5 ft (0.8 meters).

3. At a distance of approximately 1 foot (30 cm), the signal will become constant.

Deactivating the system(s)

1. Press the Park assist button on the center console (see [page 27](#)) to temporarily deactivate the system(s).
2. The indicator light in the button will go out when the system(s) have been deactivated.
3. If the vehicle is equipped with front and rear park assist, both systems will be deactivated by pressing

the button.

NOTE: It may be necessary to deactivate one or both of the park assist systems in certain cases.

- **Rear park assist:** towing a trailer, carrying bicycles in a rear-mounted carrier, etc, could trigger the rear park assist system's sensors.
- **Front park assist:** it may not be possible to combine auxiliary headlights and front park assist since these lights could trigger the system's sensors.

Faults in the system

If a fault should occur in the system, the LED in the button will be switched off and a message will be displayed in the text window.

Cleaning the sensors

For the system to function properly, the sensors in the front and/or rear bumpers should be kept clean. They can be cleaned with car washing detergent and a sponge.




WARNING!

This system is designed to be a supplementary aid when the vehicle is backing up. It is not, however, intended to replace the driver's attention and judgement.

pg. 101 Starting and driving

Towing



Positions for attaching towing eyelets

Emergency towing

The towing eyelet is located in the tool bag, under the floor of the cargo area. This eyelet must be screwed into the positions provided on the right sides of either the front or rear bumper (see illustrations).

To attach the towing eyelet:

A Use a coin to pry open the lower edge of the cover (A).

B Screw the towing eyelet (C) in place (B), first by hand and then using the tire iron until it is securely in place.

After the vehicle has been towed, the eyelet should be removed and returned to the tool bag. Press the cover back into position.

Precautions when the vehicle is in tow

- The steering wheel must be unlocked. Turn the ignition key to position I or II.
- The gear selector must be in position N.
- Maximum speed: 50 mph (80 km/h). Do not exceed the maximum allowable towing speed.
- Maximum distance with front wheels on ground: 50 miles (80 km).
- While the vehicle is being towed, try to keep the tow rope taut at all times.
- The vehicle should only be towed in forward direction.

CAUTION


- Please check with state and local authorities before attempting this type of towing, as vehicles being towed are subject to regulations regarding maximum towing speed, length and type of towing device, lighting, etc.
- If the vehicle's battery is dead, do not attempt to start the vehicle by pushing or pulling it as this will damage the three-way catalytic converter(s). The engine must be jump started using an auxiliary battery (see [page 103](#)).
- If the vehicle is being towed on a flat bed truck, the towing eyelets must not be used to secure the vehicle on the flat bed. Consult the tow truck operator.

**WARNING!**

- Remember that the power brakes and power steering will not function when engine is not running. The braking and steering systems will function but the brake pedal pressure required is 3 - 4 times above normal and greater steering effort must be exerted.
- The towing eyelets must not be used for pulling the vehicle out of a ditch or for any similar purpose involving severe strain. Do not use the towing eyelets to pull the vehicle up onto a flat bed tow truck.

pg. 102 Starting and driving

Towing (contd)



Towing vehicles with front wheel drive/All Wheel Drive

Volvo recommends the use of flat bed equipment.

If wheel lift equipment must be used, please use extreme caution to help avoid damage to the vehicle. **In this case, the vehicle should be towed with the rear wheels on the ground if at all possible.**

If it is absolutely necessary to tow the vehicle with the front wheels on the ground, please refer to the towing information on the previous page.

CAUTION

Sling-type equipment applied at the front will damage radiator and air conditioning lines.

It is equally important not to use sling-type equipment at the rear or apply lifting equipment inside the rear wheels; serious damage to the rear axle may result.

If the vehicle is being towed on a flat bed truck, the towing eyelets must not be used to secure the vehicle on the flat bed. Consult the tow truck operator.




WARNING!

Do not use the towing eyelets to pull the vehicle up onto a flat bed tow truck.

pg. 103 Starting and driving

Jump starting



Jump starting

Follow these instructions to jump start your vehicle's dead battery or to jump start another vehicle's dead battery using your vehicle.

Although your vehicle's battery is located under the floor of the cargo area, jumper cables should be connected in the **engine compartment**, to the points shown in the illustrations.

If the 12-volt auxiliary battery to be used is in another vehicle, check that the vehicles are not touching to prevent premature completion of a circuit. Be sure to follow jump starting instructions provided for the other vehicle.

To jump start your vehicle:

- Switch off the ignition.
- First connect the auxiliary battery positive (+) terminal (1) to the positive (+) terminal in your vehicle's engine compartment (2), located under a small black plastic cover attached to the fuse box cover, marked with a "+" sign.

Remove the cover on the main fuse box if necessary to access this terminal. Then connect the auxiliary battery's negative (-) terminal (3) to the ground point in your vehicle's engine compartment (4).

- Start the engine in the assisting vehicle, then start the engine in the vehicle with dead battery.
- After the engine has started, first remove the negative (-) terminal jumper cable. Then remove the positive (+) terminal jumper cable.



WARNING!

PROPOSITION 65 WARNING!

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer and reproductive harm. Wash hands after handling

**WARNING!**

- Do not connect the jumper cable to any part of the fuel system or to any moving parts. Avoid touching hot manifolds.
- Never expose the battery to open flame or electric spark.
- Do not smoke near the battery.
- Batteries generate hydrogen gas, which is flammable and explosive.
- Battery fluid contains sulphuric acid. Do not allow battery fluid to contact eyes, skin, fabrics or painted surfaces. If contact occurs, flush the affected area immediately with water. Obtain medical help immediately if eyes are affected.
- Failure to follow the instructions for jump starting can lead to personal injury.

pg. 104 Starting and driving

Towing a trailer

The maximum weights recommended by Volvo for trailers with brakes are shown in the table below.

No. of occupants	1	2	3	4	5	6	7
Seating position	Front seat	Front seat	2nd row of seats	2nd row of seats	2nd row of seats	Optional 3rd row of seats	Optional 3rd row of seats
All Wheel Drive	5,000 lbs (2250 kg)	5,000 lbs (2250 kg)	4,500 lbs (2050 kg)	3,700 lbs (1700 kg)	2,900 lbs (1350 kg)	1,800 lbs (800 kg)	Trailer towing not recommended
Max. trailer hitch tongue load	500 lbs (225 kg)	500 lbs (225 kg)	450 lbs (205 kg)	370 lbs (170 kg)	290 lbs (135 kg)	180 lbs (80 kg)	-
Front Wheel Drive	4,000 lbs (1800 kg)	4,000 lbs (1800 kg)	4,000 lbs (1800 kg)	4,000 lbs (1800 kg)	3,700 lbs (1650 kg)	2,500 lbs (1150 kg)	1,400 lbs (650 kg)

Max. trailer hitch tongue load	400 lbs (180 kg)	400 lbs (180 kg)	400 lbs (180 kg)	400 lbs (180 kg)	370 lbs (165 kg)	250 lbs (115 kg)	140 lbs (65 kg)
--------------------------------	------------------	------------------	------------------	------------------	------------------	------------------	-----------------

NOTE:

- **Recommended hitch tongue load: not more than 10% of the trailer's weight.**

The trailer load should be positioned so that it does not shift and the tongue load should be 10% of the trailer's weight. However, the tongue load should not exceed the maximum permissible weights indicated in the table above.

- When towing trailers without brakes, the maximum permissible trailer weight is 1,700 lbs (750 kg).
- If necessary, redistribute the weight of any cargo in the trailer to avoid excessive weight on the trailer hitch.
- The maximum trailer weight listed in the table for All Wheel Drive models, 5,000 lbs (2250 kg) is only applicable when there are not more than two occupants in the vehicle, in the front seats, with a combined weight of 300 lbs (135 kg), with no other cargo in the vehicle.

pg. 105 Starting and driving

Towing a trailer (contd)

- The maximum weight listed for Front Wheel Drive models, 4,000 lbs (1800 kg) is only applicable when there are not more than four occupants in the vehicle, in the front seats and second row of seats, with a combined weight of 600 lbs (270 kg), with no other cargo in the vehicle.
- Please be aware that the load on the trailer hitch is part of the vehicle's total load carrying capacity. The amount of cargo in the vehicle and the trailer must be limited so that the gross vehicle weight and maximum permissible rear axle weight ([see page 173](#)) are not exceeded.
- Vehicles used for towing a trailer on a regular basis, or for long-distance highway towing should be equipped with an automatic transmission oil cooler and Volvo's automatic self-leveling system for the rear suspension. Consult your Volvo retailer.
- Volvo recommends the use of Volvo trailer hitches that are specially designed for the vehicle.
- All Volvo models are equipped with energy-absorbing shock-mounted bumpers. Trailer hitch installation should not interfere with the proper operation of this bumper system.
- Increase tire pressure to recommended full inflation pressure. See chapter "Wheels and tires."
- When your vehicle is new, avoid towing heavy trailers during the first 620 miles (1,000 km).
- Engine and transmission are subject to increased loads. Therefore, engine coolant temperature should be closely watched when driving in hot climates or hilly terrain. Use a lower gear and turn off the air conditioner if the temperature gauge needle enters the red range.
- If the automatic transmission begins to overheat, a message will be displayed in the text window.
- Hauling a trailer affects handling, durability, and economy.
- It is necessary to balance trailer brakes with the towing vehicle brakes to provide a safe stop (check and observe state/local regulations).

- Do not connect the trailer's brake system directly to the vehicle's brake system.
- Remove the ball and drawbar assembly when the hitch is not being used.
- Volvo recommends the use of synthetic engine oil when towing a trailer over long distances or in mountainous areas.



WARNING!

- Bumper-attached trailer hitches must not be used on Volvos, nor should safety chains be attached to the bumper.

Trailer hitches attaching to the vehicle rear axle must not be used.

- Never connect a trailer's hydraulic brake system directly to the vehicle brake system, nor a trailer's lighting system directly to the vehicle lighting system. Consult your nearest authorized Volvo retailer for correct installation.

- When towing a trailer, the trailer's safety wire must be correctly fastened to the hole or hook provided in the trailer hitch on the vehicle. The safety wire should never be fastened to or wound around the drawbar ball.

NOTE!

- When parking the vehicle with a trailer on a hill, apply the parking brake before putting the gear selector in (P)ark. When starting on a hill, put the gear selector in (D)rive before releasing the parking brake. Always follow the trailer manufacturer's recommendations for wheel chocking.
- If you use the manual (Geartronic) shift positions while towing a trailer, make sure the gear you select does not put too much strain on the engine (using too high a gear).

pg. 106 Starting and driving

Smoother starts with a trailer Models equipped with the V8-engine and the 6-speed automatic transmission have a built-in function that reduces acceleration slightly in first gear when the vehicle is towing a trailer. This is done to help avoid wheel spin and to make starting off smoother.


- This function is activated when the trailer's electrical connector is plugged into the electrical socket mounted near the trailer hitch.
- The function is automatically deactivated when the trailer's wiring is disconnected from the socket. The vehicle will then accelerate normally.

NOTE: Since this function is activated when a connector is plugged into the electrical socket near the trailer hitch, it will be activated by any electrical equipment (e.g. bicycle racks with lighting, etc) that is plugged in, and will remain active until the equipment is unplugged from the socket.

Leveling

If your vehicle is equipped with automatic levelling, the rear suspension always retains the correct ride height regardless of the load.

- The system adjusts the rear suspension to the correct level after the vehicle has been driven a short distance.
- When the vehicle is stationary, the rear suspension lowers, which is normal.



A - ball holder, B - locking bolt, C - safety wire attachment, D - hitch assembly, E - cotter pin

Detachable trailer hitch - installing/removing

Installing the ball holder

1. If necessary, remove the cotter pin from the locking bolt and slide the locking bolt out of the hitch assembly.
2. Slide the ball holder into the hitch assembly.
3. Align the hole in the ball holder with the one in the hitch assembly.
4. Slide the locking bolt through the hitch assembly/ball holder.
5. Insert the cotter pin in the hole at the end of the locking bolt.


Removing the ball holder

1. Remove the cotter pin from the locking bolt and slide the locking bolt out of the ball holder/hitch assembly.
2. Pull the ball holder out of the hitch assembly.

NOTE: A cover for the hitch assembly can be purchased from your Volvo retailer.

pg. 107 Starting and driving

Load carriers




Positioning the load carriers

Make sure that the wing-shaped load carriers are installed on the roof rails with the rounded edge forward (see the inset illustration above). The load carriers are identical and can be placed anywhere along the roof rails.

When not in use, we recommend that the front load carrier be placed approximately 2 inches (5 cm) in front of the center roof rail anchorage point and the rear load carrier approximately 1.5 inches (3.5 cm) in front of the rear rail anchorage. This will help to reduce wind noise.

NOTE: Volvo accessories mounted on these load carriers will require T-track mounting hardware for correct installation. Please consult your Volvo retailer.




Installing the load carriers

Make sure that the load carrier is pressed firmly out against the roof rail. Screw the load carrier in place. Use the supplied torque wrench and tighten to the mark on the wrench (corresponding to 6 Nm). See illustration.



WARNING!

Loads carried on the vehicle's roof should not exceed 220 lbs (100 kg), including the weight of the load carriers and any other load carrying equipment (ski boxes, bicycle racks, etc.). Excessive loads on the roof can adversely affect the handling and roadholding characteristics of the vehicle.



Load carrier cover

The vehicle's ignition key or the stud on the edge of the supplied torque wrench can be used to undo or tighten the cover. Turn a quarter turn (90 degrees). See illustration.

pg. 108 Starting and driving

Cold weather precautions

If you wish to check your vehicle before the approach of cold weather, the following advice is worth noting:

- Make sure that the engine coolant contains 50 percent antifreeze. Any other mixture will reduce freeze protection. This gives protection against freezing down to -31°F (-35°C). See section "Coolant". **The use of "recycled" antifreeze is not approved by Volvo. Different types of antifreeze must not be mixed.**
- Volvo recommends using only genuine Volvo antifreeze in your vehicle's radiator. Your Volvo retailer stocks plenty of Volvo engine coolant to help protect your vehicle during cold weather.
- Try to keep the **fuel tank** well filled - this prevents the formation of condensation in the tank. In addition, in extremely cold weather conditions it is worthwhile to add fuel line de-icer before refueling.
- The viscosity of the **engine oil** is important. Oil with low viscosity (thinner oil) improves cold-weather starting as well as decreasing fuel consumption while the engine is warming up. For winter use, 5W-30 oil, particularly the synthetic type*, is recommended. Be sure to use good quality oil but do not use cold-weather oil for hard driving or in warm weather. See section "Engine oil" for more information.
- The load placed on the **battery** is greater during the winter since the windshield wipers, lighting, etc.

are used more often. Moreover, the capacity of the battery decreases as the temperature drops. In very cold weather, a poorly charged battery can freeze and be damaged. It is therefore advisable to check the state of charge more frequently and spray an antirust oil on the battery posts.

- Volvo recommends the use of **snow tires** on all four wheels for winter driving - see section "Wheels and tires."
- To prevent the **washer fluid reservoir** from freezing, add washer solvents containing antifreeze (see [page 147](#) for the location of the washer fluid reservoir).

This is important since dirt is often splashed on the windshield during winter driving, requiring the frequent use of the washers and wipers. Volvo Washer Solvent should be diluted as follows:

Down to 14° F (-10° C): 1 part washer solvent and 4 parts water

Down to 5° F (-15° C): 1 part washer solvent and 3 parts water

Down to 0° F (-18° C): 1 part washer solvent and 2 parts water

Down to -18° F (-28° C): 1 part washer solvent and 1 part water

- Use Volvo Teflon Lock Spray in the locks.

NOTE: Avoid the use of de-icing sprays as they can cause damage to the locks.

W Winter/Wet driving mode-enhanced vehicle traction

- Mode W will only function if the gear selector is in the **(D)**rive position.
- Press the button at the base of the gear selector to engage/disengage this driving mode.
- An LED in the button will light up to indicate that W is engaged and this will also be displayed in the instrument panel (see [page 22](#)).
- This mode may be selected for starting/moving off on slippery roads.

* Synthetic oil is not used when the oil is changed at the normal maintenance intervals except at owner request and at additional charge. Please consult your Volvo retailer.

pg. 109 Starting and driving

Before a long distance trip

It is always worthwhile to have your vehicle checked at a Volvo retailer before driving long distances. Your retailer will also be able to supply you with bulbs, fuses, spark plugs and wiper blades for your use in the event that problems occur.

As a minimum, the following items should be checked before any long trip:

- Check that engine runs smoothly and that fuel consumption is normal.
- Check for fuel, oil, and fluid leakage
- Check transmission oil level*.
- Check condition of drive belts.
- Check state of the battery's charge.

- Examine tires carefully (the spare tire as well), and replace those that are worn. Check tire pressures.
- The brakes, front wheel alignment, and steering gear should be checked by your Volvo retailer only.
- Check all lights, including high beams.
- Reflective warning triangles are legally required in some states/provinces.
- Have a word with your Volvo retailer if you intend to drive in countries where it may be difficult to obtain the correct fuel.
- Consider your destination. If you will be driving through an area where snow or ice are likely to occur, consider snow tires.

* To prevent injury from contact with hot surfaces, do not inspect your vehicle's transmission fluid yourself. Have your vehicle's transmission fluid level inspected by a qualified Volvo service technician.

pg. 110 Starting and driving



[Contents](#) | [Top of Page](#)

2 0 0 6 VOLVO XC90

Vehicle care

pg. 135 Vehicle care

[Washing and cleaning the vehicle](#) [136](#)

[Paint touch up](#) [139](#)

pg. 136 Vehicle care

Washing and cleaning the vehicle

- The vehicle should be washed at regular intervals since dirt, dust, insects and tar spots adhere to the paint and may cause damage. It is particularly important to wash the vehicle frequently in the wintertime to prevent corrosion, when salt has been used on the roads.
- When washing the vehicle, do not expose it to direct sunlight. Use lukewarm water to soften the dirt before you wash with a sponge, and plenty of water, to avoid scratching.
- Bird droppings: Remove from paintwork as soon as possible. Otherwise the finish may be permanently damaged.
- A detergent can be used to facilitate the softening of dirt and oil.
- A water-soluble grease solvent may be used in cases of sticky dirt. However, use a wash place equipped with a drainage separator.

CAUTION

If the vehicle is equipped with chromeplated aluminum wheels, use only special car washing detergents to clean the wheels. Wheel cleaning agents can permanently stain chrome-plated wheels

- Dry the vehicle with a clean chamois and remember to clean the drain holes in the doors and rocker panels.
- Tar spots can be removed with kerosene or tar remover after the vehicle has been washed.
- A stiff-bristle brush and lukewarm soapy water can be used to clean the wiper blades. Frequent cleaning improves visibility considerably.
- Wash off the dirt from the underside (wheel housings, fenders, etc.).

- In areas of high industrial fallout, more frequent washing is recommended.
- After cleaning the engine, the spark plug wells should be inspected for water and blown dry if necessary.

Suitable detergents: Special vehicle washing detergents should be used. A suitable mixture is about 2.5 fl. oz. (8.5 cl) of detergent to 2.6 US gal. (10 liters) of warm water. After washing with a detergent the vehicle should be well rinsed with clean water.

Exterior plastic components

Cleaning exterior plastic components should be done with a cleaning agent specially designed for this purpose. Solvents or stain removers should not be used. Consult your Volvo retailer.

CAUTION

- During high pressure washing, the spray mouthpiece must never be closer to the vehicle than 13" (30 cm). Do not spray into the locks.
- When washing or steam cleaning the engine, avoid spraying water or steam directly on the electrical components or toward the rear side of the engine.

Special moonroof cautions:

- Always close the moonroof and visor before washing your vehicle.
- Never use abrasive cleaning agents on the moonroof.
- Never use wax on the rubber seals around the moonroof.

NOTE: When washing the vehicle, remember to remove dirt from the drain holes in the doors and sills.



WARNING!

When the vehicle is driven immediately after being washed, apply the brakes several times in order to remove any moisture from the brake linings.

Engine cleaning agents should not be used when the engine is warm. This constitutes a fire risk.

pg. 137 Vehicle care

Automatic washing - simple and quick

- We do NOT recommend washing your vehicle in an automatic wash during the first six months (because the paint will not have hardened sufficiently).
- An automatic wash is a simple and quick way to clean your vehicle, but it is worth remembering that it may not be as thorough as when you yourself go over the vehicle with sponge and water. Keeping the underbody clean is most important, especially in the winter. Some automatic washers do not have facilities for washing the underbody.
- Before driving into an automatic car wash, make sure that side view mirrors, auxiliary lamps, etc, are

secure, and that any antenna(s) are retracted or removed. Otherwise there is risk of the machine dislodging them.

Polishing and Waxing

- Normally, polishing is not required during the first year after delivery, however, waxing may be beneficial.
 - Before applying polish or wax the vehicle must be washed and dried. Tar spots can be removed with kerosene or tar remover. Difficult spots may require a fine rubbing compound.
 - After polishing use liquid or paste wax.
 - Several commercially available products contain both polish and wax.
 - Waxing alone does not substitute for polishing a dull surface.
 - A wide range of polymer-based waxes can be purchased today. These waxes are easy to use and produce a long-lasting, high-gloss finish that protects the bodywork against oxidation, road dirt and fading.
 - Do not polish or wax your vehicle in direct sunlight (the surface of the vehicle should not be warmer than 113° F (45° C)).
-

CAUTION:

Volvo does not recommend the use of long-life or durable paint protection coatings, some of which may claim to prevent pitting, fading, oxidation, etc. These coatings have not been tested by Volvo for compatibility with your vehicle's clear coat. Some of them may cause the clear coat to soften, crack, or cloud. Damage caused by application of paint protection coatings may not be covered under your vehicle's paint warranty.

Mirrors/side windows with the water repellent glass coating-option

- Do not apply wax, degreasing agents, etc to this glass. This could damage the coating.
- Clean the glass surface with care to avoid scratching.
- Use only suitable plastic scrapers to remove ice or snow from the windows.

NOTE: The water repellent coating is subject to natural wear.

- In order to maintain the coating's water repellent characteristics, it should be treated with a special compound that is available at your Volvo retailer.
- This treatment should be carried out for the first time after three years, and thereafter once a year.

Cleaning the upholstery

Fabric

Clean with soapy water or a detergent. For more difficult spots caused by oil, ice cream, shoe polish, grease, etc., use a clothing/fabric stain remover. Consult your Volvo retailer.

Interior plastic components

Cleaning interior plastic components should be done with a cleaning agent specially designed for this purpose. Consult your Volvo retailer.

Alcantera™ suede-like material

Suede-like upholstery can be cleaned with a soft cloth and mild soap solution.

Leather care

Volvo's leather upholstery is manufactured with a protectant to repel soiling. Over time, sunlight, grease and dirt can break down the protection. Staining, cracking, scuffing, and fading can result.

Volvo offers an easy-to-use, non-greasy leather care kit formulated to clean and beautify your vehicle's leather, and to renew the protective qualities of its finish. The cleaner removes dirt and oil buildup. The light cream protectant restores a barrier against soil and sunlight.

Volvo also offers a special leather softener that should be applied after the cleaner and protectant. It leaves leather soft and smooth, and reduces friction between leather and other finishes in the vehicle.

Volvo recommends cleaning, protecting and conditioning your vehicle's leather two to four times a year. Ask your Volvo retailer about Leather Care Kit 951 0251 and Leather Softener 943 7429.

CAUTION:

- Under no circumstances should gasoline, naphtha or similar cleaning agents be used on the plastic or the leather since these can cause damage.
 - Take extra care when removing stains such as ink or lipstick since the coloring can spread.
 - Use solvents sparingly. Too much solvent can damage the seat padding.
 - Start from the outside of the stain and work toward the center.
 - Sharp objects (e.g. pencils or pens in a pocket) or velcro fasteners on clothing may damage the textile upholstery.
-

Cleaning the seat belts

Clean only with lukewarm water and a mild soap solution.

Cleaning floor mats

The floor mats should be vacuumed or brushed clean regularly, especially during winter when they should be taken out for drying. Spots on textile mats can be removed with a mild detergent.

pg. 139 Vehicle care

Paint touch up

Paint damage requires immediate attention to avoid rusting. Make it a habit to check the finish regularly - when washing the vehicle for instance. Touch-up if necessary.

Paint repairs require special equipment and skill. Contact your Volvo retailer for any extensive damage.

Minor scratches can be repaired by using Volvo touch-up paint.

NOTE: When ordering touch-up paint from your Volvo retailer, use the paint code indicated on the model plate. The plate is located in the engine compartment.

Color code

Make sure you have the right color. The color code number is on the data plate in the engine compartment.



Minor stone chips and scratches

Material:

- Primer - can
- Paint - touch-up pen
- Brush
- Masking tape
- If the stone chip has not gone down to the bare metal and an undamaged color coat remains, you can add paint immediately after removing dirt.

NOTE: When touching up the vehicle, it should be clean and dry. The surface temperature should be above 60° F (15° C).

Minor scratches on the surface

If the stone chip has not penetrated down to the metal and an undamaged layer of paint remains, the touch-up paint can be applied as soon as the spot has been cleaned.

Deep scratches

1. Place a strip of masking tape over the damaged surface. Pull the tape off so that any loose flakes of paint adhere to it.
2. Thoroughly mix the primer and apply it with a small brush.

When the primer surface is dry, the paint can be applied using a brush. Mix the paint thoroughly; apply several thin paint coats and let dry after each application.



3. If there is a longer scratch, you may want to protect surrounding paint by masking it off.

pg. 140 Vehicle care

This page intentionally left blank



[Contents](#) | [Top of Page](#)

2006 VOLVO XC90

Wheels and tires

pg. 111 Wheels and tires

<u>General information</u>	<u>112</u>
<u>Tire inflation pressure tables</u>	<u>116</u>
<u>Tire Pressure Monitoring System (TPMS) - option on certain U.S. models only</u>	<u>117</u>
<u>Tire designations</u>	<u>119</u>
<u>Glossary of tire terminology</u>	<u>120</u>
<u>Vehicle loading</u>	<u>121</u>
<u>Uniform Tire Quality Grading</u>	<u>122</u>
<u>Snow chains, snow tire, studded tires</u>	<u>123</u>
<u>Temporary Spare</u>	<u>124</u>
<u>Changing wheels</u>	<u>125</u>
<u>Tire sealing system (option on certain models)</u>	<u>130</u>

pg. 112 Wheels and tires

General information

General information

Your vehicle is equipped with tires according to the vehicle's tire information placard on the Bpillar (the structural member at the side of the vehicle, at the rear of the driver's door opening), or on the inside of the fuel filler door on Canadian models.


The tires have good road holding characteristics and offer good handling on dry and wet surfaces. It should be noted however that the tires have been developed to give these features on snow/ice-free surfaces.

Certain models are equipped with "all-season" tires, which provide a somewhat higher degree of road holding on slippery surfaces than tires without the "all-season" rating. However, for optimum road holding on icy or snow-covered roads, we recommend suitable winter tires on all four wheels. When replacing tires, be sure that the new tires are the same size designation, type (radial) and preferably from the same manufacturer, on all four wheels. Otherwise there is a risk of altering the car's roadholding and handling characteristics.

Storing wheels and tires

When storing complete wheels (tires mounted on rims), they should be suspended off the floor or placed on their sides on the floor.

Tires not mounted on rims should be stored on their sides or standing upright, but should not be suspended.



Tread wear indicator

CAUTION

Tires should preferably be stored in a cool, dry, dark place, and should never be stored in close proximity to solvents, gasoline, oils, etc.

Tread wear indicator

The tires have wear indicator strips running across or parallel to the tread. The letters TWI are printed on the side of the tire. When approximately 1/16" (1.6 mm) is left on the tread, these strips become visible and indicate that the tire should be replaced. Tires with less than 1/16" (1.6 mm) tread offer very poor traction.


When replacing worn tires, it is recommended that the tire be identical in type (radial) and size as the one being replaced. Using a tire of the same make (manufacturer) will prevent alteration of the driving characteristics of the vehicle.



WARNING!

- The wheel and tire sizes for your Volvo are specified to meet stringent stability and handling requirements. Unapproved wheel/ tire size combinations can negatively affect your vehicle's stability and handling. Approved tire sizes are shown in the Tire inflation pressure tables on [page 116](#).
- Any damage caused by installation of unapproved wheel/tire size combinations will not be covered by your new vehicle warranty. Volvo assumes no responsibility for death, injury, or expenses that may result from such installations.

pg. 113 Wheels and tires



New tires

Remember that tires are perishable goods. As of 2000, the manufacturing week and year will be indicated with 4 digits (e.g. 1502 means that the tire illustrated was manufactured during week 15 of 2002).

Tire age

Tires degrade over time, even when they are not being used, which can affect their reliability and roadholding characteristics. Therefore, all tires older than 6 years (including the spare tire and winter tires) should be inspected by a qualified technician, regardless of appearance or mileage. Heat caused by hot climates or frequent high loading conditions can accelerate the aging process.

A tire's age can be determined by the DOT stamp on the sidewall (see the illustration above).


A tire with e.g., visible cracks or discoloration should be replaced immediately.

Improving tire economy:

- Maintain correct tire pressure. See the tire pressure table on [page 116](#).
- Drive smoothly: avoid fast starts, hard braking and tire screeching.
- Tire wear increases with speed.
- Correct front wheel alignment is very important.

- Unbalanced wheels impair tire economy and driving comfort.
- Tires must maintain the same direction of rotation throughout their lifetime.
- When replacing tires, the tires with the most tread should be mounted on the rear wheels to reduce the chance of oversteer during hard braking. Hitting curbs or potholes can damage the tires and/or wheels permanently.


pg. 114 Wheels and tires



Tire inflation placards on U.S. models

Tire inflation

Check tire inflation pressure regularly. A table listing the recommended inflation pressure for your vehicle can be found on [page 116](#). Tire inflation pressure placards are also located on the driver's side B-pillar (the structural member at the side of the vehicle, at the rear of the driver's door opening), or on the inside of the fuel filler door on Canadian models. These placards indicate the designation of the factory-mounted tires on your vehicle, as well as load limits and inflation pressure.



Tire inflation placard on Canadian models

NOTE: The placards shown indicate inflation pressure for the tires installed on the car at the factory only.

- Use a tire gauge to check the tire inflation pressure, including the spare, at least once a month and before long trips. You are strongly urged to buy a reliable tire pressure gauge, as automatic service station gauges may be inaccurate.
- Use the recommended cold inflation pressure for optimum tire performance and wear.
- Under-inflation or over-inflation may cause uneven treadwear patterns.



WARNING!

- Under-inflation is the most common cause of tire failure and may result in severe tire cracking, tread separation, or "blowout," with unexpected loss of vehicle control and increased risk of injury.
- Under-inflated tires reduce the load carrying capacity of your vehicle.

When weather temperature changes occur, tire inflation pressures also change. A 10-degree temperature drop causes a corresponding drop of 1 psi (7 kPa) in inflation pressure. Check your tire pressures frequently and adjust them to the proper pressure, which can be found on the vehicle's tire information placard or certification label.

Checking tire pressure

Cold tires

Inflation pressure should be checked when the tires are cold.

The tires are considered to be cold when they have the same temperature as the surrounding (ambient) air.

This temperature is normally reached after the car has been parked for at least 3 hours.

pg. 115 Wheels and tires

After driving a distance of approximately 1 mile (1.6 km), the tires are considered to be hot. If you have to drive farther than this distance to pump your tire(s), check and record the tire pressure first and add the appropriate air pressure when you get to the pump.

If checking tire pressure when the tire is hot, never "bleed" or reduce air pressure. The tires are hot from driving and it is normal for pressures to increase above recommended cold pressures. A hot tire at or below recommended cold inflation pressure could be significantly under-inflated.

To check inflation pressure:

1. Remove the cap from the valve on one tire, then firmly press the tire gauge onto the valve.
2. Add air to reach the recommended air pressure
3. Replace the valve cap.
4. Repeat this procedure for each tire, including the spare.
5. Visually inspect the tires to make sure there are no nails or other objects embedded that could puncture the tire and cause an air leak.
6. Check the sidewalls to make sure there are no gouges, cuts, bulges or other irregularities.

NOTE:

- If you overfill the tire, release air by pushing on the metal stem in the center of the valve. Then recheck the pressure with your tire gauge.
- Some spare tires require higher inflation pressure than the other tires. Consult the tire inflation table on [page 116](#) or see the inflation pressure placard.

pg. 116 Wheels and tires

Tire inflation pressure tables

Tire pressures recommended by Volvo for your vehicle. Refer to the tire inflation placard for information specific to the tires installed on your vehicle at the factory.

Cold tire pressure for vehicle loads up to 1160 lbs (525 kg) ^a		
Tire size	Front, psi (kPa)	Rear, psi (kPa)
XC90		
225/70R16	39 (270)	39 (270)
235/65R17		
235/60R18		
255/50R19		

Temporary spare tire T155/85R18	61 (420)	61 (420)
------------------------------------	----------	----------

a. These weights include the weight of all occupants of the car plus cargo.

Optional tire pressure. These inflation pressures may only be used when the vehicle is not fully loaded.

Optional cold tire pressure that may only be used for vehicle loads up to 495 lbs (225 kg).		
Tire size	Front, psi (kPa)	Rear, psi (kPa)
XC90		
225/70R16	32 (220)	32 (220)
235/65R17		
235/60R18		
255/50R19		
Temporary spare tire T155/85R18	61 (420)	61 (420)

NOTE: The optional tire pressure shown in the table above may not be used on XC90s equipped with the Tire Pressure Monitoring System (option as available). Vehicles with this system must use the standard tire pressure listed in the table in the left column (39 psi/270 kPa).

pg. 117 Wheels and tires

Tire Pressure Monitoring System (TPMS) - option on certain U.S. models only

The tire pressure monitoring system uses sensors mounted in the tire valves to check inflation pressure levels. When the vehicle is moving at a speed of 20 mph (30 km/h) or faster, these sensors transmit inflation pressure data to a receiver located in the vehicle.


USA - FCC ID: MRXTG315AM04

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**WARNING!**

The TPMS system uses a radio frequency of 315 MHz. Accessory electrical equipment using the same frequency could interfere with TPMS and should not be installed in the vehicle. Please consult your Volvo retailer, a qualified Volvo service technician, or the accessory equipment's supplier for further information.



When low inflation pressure is detected, TPMS will light up the tire pressure warning light () (also referred to as a telltale) in the instrument panel, and will display a message in the text window. The wording of this message is determined by the degree of inflation pressure loss.

NOTE: If a fault occurs in TPMS, the tire pressure warning light will flash for approximately 1 minute and TIRE PRESS SYST SERVICE REQUIRED will be displayed.

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should consult the appropriate section of this owner's manual to determine the proper tire inflation pressure.) When the low tire pressure telltale is illuminated, one or more of your tires is significantly underinflated. You should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Your vehicle has also been equipped with a TPMS malfunction telltale to indicate when the system is not operating properly. When the malfunction telltale is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement tires on the vehicle. Always check the TPMS malfunction telltale after replacing one or more tires on your vehicle to ensure that the replacement tires are compatible with the TPMS.

NOTE: TPMS indicates low tire pressure but does not replace normal tire maintenance. For information on correct tire pressure, please refer to the table on [page 116](#), or consult your Volvo retailer.

Erasing warning messages

When a low tire pressure warning message has been displayed, and the tire pressure warning light has come on:

1. Use a tire pressure gauge to check the inflation pressure of all four tires.
2. Re-inflate the tire(s) to the correct pressure (consult the tire pressure placard or the table on [page 116](#)).
3. Drive the car for at least one minute at a speed of 20 mph (30 km/h) or faster.

This will erase the warning text and the warning light will go out.

(contd. on following page)

pg. 118 Wheels and tires

Changing tires

Please note the following when changing or replacing the factory installed TPMS wheels/tires on the vehicle:

- Only the factory-mounted wheels are equipped with TPMS sensors in the valves.
- If the vehicle is equipped with a temporary spare tire, this tire does not have a TPMS sensor.
- If winter wheels without TPMS sensors are mounted on the vehicle, TIRE PRESS SYST SERVICE REQUIRED will be displayed each time the vehicle is driven above 25 mph (40 km/h) for 10 minutes or more.
- Once TPMS sensors are properly installed, the warning message should not reappear.
- Volvo recommends that TPMS sensors be fitted on all wheels used on the vehicle. Volvo does not recommend moving sensors back and forth between sets of wheels.

CAUTION


When inflating tires with TPMS valves, press the pump's mouthpiece straight onto the valve to help avoid bending or otherwise damaging the valve.



WARNING!

Incorrect inflation pressure could lead to tire failure, resulting in a loss of control of the vehicle.

pg. 119 Wheels and tires



Federal law mandates that tire manufacturers place standardized information on the sidewall of all tires (see the illustration).

The following information is listed on the tire sidewall:

The tire designation (the following figures are examples of a tire designation):

1. 215: the width of the tire (in millimeters) from sidewall edge to sidewall edge. The larger the number, the wider the tire.
2. 65: The ratio of the tire's height to its width.
3. R: Radial tire.
4. 15: The diameter of the wheel rim (in inches).
5. 95: The tire's load index. In this example, a load index of 95 equals a maximum load of 1521 lbs (690 kg).
6. H: The tire's speed rating, or the maximum speed at which the tire is designed to be driven for extended periods of time, carrying a permissible load for the vehicle, and with correct inflation pressure. For example, H indicates a speed rating of 130 mph (210 km/h).

NOTE: This information may not appear on the tire because it is not required by law.

7. M+S or M/S = Mud and Snow, AT = All Terrain, AS = All Season

8. **U.S. DOT Tire Identification Number (TIN):** This begins with the letters "DOT" and indicates that the tire meets all federal standards. The next two numbers or letters are the plant code where it was manufactured, the next two are the tire size code and the last four numbers represent the week and year the tire was built. For example, the numbers 317 mean the 31st week of 1997. After 2000 the numbers go to four digits. For example, 2501 means the 25th week of 2001. The numbers in between are marketing codes used at the manufacturer's discretion. This information helps a tire manufacturer identify a tire for safety recall purposes.

9. **Tire Ply Composition and Material Used:** Indicates the number of plies indicates or the number of layers of rubber-coated fabric in the tire tread and sidewall. Tire manufacturers also must indicate the ply materials in the tire and the sidewall, which include steel, nylon, polyester, and others.

10. **Maximum Load:** Indicates the maximum load in pounds and kilograms that can be carried by the tire. Refer to the vehicle's tire information placard or the safety certification label, located on the B-Pillar or the driver's door or on the inside of the fuel filler door on Canadian models, for the correct tire pressure for your vehicle.

11. **Treadwear, Traction, and Temperature grades:** See [page 122](#) for more information.

12. **Maximum permissible inflation pressure:** the greatest amount of air pressure that should ever be put in the tire. This limit is set by the tire manufacturer.

pg. 120 Wheels and tires

Glossary of tire terminology

The tire suppliers may have additional markings, notes or warnings such as standard load, radial tubeless, etc.

Glossary of tire terminology

- **Tire information placard:** A placard showing the OE (Original Equipment) tire sizes, recommended inflation pressure, and the maximum weight the vehicle can carry.
- **Tire Identification Number (TIN):** A number on the sidewall of each tire providing information about the tire brand and manufacturing plant, tire size and date of manufacturer.
- **Inflation pressure:** A measure of the amount of air in a tire.
- **Standard load:** A class of P-metric or Metric tires designed to carry a maximum load at 35 psi [37 psi (2.5 bar) for Metric tires]. Increasing the inflation pressure beyond this pressure will not increase the tires load carrying capability.
- **Extra load:** A class of P-metric or Metric tires designed to carry a heavier maximum load at 41 psi [43 psi (2.9 bar) for Metric tires]. Increasing the inflation pressure beyond this pressure will not increase the tires load carrying capability.
- **kPa:** Kilopascal, a metric unit of air pressure.

- **PSI:** Pounds per square inch, a standard unit of air pressure.
- **B-pillar:** The structural member at the side of the vehicle behind the front door.
- **Bead area of the tire:** Area of the tire next to the rim.
- **Sidewall of the tire:** Area between the bead area and the tread.
- **Tread area of the tire:** Area of the perimeter of the tire that contacts the road when mounted on the vehicle.
- **Rim:** The metal support (wheel) for a tire or a tire and tube assembly upon which the tire beads are seated.
- **Maximum load rating:** a figure indicating the maximum load in pounds and kilograms that can be carried by the tire. This rating is established by the tire manufacturer.
- **Maximum permissible inflation pressure:** the greatest amount of air pressure that should ever be put in the tire. This limit is set by the tire manufacturer.
- **Recommended tire inflation pressure:** inflation pressure, established by Volvo, which is based on the type of tires that are mounted on a vehicle at the factory. This inflation pressure is affected by the number of occupants in the car, the amount of cargo, and the speed at which the vehicle will be driven for a prolonged period. This information can be found on the tire inflation placard(s) located on the driver's side B-pillar or on the inside of the fuel filler door on Canadian models, and in the tire inflation table in this chapter.
- **Cold tires:** The tires are considered to be cold when they have the same temperature as the surrounding (ambient) air. This temperature is normally reached after the car has been parked for at least 3 hours.

pg. 121 Wheels and tires

Vehicle loading

Properly loading your vehicle will provide maximum return of vehicle design performance. Before loading your vehicle, familiarize yourself with the following terms for determining your vehicle's weight ratings, with or without a trailer, from the vehicle's Federal/Canadian Motor Vehicle Safety Standards (FMVSS/CMVSS) label, and the vehicle's tire information placard:

Curb weight

The weight of the vehicle including a full tank of fuel and all standard equipment. It does not include passengers, cargo, or optional equipment.

Capacity weight

All weight added to the curb weight, including cargo and optional equipment. When towing, trailer hitch tongue load is also part of cargo weight.

NOTE: For trailer towing information, please refer to the section "Towing a trailer" on [page 104](#).

Permissible axle weight

The maximum allowable weight that can be carried by a single axle (front or rear). These numbers are shown on the Federal/Canadian Motor Vehicle Safety Standards (FMVSS/CMVSS) label. The total load on each axle must never exceed its maximum permissible weight.

Gross vehicle weight (GVW)

The vehicle's curb weight + cargo + passengers.

NOTE:

- The location of the various labels in your vehicle can be found on [page 172](#).
- A table listing important weight limits for your vehicle can be found on [page 173](#).

Steps for Determining Correct Load Limit

- (1) Locate the statement "the combined weight of occupants and cargo should never exceed XXX pounds" on your vehicle's placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3) Subtract the combined weight of the driver and passengers from XXX kilograms or XXX pounds.
- (4) The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. (1400-750 (5 x 150) = 650 lbs.)
- (5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- (6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual¹ to determine how this reduces the available cargo and luggage load capacity of your vehicle.



WARNING!

- Exceeding the permissible axle weight, gross vehicle weight, or any other weight rating limits can cause tire overheating resulting in permanent deformation or catastrophic failure.
- Do not use replacement tires with lower load carrying capacities than the tires that were original equipment on the vehicle because this will lower the vehicle's GVW rating. Replacement tires with a higher limit than the originals do not increase the vehicle's GVW rating limitations.

1. See "Towing a trailer" on [page 104](#)

Uniform Tire Quality Grading

ALL PASSENGER VEHICLE TIRES MUST CONFORM TO FEDERAL SAFETY REQUIREMENTS IN ADDITION TO THESE GRADES

Quality grades can be found, where applicable, on the tire sidewall between the tread shoulder and maximum section width. For example:

Treadwear 200 Traction AA Temperature A

TREADWEAR

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one half (1 1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and many depart significantly from the norm due to variation in driving habits, maintenance practices and differences in road characteristics and climate.

TRACTION

The traction grades, from highest to lowest, are AA, A, B, and C, as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.



WARNING!

The traction grade assigned to this tire is based on braking (straight-ahead) traction tests and is not a measure of cornering (turning) traction.

TEMPERATURE

The temperature grades are AA (the highest), A, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to minimum level of performance that all passenger vehicle tires must meet under the Federal Motor Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.



WARNING!

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, under-inflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

Snow chains, snow tire, studded tires

Snow chains

Snow chains can be used on your Volvo with the following restrictions:

- Snow chains should be installed on front wheels only. Use only Volvo approved snow chains.
- If accessory, aftermarket or "custom" tires and wheels are installed and are of a size different than the original tires and wheels, chains in some cases CANNOT be used. Sufficient clearances between chains and brakes, suspension and body components must be maintained.
- Some strap-on type chains will interfere with brake components and therefore CANNOT be used.
- All Wheel Drive models: Snow chains should only be installed on the front wheels. Only chains adapted for AWD models should be used.

NOTE: Consult your Volvo retailer for additional snow chain information.

CAUTION

- Check local regulations regarding the use of snow chains before installing.
- Always follow the chain manufacturer's installation instructions carefully. Install chains as tightly as possible and retighten periodically.
- Never exceed the chain manufacturer's specified maximum speed limit. (Under no circumstances should you exceed 31 mph 50 km/h)
- Avoid bumps, holes or sharp turns when driving with snow chains.
- The handling of the vehicle can be adversely affected when driving with chains. Avoid fast or sharp turns as well as locked wheel braking.

Snow tires, studded tires¹

Tires for winter use:

- Owners who live in or regularly commute through areas with sustained periods of snow or icy driving conditions are strongly advised to fit suitable winter tires to help retain the highest degree of traction.
- It is important to install winter tires on all four wheels to help retain traction during cornering, braking, and accelerating. Failure to do so could reduce traction to an unsafe level or adversely affect handling.
- Do not mix tires of different design as this could also negatively affect overall tire road grip.
- Winter tires wear more quickly on dry roads in warm weather. They should be removed when the winter driving season has ended.

- Studded tires should be run-in 300-600 miles (500-1000 km) during which the car should be driven as smoothly as possible to give the studs the opportunity to seat properly in the tires. The tires should have the same rotational direction throughout their entire lifetime.

NOTE: Please consult state or provincial regulations restricting the use of studded winter tires before installing such tires.

1. Where permitted

pg. 124 Wheels and tires

Temporary Spare

The spare tire in your car is called a "Temporary Spare".

Recommended tire pressure (see the placard on the B-pillar or on the fuel filler door) should be maintained irrespective of which position on the car the temporary spare tire is used on. In the event of damage to this tire, a new one can be purchased from your Volvo retailer.



WARNING!


! Current legislation prohibits the use of the "Temporary Spare" tire other than as a temporary replacement for a punctured tire. It must be replaced as soon as possible by a standard tire. Road holding and handling may be affected with the "Temporary Spare" in use. Do not exceed 50 mph (80 km/h). Do not drive farther than 50 miles (80 km) on a temporary spare tire.

CAUTION:

The car must not be driven with wheels of different dimensions or with a spare tire other than the one that came with the car. The use of different size wheels can seriously damage your car's transmission.

pg. 125 Wheels and tires

Changing wheels



Location of jack - five-seat model


Changing wheels¹

Location of jack - five-seat models

The jack is located to the right under the rear hatch in the cargo area floor. Lift this hatch and release the retaining strap to lift out the jack. The rear section of the jack's crank is held in place behind the battery. The tool bag is stored to the left under the hatch. The front section of the crank is stored in the tool bag. The tool bag also contains a tool for removing certain optional wheel covers. Consult your Volvo retailer.

NOTE: The rear section of the crank is enclosed in a protective sleeve that should be slid off before the crank is used. We recommend reinserting the crank into this sleeve before the crank is stowed.

If the vehicle is equipped with the optional grocery bag holder: Fold up the rear section of the cargo area floor, disconnect the grocery bag holder's retaining cords and fold up the lower section of the floor to access the tool bag.



Location of jack - seven-seat model

Location of jack - seven-seat models

hatch in the cargo area floor. Lift this hatch and release the retaining strap to slide out the jack. The rear section of the jack's crank is held in place behind the battery. The tool bag is stored to the left under the hatch. The front section of the crank is stored in the tool bag.

NOTE: The rear section of the crank is enclosed in a protective sleeve that should be slid off before the crank is used. We recommend reinserting the crank into this sleeve before the crank is stowed.


If the vehicle is equipped with the optional grocery bag holder: Fold up the rear section of the cargo area floor, disconnect the grocery bag holder's retaining cords and fold up the lower section of the floor.

CAUTION: Seven-seat models: Do not store objects in the area for the rear seat cushions (when the backrests are to be folded down). This could damage the cushions.

1. This applies to models not equipped with the tire sealing system (see [page 130](#) for information).

pg. 126 Wheels and tires

Changing wheels (contd)



Lowering the spare wheel, 1. Jack location in 5-seat models, 2. Jack location in 7-seat models

Changing wheels - lowering the spare wheel

The spare wheel is located under the floor of the rear cargo compartment. It can be lowered using the crank (see previous page for location).



WARNING!

When raising or lowering the spare wheel, please keep in mind that components in the exhaust system may be very hot.

Lowering the spare wheel:

1. Fold down the lower section of the tailgate.
2. Fold up the rear section of the floor in the cargo compartment.
3. Connect the two sections of the jack's crank.

4. Insert the hooked end of the crank in the spare wheel retaining attachment (see the illustration above).
5. Lower the spare wheel under the vehicle by turning the crank counterclockwise until it is not possible to turn it further.
6. Pivot the toggle at the end of the cable 90 degrees to release it from the spare wheel.
7. Crank up the cable again by turning the crank clockwise.


CAUTION

When the spare wheel is mounted on the vehicle, the retaining cable could damage the underside of the vehicle if it is not retracted.

8. Place the wheel with the flat tire in the vehicle's cargo compartment.

NOTE: The space under the vehicle is designed to hold the special spare wheel only. Other full-size wheels will not fit in this compartment.


pg. 127 Wheels and tires



Returning the spare wheel to its storage compartment

1. Use the crank (turn it counterclockwise) to lower the spare wheel's retaining cable.
2. Pass the toggle at the end of the cable through the center hole in the spare wheel. Pivot the toggle 90 degrees so that when raised, the wheel will rest on the toggle.
3. Retract the retaining cable slightly by slowly turning the crank clockwise several times.
4. Position the wheel so that it is not obstructed by components in the exhaust system.
5. Continue to raise the wheel by turning the crank clockwise. Raise the wheel a little bit at a time and guide it around the rear axle until it is securely seated in the storage area.
6. When it is no longer possible to turn the crank any further, check that the spare wheel is securely in position in the storage compartment.

Changing wheels (contd)



Jack attachment points


Jack attachments

There are two attachment points for the jack on each side of the vehicle. These attachment points are under the center of each door.



WARNING!

- There is an attachment point on each side of the vehicle located under the pillars between the front and rear doors. This point is used during the production process only, and is NOT intended for attaching the jack.
- The undersides of accessory running boards are not intended for attaching the jack.




Changing a wheel:

1. Park the vehicle on a firm, level, non-slippery surface.
2. Engage the parking brake and put the gear selector in the Park position.
3. Loosen the wheel bolts by exerting downward pressure on the lug wrench.
4. Remove the wheel cap (where applicable) using the lug wrench in the tool bag.
5. With the wheels still on the ground, use the lug wrench to loosen the wheel bolts 1/2 - 1 turn. Turn the bolts counterclockwise to loosen the bolts.

CAUTION

- The vehicle must not be driven with wheels of different dimensions or with a spare tire other than the one that came with the vehicle. The use of different size wheels can seriously damage your vehicle's transmission.
- Correct tightening torque on wheel bolts must be observed.
- The wheel bolts should never be greased or lubricated.
- Extended, chromed wheel bolts must not be used with steel rims, as they make it impossible to fit the hub caps.

*Attaching the jack**Jack on certain models*

6. Place the jack on the ground, under one of the attachment points (see the illustration on the previous page) and crank while simultaneously guiding the jack's attachment bracket onto the attachment point (see illustration above) The base of the jack must be flat on a level, firm, non-slippery surface. Before raising the vehicle, check that the jack is still correctly positioned in the attachment.

7. Raise the vehicle until the wheel to be changed is lifted off the ground.

8. Unscrew the wheel bolts completely and carefully remove the wheel so as not to damage the threads on the studs.

NOTE: To avoid excessive wear and the necessity of rebalancing, mark and reinstall wheels in the same location and position as before removal. To lessen the chance of imbalance, each wheel hub is equipped

2 0 0 6 VOLVO XC90

Maintenance

pg. 141 Maintenance

[Volvo maintenance](#) [142](#)

[Owner maintenance](#) [143](#)

[Emission inspection readiness](#) [144](#)

[Working on your vehicle](#) [145](#)

[Engine compartment](#) [147](#)

[Oils and fluids](#) [148](#)

[Wiper Blades](#) [152](#)

[Battery maintenance](#) [153](#)

[Bulbs](#) [156](#)

[Fuses](#) [164](#)

pg. 142 Maintenance

Volvo Maintenance

Maintenance Service

Periodic maintenance will help keep your vehicle running well. Your Warranty and Service Records Information booklet provides a comprehensive maintenance schedule up to 150,000 miles (240,000 km) of vehicle service. This maintenance program contains inspections and services necessary for the proper function of your car, and includes components that affect vehicle emissions. The maintenance services contain several checks that require special instruments and tools and therefore must be performed by a

qualified technician. Volvo advises you to follow the service program outlined in this booklet. To keep your Volvo in top condition, specify time-tested and proven Genuine Volvo Parts and Accessories.

The Federal Clean Air Act - U.S.

The Federal Clean Air Act requires vehicle manufacturers to furnish written instructions to the ultimate purchaser to assure the proper servicing and function of the components that control emissions. These services, which are listed in the "Warranty and Service Records Information booklet," are not covered by the warranty. You will be required to pay for labor and material used.

Maintenance

Your Volvo passed several major inspections before it was delivered to you, in accordance with Volvo specifications. The maintenance outlined in the Warranty and Service Records Information booklet, many of which will positively affect your vehicle's emissions, should be performed as indicated. It is recommended that receipts for vehicle emission maintenance be retained in case questions arise concerning maintenance.

Inspection and maintenance should also be performed anytime a malfunction is observed or suspected.

Applicable warranties - U.S./Canada

In accordance with applicable U.S. and Canadian regulations, the following list of warranties is provided.

- New Vehicle Limited Warranty
- Parts and Accessories Limited Warranty
- Corrosion Protection Limited Warranty
- Seat Belt and Supplemental Restraint Systems Limited Warranty
- Emission Design and Defect Warranty
- Emission Performance Warranty

These are the federal warranties; other warranties are provided as required by state/provincial law. Refer to your separate Warranty and Service Records Information booklet for detailed information concerning each of the warranties.

Vehicle Event Data (Black Box)

Your vehicle's driving and safety systems employ computers that monitor, and share with each other, information about your vehicle's operation. One or more of these computers may store what they monitor, either during normal vehicle operation or in a crash or near-crash event. Stored information may be read and used by:

- Volvo Car Corporation
- service and repair facilities
- law enforcement or government agencies
- others who may assert a legal right to know, or who obtain your consent to know such information.

Owner maintenance

Periodic maintenance requirements and intervals are described in your vehicle's Warranty and Service Records Information booklet.

The following points can be carried out between the normally scheduled maintenance services.

Each time the car is refueled:

- Check the engine oil level
- Clean the windshield, windshield wipers, headlights, and tail lights

Monthly:

- Check cold tire pressure in all tires. Inspect the tires for wear.
- Check that engine coolant and other fluid levels are between the indicated "min" and "max" markings.
- Clean interior glass surfaces with a glass cleaner and soft paper towels.
- Wipe driver information displays with a soft cloth.
- Visually inspect battery terminals for corrosion. Corrosion may indicate a loose terminal connector, or a battery near the end of its useful service life. Consult your Volvo retailer for additional information.

As needed:

- Wash the car, including the undercarriage, to reduce wear that can be caused by a buildup of dirt, and corrosion that can be caused by salt residues.
- Clean leaves and twigs from air intake vents at the base of the windshield, and from other places where they may collect.

NOTE: Complete service information for qualified technicians is available online for purchase or subscription at www.volvotechinfo.com.

Emission inspection readiness**What is an Onboard Diagnostic System (OBD II)?**

OBD II is part of your vehicle's computerized engine management system. It stores diagnostic information about your vehicle's emission controls. It can light the Check Engine light (MIL) if it detects an emission control "fault." A "fault" is a component or system that is not performing within an expected range. A fault may be permanent or temporary. OBD II will store a message about any fault.

How do states use OBD II for emission inspections?

Many states connect a computer directly to a vehicle's OBD II system. The inspector can then read "faults." In some states, this type of inspection has replaced the tailpipe emission test.

How can my vehicle fail OBD II emission inspection?

Your vehicle can fail OBD II emission inspection for any of the following reasons.


- If your Check Engine (MIL) light is lit, your vehicle may fail inspection.
- If your vehicle's Check Engine light was lit, but went out without any action on your part, OBD II will still have a recorded fault. Your vehicle may pass or fail, depending on the inspection practices in your area.
- If you had recent service that required disconnecting the battery, OBD II diagnostic information may be incomplete and "not ready" for inspection. A vehicle that is not ready may fail inspection.

How can I prepare for my next OBD II emission inspection?

- If your Check Engine (MIL) light is lit - or was lit but went out without service, have your vehicle diagnosed and, if necessary, serviced by a qualified Volvo technician.
- If you recently had service for a lit Check Engine light, or if you had service that required disconnecting the battery, a period of driving is necessary to bring the OBD II system to "ready" for inspection. A half-hour trip of mixed stop-and-go/ highway driving is typically needed to allow OBD II to reach readiness. Your Volvo retailer can provide you with more information on planning a trip.
- Maintain your vehicle in accordance with your vehicle's maintenance schedule.

pg. 145 Maintenance

Working you your vehicle



Reinforced lifting points

Hoisting the vehicle

If a garage jack is used to lift the vehicle, the two jack attachments points should be used. They are specially reinforced to bear the weight of the vehicle (see the illustration above). A garage jack can also be placed under the front of the engine support frame. Take care not to damage the splash guard under

the engine. Ensure that the jack is positioned so that the vehicle cannot slide off it. Always use axle stands or similar structures. The car's gross vehicle weight is between 5770 lb (2630 kg) and 6080 lb (2760 kg). Use a jack and stands rated for this weight.

If a two-post hoist is used to lift the vehicle, the front and rear lift arm pads should be centered under the reinforced lift plates on the inboard edge of the sill rail (see illustration).

Please note the following before you begin working on your vehicle:

Battery (see also [page 155](#) for more information on handling the battery)

- Ensure that the battery cables are correctly connected and tightened.
- Never disconnect the battery when the engine is running (e.g. when replacing the battery).
- The battery contains acid that is both corrosive and poisonous. It is important that the battery is handled in an environmentally friendly way. Let your Volvo retailer assist you.
- Never use a fast charger to charge the battery. The battery cables should be disconnected when recharging.



WARNING!

The ignition system has very high voltage! The voltage in the ignition system is dangerous!

Do not touch spark plugs, ignition cables or the ignition coil when the engine is running or the ignition is switched on!

The ignition should be switched off when:

- Conducting engine tests.
- Replacing parts in the ignition system, such as spark plugs, ignition coil, distributor, ignition cables, etc.
- Never try to repair any part of the SRS/SIPS/WHIPS/IC systems yourself. Any interference in the system could cause malfunction and serious injury. Any work should only be performed by an authorized Volvo workshop.

pg. 146 Maintenance

Belt check

Check the belt regularly to make sure it is in good condition and is clean. A worn or dirty belt can cause poor cooling and low alternator output as well as impair the operation of the power steering and the air conditioning unit.

NOTE: The drive belt is equipped with a self-tensioning mechanism and requires no adjustment between changes.

**WARNING!**

The engine must not be running when this check is performed.

Check coolant level

The cooling system must be filled with coolant and not leak to operate at maximum efficiency. Check the coolant level regularly. The level should be between the "MAX" and "MIN" marks on the expansion tank. The check should be made with particular thoroughness when the engine is new or when the cooling system has been drained.

Do not remove the filler cap other than for topping up with coolant. Frequent removal may prevent coolant circulation between the engine and the expansion tank during engine warm up and cooling.

Changing coolant

Normally, the coolant does not need to be changed. If the system must be drained, consult your Volvo retailer.

NOTE: Do not top off with water only. This reduces the rust-protective and antifreeze qualities of the coolant and has a lower boiling point. It can also cause damage to the cooling system if it should freeze. Top off with Volvo Genuine Coolant/Antifreeze only (a 50/50 mix of water and antifreeze).

CAUTION


The cooling system must always be kept filled to the correct level. If it is not kept filled, there can be high local temperatures in the engine which could result in damage. Different types of antifreeze/coolant may not be mixed.

**WARNING!**

Never remove the radiator cap while the engine is warm. Wait until the vehicle cools.

pg. 147 Maintenance

Engine compartment



Engine compartment

1. Brake fluid reservoir
2. Relay/fuse box
3. Air cleaner
4. Cooling fan
5. Radiator
6. Dipstick - engine oil
7. Filler cap - engine oil
8. Washer fluid reservoir
9. Power steering fluid reservoir
10. Expansion tank - coolant
11. Data plate
12. Battery (under floor in rear cargo area)



WARNING!

The cooling fan (4) may start or continue to operate (for up to 6 minutes) after the engine has been switched off.

pg. 148 Maintenance

Oil and fluids

Oil specifications

Engine oil must meet the minimum ILSAC specification GF-3, API SL, or ACEA A1/B1. Lower quality oils may not offer the same fuel economy, engine performance, or engine protection.

Volvo recommends  .

Depending on your driving habits, premium or synthetic oils may provide superior fuel economy and engine protection. Consult your Volvo retailer for recommendations on premium or synthetic oils.


Oil additives must not be used.

NOTE: Synthetic oil is not used when the oil is changed when the normal maintenance is carried out. This oil is only used at customer request, at additional charge. Please consult your Volvo retailer.

Oil Viscosity

Operation in hot climates.

For the protection of your engine when temperatures in your area exceed 86° F (30° C), Volvo recommends that you use an oil with suitable viscosity, as shown in the chart below.



Operation in temperate climates

Incorrect viscosity oil can shorten engine life. Under normal use when temperatures do not exceed 86° F (30° C), SAE 5W-30 will provide good fuel economy and engine protection. See the viscosity chart above.

Extreme engine operation

Synthetic oils meeting ACEA A5/B5 requirements are recommended for driving in areas of sustained temperature extremes (hot or cold), when towing a trailer over long distances, and for prolonged driving in mountainous areas.



American Petroleum Institute (API) symbol

American Petroleum Institute (API) symbol

- The API Service Symbol "donut" is divided into three parts:
- The upper section describes the oil's performance level.
- The center identifies the oil's viscosity.
- The lower section indicates whether the oil has demonstrated energy-conserving properties in a standard test in comparison to a reference oil.

pg. 149 Maintenance

Changing engine oil and oil filter

See the previous page for oil specifications and [page 176](#) for oil volumes. Refer to the Warranty and Service Records Information booklet for information on the oil change intervals.


NOTE:

- Volvo does not recommend the use of oil additives.
- Synthetic oil is not used when the oil is changed at the normal maintenance intervals except at owner request and at additional charge. Please consult your Volvo retailer.

Checking and adding oil

The oil level should be checked every time the vehicle is refueled. This is especially important during the period up to the first scheduled maintenance service.

- The car should be parked on a level surface when the oil is checked.
- **If the engine is warm**, wait for at least 10-15 minutes after the engine has been switched off before checking the oil.



Checking the oil

1. Pull out the dipstick and wipe it with a lintfree rag.

2. Reinsert the dipstick, pull it out, and check the oil level.
3. Add oil if necessary. If the level is close to the MIN mark, add approximately 1 US quart (1 liter) of oil.
4. Run the engine until it reaches normal operating temperature.
5. Switch off the engine and wait for at least 10-15 minutes and recheck the oil level. If necessary, add oil until the level is near the mark.



Oil level should be between the MIN and MAX marks on the dipstick

CAUTION

- Not checking the oil level regularly can result in serious engine damage if the oil level becomes too low.
- Never fill oil above the MAX mark. This could cause an increase in oil consumption.
- Not checking the oil level regularly can result in serious engine damage if the oil level becomes too low.
- Always add oil of the same type and viscosity as already used.




WARNING!

Do not allow oil to spill onto or come into contact with hot exhaust pipe surfaces.

pg. 150 Maintenance

Oil and fluids (contd)




Washer fluid reservoir

Washer fluid reservoir

The washer fluid reservoir is located in the engine compartment and holds approx. 6.8 US qt (6.5 liters). When there is less than approximately 1 US qt (1 liter) remaining in the reservoir, the washer fluid spray will be directed to the windshield only.

During cold weather, the reservoir should be filled with windshield washer solvent containing antifreeze.



Coolant reservoir

Changing coolant

Normally, the coolant does not need to be changed. If the system must be drained, consult your Volvo retailer.

NOTE: Do not top off with water only. This reduces the rust-protective and antifreeze qualities of the coolant and has a lower boiling point. It can also cause damage to the cooling system if it should freeze. Top off with Volvo Genuine Coolant/Antifreeze only (a 50/50 mix of water and antifreeze).

CAUTION

The cooling system must always be kept filled to the correct level. If it is not kept filled, there can be high local temperatures in the engine which could result in damage. Different types of antifreeze/coolant may not be mixed.

Check coolant regularly!




WARNING!

- Never remove the radiator cap while the engine is warm. Wait until the vehicle cools.
- If it is necessary to top up the coolant when the engine is warm, unscrew the expansion tank cap slowly so that the overpressure dissipates.

pg. 151 Maintenance

Oil and fluids (contd)




Brake fluid reservoir

The brake fluid should always be above the MIN mark on the side of the reservoir. Check, without removing the cap, that there is sufficient fluid in the reservoir.

Fluid type : DOT 4+ boiling point $>536^{\circ}\text{F}$ (280°C), P/N 9437433

Replace : Every second year or 30,000 miles (48,000 km). The fluid should be replaced once a year or every 15,000 miles (24,000 km) when driving under extremely hard conditions (mountain driving, etc.)

Always entrust brake fluid changing to an authorized Volvo retailer.



Power steering fluid reservoir

The fluid level should always be between the ADD and FULL marks.


Fluid type : Volvo synthetic power steering fluid (Pincushion CHF 11S) P/N 1161529 or equivalent.

Replace : No fluid change required

NOTE: If a problem should occur in the power steering system or if the vehicle has no electrical current and must be towed, it is still possible to steer the vehicle. However, keep in mind that greater effort will be required to turn the steering wheel.

pg. 152 Maintenance


Wiper blades



Windshield wiper blades

1. Lift the wiper arm off the windshield.
2. Press in the catches (A in the illustration above).
3. Pull out the wiper blade.
4. Insert a new wiper blade and ensure that it is firmly in place.

NOTE: The driver's side wiper blade is longer than the one on the passenger's side.




Tailgate wiper blade

1. Pull the wiper blade out, away from the tailgate window.
2. Pull the wiper blade outward, toward the tailgate.
3. Press the new wiper blade into place. Check that it is properly secured.



[Contents](#) | [Top of Page](#)



Battery Maintenance

The battery in your vehicle is located under the floor of the cargo compartment.

Driving habits and conditions, climate, the number of starts, etc. all affect the service life and function of the battery. In order for your battery to perform satisfactorily, keep the following in mind:

- Check the fluid level in each cell in the battery every 24 months or every 15,000* miles (24,000 km), whichever is sooner. The fluid should be at the level shown in the illustration above (A)**.
- Use a screw driver to open the caps and a flashlight to inspect the level.
- If necessary, add distilled water. The level should never be above the indicator (A**).
- The fluid level should be checked if the battery has been recharged.
- After inspection, be sure the cap over each battery cell is securely in place.
- Check that the battery cables are correctly connected and properly tightened. Route ventilation hose through opening in floor (see [page 151](#))
- Never disconnect the battery when the engine is running, for example when changing the battery.
- The battery should be disconnected from the vehicle when a battery charger is used directly on the battery.
- However, if the battery is being charged via the connecting points in the engine compartment (see [page 103](#)), the battery must be connected.

* More frequently in warm climates.

** The level indicator inside the battery could be designed in various ways. See illustration.



Wear protection goggles



See owner's manual for details



Keep away from children




Corrosive



No smoking, no open flames, no sparks




Explosion




Replacing the battery

1. Switch off the ignition.
2. **Wait at least 5 minutes after switching off the ignition before disconnecting the battery** so that all information in the vehicle's electrical system can be stored in the control modules.
3. Remove the retaining bracket and unscrew the cover over the battery. Wait at least 5 minutes after switching off the ignition before disconnecting the battery so that all information in the vehicle's electrical system can be stored in the control modules.
4. Disconnect the negative (ground) cable first. Disconnect the positive cable and pull the ventilation hose (see next page) from the battery.



5. Lift out the old battery and put a new battery into place.
6. Connect the positive cable first.
7. Connect the negative (ground) cable.
8. Be sure that the ventilation hose (see below) is securely connected to the battery and that the other end of the hose is properly routed through the ventilation opening in the floor of the battery compartment.

9. Reinstall the cover and retaining bracket and screw it securely in place.



Ventilation hose

⚠ WARNING!

- Never expose the battery to open flame or electric spark.
- Do not smoke near the battery.
- Battery fluid contains sulfuric acid. Do not allow battery fluid to contact eyes, skin, fabrics or painted surfaces. If contact occurs, flush the affected area immediately with water. Obtain medical help immediately if eyes are affected.

pg. 155 Maintenance

Battery Maintenance (contd)

⚠ WARNING!

Ventilation hose: The battery generates hydrogen gas, which is flammable and explosive. The battery is fitted with a ventilation hose which vents hydrogen gas out of the battery compartment through a ventilation opening in the bottom of this compartment. If the battery must be replaced, it is essential that the ventilation hose is properly connected to the battery and that it is routed through the ventilation opening provided (see illustration).

Be sure the ventilation hose is free of debris. Only use replacement batteries equipped with a ventilation hose. Consult your Volvo retailer.

NOTE: After the battery has been disconnected or replaced, lock and unlock the vehicle with the central

locking system's remote control to reactivate such features as the power windows, moonroof, courtesy lighting, etc.




WARNING!

PROPOSITION 65 WARNING!

Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the state of California to cause cancer and reproductive harm. Wash hands after handling.

pg. 156 Maintenance

Bulbs



The following bulbs are used in the vehicle:


Bulb	Type	Socket
1. High beam	H7 65W	-
1. Low beam	H11 55W	-
2. Bi-Xenon headlight (option)	D2R 35W	
3. Front fog lights	H1 55W	
4. Front parking lights, front/rear side marker lights, license plate light, rear footwell lighting	W5W	W2,1x9,5d
5. Front turn signals	H21W	BAY9s
5. Rear fog light	P21/4W	BAY9s

6. Side turn signals	WY5W	W2,1x9,5d
7. Brake lights, backup lights	P21W	BAY15d
8. Rear turn signals	PY21W	BA15s
9. Rear parking lights	P21/4W	BAZ15s
10. Vanity mirror lighting	1.2W	SV5.5
11. Front footwell lighting, cargo area lighting	C5W	SV8.5

⚠ WARNING!

Bi-Xenon headlights (option) - due to the high voltage used by these headlights, these bulbs should only be replaced by an authorized Volvo service technician.

pg. 157 Maintenance




Retaining pins

Replacing high/low beams/turn signal/parking light bulbs

The entire lamp housing must be lifted out when replacing these bulbs.


To lift out the lamp housing:

1. Switch off the ignition.
2. Open the hood.
3. Pull up the retaining pins (see the illustration above).
4. Lift out the lamp housing.




CAUTION

- Do not touch the glass on the halogen bulbs with your fingers. Grease, oil, or any other impurities can be carbonized onto the bulb and cause damage to the reflector.
- Be sure to use bulbs of the correct type and voltage.




Location of the bulbs in the headlight housing

1. Low beam headlight/Bi-Xenon headlight (option)
2. High beam headlight
3. Turn signal
4. Parking light
5. Side marker light



Replacing the low beam bulb


1. Remove the plastic cover over the bulb (1) by turning it counterclockwise.
2. Pull the connector from the lamp housing (2).
3. Loosen the bulb's retaining spring by first moving it to the right and then moving it out of the way.
4. Pull out the bulb from the holder.
5. Insert the new bulb (without touching the glass) in the holder.
6. Move the retaining spring up and push it slightly to the left until it seats properly.
7. Press the bulb holder into place on the headlight housing.
8. Reinstall the plastic cap. The letters "HAUT" on the cap must be upward.



Replacing the high beam bulb

1. Remove the rubber cover over the bulb (1) by pulling it off.
2. Pull the connector from the lamp housing (2).
3. Loosen the bulb's retaining spring by first moving it to the right and then moving it out of the way.
4. Pull out the bulb from the holder.

5. Insert the new bulb (without touching the glass) in the holder.
6. Move the retaining spring up and push it slightly to the left until it seats properly.
7. Press the bulb holder into place on the headlight housing.
8. Press the rubber cover into place.




Replacing the parking light/side marker light bulbs

1. Turn the lamp holder approximately 1/4 turn counterclockwise and pull it out of the headlight housing.
2. Pull the bulb straight out.
3. Align the guide lugs on the side of the base of the new bulb in the grooves in the holder and press it into place.
4. Press the lamp holder into the place in the headlight housing and turn it approximately 1/4 turn clockwise.

pg. 159 Maintenance


Bulbs (contd)



390195271

Replacing the turn signal bulb


1. Turn the lamp holder approximately 1/4 turn counterclockwise and pull it out of the headlight housing.
2. Press in the bulb slightly and pull it out of the holder.
3. Align the guide lugs on the side of the base of the new bulb in the grooves in the holder. Press it in and turn it slightly clockwise.
4. Press the lamp holder into the place in the headlight housing and turn it approximately 1/4 turn clockwise.



390195271

Replacing the side turn signal bulb

1. Switch off the ignition.
2. Pry out the lens by inserting a small screw driver under the lower edge.
3. Turn the lamp holder 1/4 turn counterclockwise and pull it straight out.
4. Pull the bulb straight out of the holder.
5. Press the new bulb into the holder.
6. Reinsert the bulb holder in the lens and turn 1/4 turn clockwise.




Front fog lights

Avoid touching the glass on the bulb with your fingers.

1. Switch off the ignition.
2. Turn the bulb holder slightly counterclockwise to release it.
3. Replace the bulb. The shape of the foot of the bulb corresponds to the shape of the bulb holder.
4. Reinstall the bulb holder by turning it slightly clockwise. The side of the holder marked "TOP" should face upward.

pg. 160 Maintenance




Location of tail light bulbs

- A - Turn signal
- B - Brake light

- C - Back-up light
- D - Parking light

Replacing bulbs in the tail light cluster


1. Switch off all lights and turn ignition key to position 0.
2. Fold down the lower section of the tailgate, and fold up the rear section of the cargo area floor.



3. If the vehicle is equipped with the optional grocery bag holder, detach the holder's bands.
4. Remove the corner panel (1 in the illustration above).
5. Open the cover (2) in the side panel by pulling the tab (3) upward/outward.
6. Loosen the bolts (4) with the 10 mm wrench.
7. Pull the entire tail light housing straight out.
8. Disconnect the wiring.
9. Place the tail light housing on a soft cloth to avoid scratching the lens.
10. Turn the lamp holder(s) counterclockwise and pull out.
11. Turn the bulb counterclockwise and remove. Insert a new bulb.
12. Place the lamp holder in the groove and turn clockwise.
13. Press wiring back into place.
14. Align the tail light housing with the holes for the retaining bolts and press it into place.
15. Tighten the retaining bolts.
16. Reinsert the side and corner panels.


NOTE: If the message indicating a burned out bulb remains in the information display after the bulb has been replaced, consult an authorized Volvo retailer or workshop.

Bulbs (contd)



Rear fog light

1. Switch off the ignition.
2. Carefully insert a small screwdriver (see illustration above)
3. Pry out the lamp housing.
4. Turn the bulb holder counterclockwise and pull out the bulb.
5. Insert a new bulb and press the lamp housing back into place.



Door step courtesy lights

The door step courtesy lights are located under the dashboard on the driver's and passenger's sides. To replace a bulb:

1. Carefully insert a screwdriver and pry out the lens.
2. Replace the defective bulb.

3. Reinstall the lens.



Cargo compartment light

1. Carefully insert a screwdriver and pry out the lens.
2. Pry out the bulb and replace it.
3. Press the lens back into place.

pg. 162 Maintenance



Front courtesy lights


These bulbs may be difficult for you to replace yourself. We recommend that you let an authorized Volvo retailer replace these bulbs if necessary.



Rear reading lights

These bulbs may be difficult for you to replace yourself. We recommend that you let an authorized Volvo retailer replace these bulbs if necessary.


NOTE: Other bulbs may be difficult for you to replace yourself. Let an authorized Volvo retailer replace these bulbs if necessary.



Vanity mirror lights

1. Carefully insert a screwdriver and pry out the lens.
2. Pry out the bulb and replace it.
3. Carefully press the lower edge of lens onto the four tabs and press the upper edge of the lens into place.

Bulbs (contd)




License plate lights

1. Switch off the ignition.
2. Loosen the screws with a Torx screwdriver.
3. Turn the bulb holder counterclockwise and pull it out.
4. Pull out the defective bulb and insert a new one.
5. Reinsert the bulb holder into the housing and turn it clockwise.
6. Reinstall the housing and screw it into place.

pg. 164 Maintenance

Fuses



Replacing fuses

If an electrical component fails to function, it is possible that a fuse has blown.

The fuse boxes are located in four different places:

1. Relays/fuse box in the engine compartment
2. Fuse box in the passenger compartment, behind the plastic cover
3. Fuse box in the passenger compartment, on the edge of the dashboard
4. Fuse box in the cargo compartment.

A label on the inside of each cover indicates the amperage and the electrical components that are connected to each fuse.

The easiest way to see if a fuse is blown is to remove it. Pull the fuse straight out. If a fuse is difficult to remove, you will find a special fuse removal tool (and several extra fuses) in the passenger compartment fuse box on the driver's end of the dashboard. From the side, examine the curved metal wire (see next page) to see if it is broken. If so, put in a new fuse of the **same color and amperage** (written on the fuse). Spare fuses are stored in the fuse box in the engine compartment and the passenger compartment. If fuses burn out repeatedly, have the electrical system inspected by an authorized Volvo retailer.





WARNING!

Never use fuses with higher amperage than those stated on the following pages. Doing so could overload the vehicle's electrical system.

pg. 165 Maintenance

Fuses (contd)



A-To open, press the plastic catches on the rear side of the fuse box cover and lift.

Fuse box in the engine compartment


When replacing fuses, be sure to replace a blown fuse with a new one of the same color and amperage (written on the fuse). Fuses in positions marked X are replacement fuses.

Fuses in the engine compartment

No.	Amperage
1. ABS	30A
2. ABS	30A
3. Headlight washers	35A
4. -	
5. Auxiliary lights (option)	20A
6. Starter motor relay	35A
7. Windshield wipers	25A
8. -	
9. Fuel pump	15A
10. Ignition coils, engine control module	20A
11. Throttle pedal sensor, A/C compressor, e-box fan	10A
12. Engine control module, fuel injectors, mass airflow sensor	15A
13. -	
14. Heated oxygen sensor(s)	20A
15. Crankcase ventilation heater, solenoid valves (V8), mass airflow sensor (V8), engine control module (V8)	15A
16. Driver's side low beam headlight	20A
17. Passenger's side low beam headlight	20A
18. -	

- | | |
|--|-----|
| 19. Engine control module feed, engine relay | 5A |
| 20. Parking lights | 15A |
| 21. - | |

pg. 166 Maintenance



Fuses in the passenger compartment


Fuses are located inside the access panel on the edge of the dashboard, on the driver's side. There are also a number of spare fuses. When replacing a blown fuse, be sure to replace it with a new one of the same color and amperage (written on the fuse).

No.	Amperage
1. Blower - climate system	30A
2. Audio amplifier	30A
3. Power driver's seat (option)	25A
4. Power passenger's seat (option)	25A
5. Driver's door - central locking, power windows, door mirror	25A
6. Front passenger's door - central locking, power windows, door mirror	25A
7. -	
8. -	
9. Audio, navigation system (option)	10A
10. On-board diagnostics, headlight switch, steering wheel angle sensor, steering wheel module	5A

11. Ignition switch, SRS, engine control module, immobilizer, transmission control module (V8)	7.5A
12. Ceiling lighting, upper electronic control module	10A
13. Moonroof (option)	15A
14. -	
15. -	
16. -	
17. -	
18. -	
19. -	
20. -	
21. -	
22. -	
23. -	
24. -	
25. -	
26. -	
27. -	
28. -	
29. -	
30. -	
31. -	
32. -	
33. -	
34. -	
35. -	
36. -	
37. -	
38.-	

pg. 167 Maintenance

Fuses (contd)



No.	Amperage
1. Heated passenger's seat	15A
2. Heated driver's seat	15A
3. Horn	15A
4. -	
5. Audio system	10A
6. -	
7. -	
8. Alarm siren	5A
9. Brake light switch feed	5A
10. Instrument panel, climate system, power driver's seat, Occupant Weight Sensor (USA)	10A
11. 12-volt sockets - front and rear seats	15A
12. -	
13. -	
14. -	
15. ABS, STC/DSTC	5A
16. Power steering, Bi-Xenon headlights (option)	10A
17. Driver's side front fog light (option)	7.5A
18. Passenger's side front fog light (option)	7.5A
19. -	
20. Coolant pump (V8)	5A
21. Transmission control module	10A
22. Driver's side high beam	10A
23. Passenger's side high beam	10A
24. -	
25. -	
26. -	
27. -	


28. Power passenger's seat (option)	5A
29. -	
30. -	
31. -	
32. -	
33. Vacuum pump	20A
34. Pump - windshield and tailgate washers	15A
35. -	
36. -	

pg. 168 Maintenance

Fuses (contd)

Fuses in the cargo compartment

The fuses in the cargo area are located behind the panel on the driver's side of the cargo compartment. When replacing a blown fuse, be sure to replace it with a new one of the same color and amperage (written on the fuse).



Fuses in the cargo compartment

No.	Amperage
1. Backup lights	10A
2. Parking lights, foglights, cargo compartment lighting, license plate lights, brake light diodes	20A
3. Accessories	15A
4. -	
5. Rear electronic module	10A
6. Navigation system (option), radio receiver, rear seat entertainment (accessory)	7.5A
7. Trailer wiring (30-feed)	15A
8. 12-volt socket in cargo compartment	15A
9. Rear passenger's side door: power window, power window cutout function	20A
10. Rear driver's side door: power window, power window cutout function	20A
11. -	
12. -	
13. -	
14. Subwoofer (option), rear air conditioning system (option)	15A
15. -	
16. -	
17. Accessory audio	5A
18. -	
19. Rear window wiper	15A
20. Trailer wiring (15-feed)	20A
21. -	
22. -	
23. All Wheel Drive	7.5A
24. -	
25. -	
26. Park assist	5A
27. Main fuse: trailer wiring, park assist, All Wheel Drive	30A
28. Central locking system	15A
29. Driver's side trailer lighting: parking light, turn signal	25A
30. Passenger's side trailer lighting: brake light, fog light, turn signal	25A
31. Main fuse: fuses 37, 38	40A
32. -	

33. -

34. -

pg. 169 Maintenance

Fuses (contd)

35. -

36. -

37. Heated rear window 20A

38. Heated rear window 20A



[Contents](#) | [Top of Page](#)

2 0 0 6 VOLVO XC90

Specifications

pg. 171 Specifications

[Label information](#) [172](#)

[Weights](#) [173](#)

[Dimensions](#) [174](#)

[Fluid capacities](#) [175](#)

[Engine oil](#) [176](#)


[Lubricants](#) [177](#)

[Electrical system](#) [179](#)

[Engine specifications](#) [180](#)

All specifications are subject to change without prior notice.

pg. 172 Specifications



Label information

1. Vehicle Emission Control Information

Your Volvo is designed to meet all applicable emission standards, as evidenced by the certification label on the underside of the hood. For further information regarding these regulations, please consult your Volvo retailer.

2. Vacuum hose routing (underside of hood)

3. Loads and Tire Pressures (on inside of fuel filler door). Canadian models only.

4. Child safety lock label

5. Federal Motor Vehicle Safety

Standards (FMVSS) specifications (USA) and Ministry of Transport (CMVSS) standards (Canada) Your Volvo is designed to meet all applicable safety standards, as evidenced by the certification label on the facing side of the driver's door. For further information regarding these regulations, please consult your Volvo retailer.

6. Loads and Tire Pressures U.S. models only

Certain models will only have one decal, depending on the specifications of the vehicle.

7. Vehicle Identification Number (VIN)¹

The VIN plate is located on the top left surface of the dashboard. The VIN is also stamped on the right hand door pillar.

8. Model plate

Vehicle Identification Number (VIN). Codes for color and upholstery, etc. The plate is located in the engine compartment, on the inside of the left front fender.

1. The Vehicle Identification Number (VIN) should always be quoted in all correspondence concerning your vehicle with the retailer and when ordering parts.

pg. 173 Specifications

Weights

Gross vehicle weight*	USA	Canada
5-seat, 5-cyl, FWD	5640 lbs	-
5-seat, 5-cyl, AWD	5790 lbs	2630 kg
5-seat, 8-cyl, AWD	5900 lbs	2680 kg
7-seat, 5-cyl, FWD	5840 lbs	-
7-seat, 5-cyl, AWD	6005 lbs	2720 kg
7-seat, 8-cyl, AWD	6080 lbs	2760 kg

Capacity weight

5-seat models	1160 lbs	525 kg
7-seat models	1210 lbs	550 kg
Permissible axle weight, front*		
5-seat, 5-cyl, FWD	2710 lbs	-
5-seat, 5-cyl, AWD	2820 lbs	1280 kg
5-seat, 8-cyl, AWD	2910 lbs	1320 kg
7-seat, 5-cyl, FWD	2710 lbs	-
7-seat, 5-cyl, AWD	2820 lbs	1280 kg
7-seat, 8-cyl, AWD	2910 lbs	1320 kg

FWD = Front Wheel Drive

AWD = All Wheel Drive

* Permissible axle weight or gross vehicle weight must never be exceeded.

Permissible axle weight, rear*	USA	Canada
5-seat, 5-cyl, FWD	3060 lbs	-
5-seat, 5-cyl, AWD	3150 lbs	1430 kg
5-seat, 8-cyl, AWD	3150 lbs	1430 kg
7-seat, 5-cyl, FWD	3170 lbs	-
7-seat, 5-cyl, AWD	3240 lbs	1470 kg
7-seat, 8-cyl, AWD	3240 lbs	1470 kg

Curb weight

5-seat, FWD	4355-4390 lbs	-
5-seat, AWD	4490-4670 lbs	2045-2125 kg
7-seat, FWD	4530-4565 lbs	-
7-seat, AWD	4665-4830 lbs	2115-2190 kg

Max. roof load	220 lbs	100 kg
Trailer weight, w/o brakes	1700 lbs	750 kg
Trailer weight, with brakes	See the table on page 104	
Max. tongue weight	See the table on page 104	

pg. 174 Specifications

Dimensions

Dimensions

Length	188.9 in (479.8 cm)
Width	74.7 in (189.8 cm)
Height	70.2 in (178.4 cm)
Wheelbase	112.6 in (285.7 cm)
Front track	64.3 in (163.4 cm)
Rear track	63.9 (162.4 cm)
Turning circle	39-40 ft. (11.9-12.3 m)

Cargo capacity

With optional 3rd row of seats folded down:

5-seat: 41.6 cu ft (1178 litres)

7-seat: 43.3 cu ft (1225 litres)

Behind 1st row of seats, with 2nd (and optional 3rd) row of seats folded down:

5-seat: 84.9 cu ft (2403 litres)

7-seat: 85.1 cu ft (2410 litres)

Behind 1st row of seats, with front passenger seat, 2nd row (and optional 3rd row) of seats folded down:

5-seat: 92.0 cu ft (2606 litres)

7-seat: 93.2 cu ft (2640 litres)

pg. 175 Specifications

Fluid Capacities

Fuel tank 21.1 US gallons (80 liters).
Minimum octane requirement - AKI 87 (RON 91) - unleaded fuel (See also [page 86](#))

Transmission oil

AW55-51 (5-cyl. turbo) 7.6 US qts. (7.2 liters) JWS 3309

TF-80SC (V8) 7.4 US qts. (7.0 liters) JWS 3309

Miscellaneous

Power steering 1.1 US qts. (1.0 liters)

Windshield washer reservoir 6.9 US qts. (6.5 liters)

Brake fluid 0.63 US qts. (0.6 liters)

Air conditioning system Front - 2.2 lb. (1 kg), Rear (option) 2.9 lb. (1.3 kg) R 134a (HFC134a)



WARNING!

When adding accessories, equipment, luggage and other cargo to your vehicle, the total capacity weight must not be exceeded.

pg. 176 Specifications

Engine oil


Specifications

Engine oil must meet the minimum ILSAC specification GF-3, API SL, or ACEA A1/B1. Lower quality oils may not offer the same fuel economy, engine performance, or engine protection.

Volume

Engine designation	Volume between MIN-MAX on dipstick	Volume ^a
2.5T B5254T2	1.3 US qts (1.2 liters)	5.8 US qts. (5.5 liters)
V8 AWD B8444S	1.3 US qts (1.2 liters)	7.1 US qts. (6.7 liters)

a. Including filter replacement



Lubricants

Transmission

Oil grade:

See the table on [page 175](#).

Different types of oil should never be mixed.

Power steering

Grade: Volvo synthetic power steering fluid (Pentosin CHF 11S) P/N 1161529 or equivalent.

Brake fluid

Fluid type: DOT 4+ boiling point >536°F (280°C), P/N 9437433

Cooling system

Type Positive pressure, closed system.

Coolant Volvo original coolant/antifreeze

Volume 5-cyl. turbo 9.5 US qts. (9.0 liters)
V8 10.7 US qts. (10.2 liters)

The thermostat begins to open at 194°F (90°C).

Suspension

Rear suspension

Individual rear wheel suspension with longitudinal support arms, double link arms and track rods.

Front suspension

Spring strut suspension with integrated shock absorbers and control arms linked to the support frame. Power-assisted rack and pinion steering. Safety type steering column.

pg. 178 Specifications

Three-way catalytic converter cautions

- Keep your engine properly tuned. Certain engine malfunctions, particularly involving the electrical, fuel or distributor ignition systems, may cause unusually high three-way catalytic converter temperatures. Do not continue to operate your vehicle if you detect engine misfire, noticeable loss of power or other unusual operating conditions, such as engine overheating or backfiring. A properly tuned engine will help avoid malfunctions that could damage the three-way catalytic converter.
- Do not park your vehicle over combustible materials, such as grass or leaves, which can come into contact with the hot exhaust system and cause such materials to ignite under certain wind and weather conditions.
- Excessive starter cranking (in excess of one minute), or an intermittently firing or flooded engine can cause three-way catalytic converter or exhaust system overheating.
- Remember that tampering or unauthorized modifications to the engine, the Electronic Control Module, or the vehicle may be illegal and can cause three-way catalytic converter or exhaust system overheating. This includes:
 - Altering fuel injection setting or components.
 - Altering emission system components or location or removing components.
 - Repeated use of leaded fuel.

NOTE: Unleaded fuel is required for vehicles with three-way catalytic converters.

pg. 179 Specifications

Electrical system

12-volt system with voltage controlled generator. Single wire system in which the chassis and engine block are used as conductors, grounded on the chassis.

Battery	2.5T	V8
Voltage	12 V	12 V
Cold start capacity (CCA)	600 A	600 A

Reserve capacity (RC)	120 min	120 min
-----------------------	---------	---------

If you must replace your battery, be sure to replace it with a battery of the same cold start capacity and reserve capacity as the original (See the decal on the battery).

Generator max. current	140 A*	170 A
Starter motor, power	1.4 kW	2.0 kW
Spark plugs	P/N272313-8 or equivalent	
Gap	0.028 in.	0.7 mm
Tightening torque	22 ft. lbs.	(30 Nm)

* Models equipped with the optional rear A/C unit have 160 A generators.

pg. 180 Specifications

Engine specifications,

	B5254T2	B8444S
Output (kW/rps)	154/83	232/100
- (hp/rpm)	208/5000	311/6000
Torque (Nm/rps)	320/1500-4500	440/3900
- (ft. lbs./rpm)	236/1500-4500	325/3900
No. of cylinders	5	8
Bore (in./mm)	3.27/83	3.7/94
Stroke (in./mm)	3.67/93.2	3.13/79.5
Cylinder displacement, liters	2.52 (153.8 cu in)	4.41 (268.6 cu. in.)
Compression ratio	9.0:1	10.4:1

Charge air cooler (Intercooler)

Turbocharged engines employ a turbo-compressor to force air into the engine inlet manifold and a charge air cooler to cool the compressed inlet air. The resulting increase in air flow raises pressure in the intake manifold and increases engine power over that developed by the normally-aspirated engine. The charge air cooler (which resembles a radiator) is located between the turbo-compressor and inlet manifold.

Fuel system

The engine is equipped with a multiport fuel injection system.

pg. 181 Specifications

Volvo On Call Roadside Assistance

Your new Volvo comes with a four year ON CALL roadside assistance. Additional information, features, and benefits are described in a separate information package in your glove compartment.

If you have misplaced your package, dial:

In the U.S.A.

1-800-638-6586 (1-800-63-VOLVO)

In Canada:

1-800-263-0475

Technician certification

In addition to Volvo factory training, Volvo supports certification by the National Institute for Automotive Service Excellence (A.S.E.). Certified technicians have demonstrated a high degree of competence in specific areas. Besides passing exams, each technician must also have worked in the field for two or more years before a certificate is issued. These professional technicians are best able to analyze vehicle problems and perform the necessary maintenance procedures to keep your Volvo at peak operating condition.

pg. 182 Specifications

This page intentionally left blank



[Contents](#) | [Top of Page](#)

2006 VOLVO XC90

Audio

pg. 183 Audio

[Audio system](#) [184](#)

[Audio system controls](#) [185](#)

[Audio functions](#) [188](#)

[Radio functions](#) [192](#)

[Menu settings and selections](#) [198](#)

[CD player](#) [199](#)


[CD changer \(option\)](#) [201](#)

[Audio systems - general information](#) [203](#)

[HomeLink® Universal Transceiver](#) [204](#)


pg. 184 Audio

Audio system





1. On/Off
2. Volume
3. CD player
4. AM/FM - for switching between FM1, FM2 and AM
5. Display
6. ENTER - select in the menu or activate a selection
7. MY KEY - programmable key for your favorite function from the menu
8. SELECTOR - select sound source
9. SOUND - make sound settings
10. EXIT/CLEAR - step back in the menu or cancel a selection
11. Menu selections
12. CD eject
13. CD slot, CD changer (option)
14. Storage compartment
15. MY KEY - programmable keys for your favorite functions from the menu
16. Station preset buttons/CD changer discs (1-6)
17. Infrared (IR) port - for the optional audio/navigation system remote control
18. Seek/change tracks or stations


Audio system controls



Steering wheel keypad (option)

The four buttons on the steering wheel keypad can be used to control the audio system. The steering wheel keypad can be used to adjust volume, shift between preset stations and change CD tracks.

- Press the  or  buttons briefly to search for a radio station, or to go to the next/previous track on a CD
- Press and hold down these buttons to search within a track.



Display

The display (1) shows the currently selected function, menu selections, etc. Clean the display with a dry, soft, lint-free cloth. Do not use cleaning agents.

Accessing and using menus

In menu mode, you can change settings and program new functions in the audio system. The various


menu alternatives are shown in the display.

Press the menu button (2) to enter menu mode. Use the menus as follows:

- Use the menu keys (3) to navigate up or down in the menus. Dots in the display indicated that there are more menu selections from which to choose.
- One long press on EXIT/CLEAR exits menu mode.
- A short press on the EXIT/CLEAR enables you to cancel, undo, or answer no to a menu selection, or to go back in the menu structure.
- Pressing ENTER confirms a menu selection, or takes you to the next submenu.

pg. 186 Audio

Audio system controls (contd)



Rear headphone connectors and controls (option)

The door panels behind the second row of seats can be equipped with headphone connectors for passengers in the second and optional third row of seats. Several people can listen to different sound sources, such as CDs or the radio at the same time without disturbing each other.

Two sets of headphones can be plugged into each connector.

- Use the SEL button (1) to step between the sound sources.
- Press the arrow keys (2) briefly to change CD tracks or switch between preset stations.
- Hold down the arrow keys to fast forward/reverse, or search for the previous/next strong radio station.
- Hold down the SEL button to turn off the sound.

For the best sound reproduction, we recommend headphones with impedance between 16-32 ohm. The



sensitivity of these should be equal to or greater than 102 dB. The headphone connections are intended for 3.5 mm contacts and are located under the lower edge of the socket.

All headphones are automatically turned off when the ignition is switched off. They must be manually restarted when the ignition is switched on again.

Headphones - limitations

- The headphones will only work when the ignition key is in position I or higher.
- If a set of headphones is connected to the same source that is being sent through the speakers, the headphone controls cannot be used to change track or station. This is to prevent the driver from being distracted by an unexpected change in music.
- If the driver selects the same sound source as someone listening to this source through headphones, the driver takes control of the sound source.
- Only one disc in the optional CD changer, and one track on the CD can be played at a time.
- Headphone users can choose from among the preset radio stations (AM, FM1, FM2) previously set by the driver.
- If FM is played in the speakers, AM is not available and vice versa.

pg. 187 Audio



Remote control (option)

1. Memory - stores radio stations that have been found by a search

To store a station:

- Press the memory button (1). The preset station number will flash 4 times in the display
- While the preset number is flashing, use the + or - buttons (5) to select a position at which to store the station

- Press button 1 again to store the station


2. Volume
3. Forward/back - fast forward or back
4. Source - step between sound sources
5. Preset/disc - selects among CD's (in the optional CD changer) or preset radio stations
6. Auto store - searches for and stores the strongest radio stations
7. Not in use
8. Not in use
9. Power - off/on

Point the remote control toward the IR port on the radio panel (see the illustration on [page 184](#)).

NOTE: If the remote control does not function properly, check the batteries (AAA or R03).

pg. 188 Audio

Audio functions



On/Off button

To activate the system:

1. Turn the ignition key to position I.
2. Press the POWER button (1) to switch the audio system on or off.

NOTE: If you switch off the ignition while the audio system is on, the system will be on when the

ignition is switched on again.

Volume control

Turn the knob (2) clockwise or counterclockwise to raise or lower the volume. The volume control is electronic and has no end position. Volume can also be raised (+) or lowered (-) using the optional steering wheel keypad.

Pause mode

If the volume is turned off, the CD player will go into pause mode. Re-activate the player by turning up the volume.

Selecting a sound source

A sound source can be selected either with the function buttons (3) - CD, AM/FM, or with the SELECTOR control (4).

To select a sound source:

- Turn the SELECTOR control to choose FM1, FM2, AM, CD, CD changer (option)
- Press the AM/FM button repeatedly to choose between FM1, FM2, AM
- Press the CD button to change to the CD player or optional CD changer

The selected sound source will be shown in the display.

pg. 189 Audio



Sound settings

1. Press the SOUND button (1) repeatedly until you come to the setting that you wish to change. Choose BASS, TREBLE, FADER, BALANCE, SUBWOOFER (option), CENTER (option) or SURROUND

(option).

2. Use the SELECTOR control (2) to adjust the level of the setting you have selected. The display shows a scale from min. to max. position. The center indicates the normal position.

NOTE:

- Sound level for the center speaker can only be set if Dolby Pro Logic II (DPL II) or three-channel stereo (3-CH) is selected in the menu.
- Sound level for the subwoofer can only be set if SUBWOOFER is selected in the menu.
- Volume for the surround sound can only be set if Dolby Pro Logic II (DPL II) is selected in the menu.

Setting

Shown in the display

Bass

BASS

Treble

TREBLE

Balance between the right and left speakers

BALANCE

Balance between the front and rear speakers

FADER

Bass speaker level

SUBWOOFER (option)

Center speaker level

CENTER (Premium Sound system only)

Surround sound level

SURROUND (Premium Sound system only)

pg. 190 Audio

Audio function (contd)




SURROUND MODE

Dolby Surround Pro Logic II (DPL II), 3-channel stereo (3-CH) - option


Dolby Surround Pro Logic II together with a center speaker in the dashboard offers you a sound experience very close to a live performance. The normal left-right stereo channels are divided to left-center-right. In addition, surround sound is produced by the rear speakers. This surround sound mirrors the resonance of a concert hall. Dolby Surround Pro Logic II functions in CD and FM modes. 3-channel stereo is recommended for AM radio broadcasts.

- Surround settings for FM and CD are stored separately.
- When listening to FM radio stations, Dolby Surround Pro Logic II functions best in areas with strong reception. If reception is weak, selecting 2 or 3- channel stereo may provide better sound quality.
- Dolby Surround Pro Logic II is only available on the highest level audio system - Premium Sound.

Use the following instructions to select PRO LOGIC II, 3-CHANNEL, or to turn these functions off. See also the menu structure on [page 198](#).

1. Select AUDIO SETTINGS in the menu and press ENTER.
 2. Select SURROUND and press ENTER.
 3. Select Dolby AM/FM, or Dolby CD and press ENTER.
 4. Select PRO LOGIC II, 3-CHANNEL, or OFF and press ENTER.
- The symbol  PL II is displayed when Pro Logic II is selected.
 - 3-CH is shown when 3-channel stereo is selected.
 - OFF indicates normal stereo mode.

Dolby noise reduction is manufactured under license from Dolby Laboratories Licensing Corporation.

"Dolby Surround Pro Logic II", and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation. Dolby Surround Pro Logic II is manufactured under licence from Dolby Laboratories Licensing Corporation.



Bass speaker - SUBWOOFER (option)

The subwoofer helps the system provide fuller sound and deeper bass.

1. Select AUDIO SETTINGS in the menu and press ENTER.
2. Select SUBWOOFER and press ENTER. See [page 189](#) for information on setting the subwoofer level.

Equalizer FR

EQ - FRONT(certain audio systems)

This function is used to fine-tune the sound from the front speakers.

1. Select AUDIO SETTINGS in the menu and press ENTER.
2. Select Equalizer FR and press ENTER.
3. Use the menu selection buttons to set the level or use the SELECTOR control.
4. Press ENTER to select the next frequency. You can select five frequencies.
5. Press ENTER until you come to the menu mode to save the changes you have made.


Equalizer RR

EQ - REAR (certain audio systems)



This function is used to fine-tune the sound from the rear speakers.

1. Select AUDIO SETTINGS in the menu and press ENTER.
2. Select EQ- REAR and press ENTER.
3. Use the menu selection buttons to set the level or use the SELECTOR control.
4. Press ENTER to select the next frequency. You can select five frequencies.
5. Press ENTER until you come to the menu mode to save the changes you have made.





Radio functions



Station search

1. Choose radio mode AM/FM1/FM2 using the SELECTOR control (1) or the AM/FM button (2).
2. Press briefly on  or  to search for the next strong station. The radio will search for the next audible station and then stop.
3. Press one of the buttons again to start a new search.

Manually search for a known frequency

1. Press and hold the  or  button (or the corresponding buttons on the steering wheel keypad). MAN will be shown in the display. The radio will slowly scroll in the desired direction and then increase speed after a few seconds.
2. Release the button when the desired frequency is displayed.
3. If you need to adjust the frequency, press briefly on  or .
4. The manual search function is available for five seconds after you last pressed the button.



Storing stations

To store a selected station under one of the station setting buttons 0-9 (1):

1. Set the desired station.
2. Press the button under which the station is to be stored and keep it depressed. The sound will be interrupted for several seconds and **STATION STORED** is shown in the display. The station is now stored.

You can store up to 10 stations each for AM, FM1 and FM2, i.e. a total of 30 stations.

Radio Frequency band

FM 87.7 - 107.9 MHz

AM 530 - 1710 kHz

MY KEY - programming a shortcut

Use the MY KEY buttons (2, 3) to program a favorite function from the menu, such as SCAN, AUTOSTORE, etc. See [page 198](#) for the functions that can be programmed with the MY KEY button.

1. Use the MENU buttons to scroll among the functions.
2. Select the desired function from the menu by holding one of the MY KEY buttons depressed for more than two seconds.
3. When **MY KEY STORED** is shown in the display, the function has been stored.
4. Activate the function by briefly pressing the MY KEY button with which the functions was stored.

Repeat steps 1-4 to store new functions on the MY KEY buttons.

NOTE: The MY KEY buttons can only be programmed for one shortcut function at a time.

pg. 194 Audio


Radio functions (contd)



Automatically storing stations - AUTOSTORE

This function automatically searches for, and stores up to 10 strong AM or FM stations in a separate memory. If more than 10 stations are found, the 10 strongest ones will be stored. The function is especially useful in areas in which you are not acquainted with radio stations or their frequencies.

1. Choose radio mode using the SELECTOR control or the AM/FM button.
2. Select AUTOSTORE in the menu and press ENTER.
3. Select AST SEARCH and press ENTER.
4. AUTOSTORING is shown in the display and a number of strong stations (max. 10) from the set frequency band are now automatically stored in the autostore memory. If there are no stations with sufficient signal strength, NO AST FOUND is displayed.
5. The stored stations are available under the buttons 0-9 (1).
6. When the radio is in autostore mode, AUTO is shown in the display. AUTO disappears when you return to the normal radio mode.
7. Return to normal radio mode by pressing the AM/FM button or EXIT/CLEAR.
8. To access previously stored stations, carry out steps 1-2 but select AST MODE in step 3 and press ENTER.



Radio Broadcast Data System (RBDS)

This feature, which may not be available in your area, functions only with FM broadcasts.

The radio in your car is equipped with an advanced system allowing information from broadcasters to be transmitted visually, as text, together with the audio signal. This information is then decoded by the radio and made **available for several new and unique features. The RBDS or Radio Broadcast Data System operates in the FM band only, and the information transmitted is supplied exclusively by participating broadcasters.** Volvo has no control over the accuracy of the data or information.

Coverage by local broadcasters may be limited at this time, but as the technology and benefits grow, you will find the radio in your car is equipped to take advantage of this system.

NOTE: PI (Program Information) Seek: When an FM station has been stored as a preset, the radio also stores RBDS program information if it is available. When the preset is selected at a later time, the radio tries to access updated program information. In weak signal areas, there may be a delay before the station becomes audible. During this delay, there will be no sound and the text "PI seek. Press EXIT to cancel." will be displayed. You may press EXIT to immediately tune in the station without RBDS program information.

Scanning - SCAN

This function automatically searches for the next strongest AM and FM stations. When the radio finds a station, it will pause for approximately 8 seconds, after which it will continue scanning.

1. Choose radio mode using the SELECTOR control (1) or the AM/FM button (2).

2. Select SCAN to start searching and press ENTER.
3. SCAN will be shown in the display.
4. Press the EXIT/CLEAR button to stop scanning.

pg. 196 Audio

Radio functions (contd)



Program type/Format - PTY

The PTY function allows you to find programs that suit your taste. Use the PTY function to select from among the different program types shown in the list.

Which PTY does the set station have?

1. Select RADIO SETTINGS in the menu and press ENTER.
2. Select PTY in the menu and press ENTER.
3. Select SHOW PTY TEXT and press ENTER. The PTY of the selected station is now shown in the display.

NOTE: Not all radio stations have PTY designations.

Program type	Text displayed
Switch off/ deactivate	CLEAR ALL PTY
News	NEWS
Information	INFORMATION
Sports	SPORT

Talk	TALK
Rock	ROCK
Classic rock	CLASSIC ROCK
Adult hits	ADULT HITS
Soft rock	SOFT ROCK
Top 40	TOP 40
Country	COUNTRY
Oldies	OLDIES
Soft	SOFT
Nostalgia	NOSTALGIA
Jazz	JAZZ
Classical	CLASSICAL
Rhythm & Blues	RHYTHM & BLUES
Soft R&B	SOFT R&B
Language	LANGUAGE
Religious music	RELIGIOUS MUSIC
Religious talk	RELIGION TALK
Personality	PERSONALITY
Public	PUBLIC
College	COLLEGE
Weather	WEATHER

Radio text

Certain stations broadcast program information, which can be shown in the display.



1. Press the MENU button.
2. Select RADIOTEXT in the menu and press ENTER.
3. Select RADIOTEXT again to deactivate.

pg. 197 Audio



Search for a specific program type - PTY

This function enables you to search for a certain type of program by searching through the entire waveband.

1. Select FM1 or FM2 and press the MENU button.
2. Select RADIO SETTINGS and press ENTER.
3. Select PTY and press ENTER.
4. Choose SELECT PTY and press ENTER.
5. Press ENTER for one or more of the listed program types to select. The PTY symbol is displayed and lights up when you make your first selection and the radio goes into PTY mode.
6. When you have made all of your selections, press EXIT/CLEAR to exit the PTY list.
7. Select SEARCH PTY and press ENTER. If the radio finds a station with the selected program type, this station will be played.
8. If the radio finds a station that does not match your selections, continue the search with the  and  buttons.
9. If no station with the selected program type is found, the radio will return to the previously tuned frequency. PTY will remain in standby mode.
10. To deactivate the PTY standby mode, select CLEAR ALL PTY and press ENTER. The PTY symbol then disappears and the radio returns to the normal operating mode.

PTY standby

To set the radio in PTY standby, repeat steps 1-6.



[Contents](#) | [Top of Page](#)

Menu settings and selections

Main menus/submenus

RADIO

1. AUTOSTORE*
 - 1.1. AST MODE
 - 1.2. AST SEARCH
 - 1.2.1 AUTOSTORING
2. SCAN* ON/OFF**
3. RADIOTEXT* ON/OFF**
4. RADIO SETTINGS
 - 4.1. PTY
 - 4.1.1. SELECT PTY
 - 4.1.2. SEARCH PTY*
 - 4.1.3. SHOWPTY ON/OFF**
 - 4.2. AF* ON**/OFF
 - 4.3. RESET ALL
5. AUDIO SETTINGS
 - 5.1. Dolby FM
 - 5.1.1. Pro Logic II
 - 5.1.2. 3CH
 - 5.1.3. OFF**
 - 5.2. Dolby CD
 - 5.2.1. Pro Logic II**
 - 5.2.2. 3CH
 - 5.2.3. OFF
 - 5.3. SUBWOOFER* ON/OFF** (certain audio systems)
 - 5.4. EQ FRONT (certain audio systems)
 - 5.5. EQ REAR (option)
 - 5.6. RESET ALL

CD (single disc)

1. RANDOM*
2. SCAN*
3. AUDIO SETTINGS*
 - 3.1. Dolby FM
 - 3.1.1. Pro Logic II
 - 3.1.2. 3CH
 - 3.1.3. OFF**

3.2. Dolby CD

3.2.1. Pro Logic II**

3.2.2. 3 CH

3.2.3. OFF ON/**OFF

3.3. SUBWOOFER* ON/OFF** (option)

3.4. EQ FRONT (certain audio systems)

3.5. EQ REAR (certain audio systems)

3.6. RESET ALL

CDX (CD changer - option)

1. RANDOM*

1.1. OFF

1.2. SINGLE DISC

1.3. ALL DISCS

2. SCAN*

3. DISC TEXT

4. AUDIO SETTINGS*

4.1. Dolby FM

4.1.1. Pro Logic II

4.1.2. 3CH

4.1.3. OFF**

4.2. Dolby CD

4.2.1. Pro Logic II**

4.2.2. 3 CH

4.2.3. OFF ON/**OFF

4.3. SUBWOOFER* ON**/OFF (option)

4.4. EQ FRONT (certain audio systems)

4.5. EQ REAR (certain audio systems)


4.6. RESET ALL

* These functions can be programmed with MY KEY (see [page 193](#)).

** Default

pg. 199 Audio

CD player





Starting the CD

1. Select the CD mode using the SELECTOR control (1) or the CD button (2).
2. Insert a CD into the player.



CD Pause

To pause CD playback, turn the volume all the way down. "CD paused" will be displayed. This will not occur if someone in the rear seat is listening to the CD through the optional headphones. Play will resume when the volume is turned up again.

Changing tracks

Press  to go to the next track or  to go to the previous track. The track number is shown in the display. If you have a keypad in the steering wheel, you can use the arrow keys in the same way.

Searching within a track


Press and hold down  or  to search within a track or the whole disc. The search continues as long as the buttons are depressed. If you have a keypad in the steering wheel, you can use the arrow keys in the same way.

Random play

This function plays the tracks on a CD in random order (shuffle).

1. Press the MENU button.
2. Select RANDOM and press ENTER.
3. RND is shown in the display as long as the function is activated.
4. Go into the menu and select RANDOM OFF to stop random play, or press EXIT.

CD player (contd)



SCAN This function plays the first ten seconds of each track.

1. Press the MENU button.
2. Select SCAN and press ENTER.
3. Press EXIT/CLEAR to listen to an entire track.

Disctext

Certain CDs contain information about the disc, such as the titles of the tracks, etc. This information can be shown in the display by activating the DISCTEXT function.

1. Press the MENU button.
2. Select DISCTEXT in the menu and press ENTER.
3. Any information that may be stored on the disc will be displayed.
4. To deactivate this function, select DISCTEXT and press ENTER.

NOTE: This function is only available on the CD changer.

CD eject

Press button 1 to eject the CD.

NOTE: For reasons of traffic safety, the ejected CD must be removed within 12 seconds or it will be automatically drawn back into the slot and the CD player will enter pause mode. Press the CD button to

restart the disc.

pg. 201 Audio

CD changer (option)



CD changer (option)

The CD changer can hold up to six discs.

1. Choose CD mode using the SELECTOR control or the CD button.
2. Select an empty slot with the number keys 1-6 (1). The display indicates which slots are empty.
3. Insert a disc into the changer.

To insert a new disc, you must first select an available empty slot in the CD changer. Make sure **INSERT DISC** is displayed before inserting a new disc.

Selecting disc number

Use the station setting buttons 1-6 (1) to select which disc is to be played. The number of the disc and the track are shown in the display.



SCAN

This function plays the first ten seconds of each track and only functions on the currently selected disc.



1. Press the MENU button.
2. Select SCAN and press ENTER.

Press EXIT/CLEAR to listen to an entire track.

Changing tracks

Press  to go to the next track or  to go to the previous track. The track number is shown in the display. If you have a keypad in the steering wheel, you can use the arrow keys in the same way.

Searching within a track

Press and hold down  or  to search within a track or the whole disc. The search continues as long as the buttons are depressed. If you have a keypad in the steering wheel, you can use the arrow keys in the same way.

pg. 202 Audio

CD changer (option) (contd)



Random play

This function offers two alternatives for playing the tracks on the disc(s) in the CD changer in random order (shuffle).


- Random one (random order on the currently selected disc)
- Random all (random order on all of the CD's in the changer)

To play tracks in random order:

1. Press the MENU button.
2. Select RANDOM and press ENTER.
3. Select SINGLE DISCS or ALL DISCS to play tracks randomly from one or all of the discs in the CD

changer.

4. RND or RND ALL is shown in the display for as long as the function is activated.

NOTE: Press  to play the next randomly selected track. This can only be done on the currently selected disc.

5. Press EXIT to stop random play.

Ejecting one disc

A **short press** on the EJECT button (1) will eject the CD that is currently playing.

NOTE: For reasons of traffic safety, you have 12 seconds in which to remove the ejected disc. After that, the disc automatically reinserts into the player.

Ejecting all discs

A **long press** on the EJECT button (1) starts the EJECT ALL function.

The text EJECTING ALL will be displayed and the entire magazine will be emptied disc by disc.

NOTE:

- The EJECT ALL function can only be used while the vehicle is at a standstill and will be cancelled if the vehicle begins to move.
- For reasons of traffic safety, you have 12 seconds in which to remove the ejected disc. After that, the disc automatically reinserts into the player.

pg. 203 Audio

Audio systems - general information

Compact disc care


- Before using a new CD for the first time, remove any burrs in the center/outer edge by running the stem of a pen or similar object around the hole/edge of the disc.
- Use CD standard EN 60908 discs only. Discs not meeting this standard may cause problems with system (poor sound). CDR discs can cause listening problems due to the quality of the disc or recording equipment used.
- Keep the discs clean. Wipe them with a soft, clean, lint-free cloth, working from the center outwards. If necessary, dampen the cloth with a neutral soap solution. Dry thoroughly before using.
- Never use cleaning spray or antistatic liquid. Use only cleaners specifically made for CD's.
- Use discs of the correct size only (3.5" discs should never be used).
- Do not put tape or labels on the disc itself. They could become stuck in the player.
- Volvo does not recommend the use of plastic outer rings on the disc.
- Condensation may occur on discs/optical components of the changer in cold winter weather. The disc

can be dried with a clean, lint-free cloth. Optical components in the CD changer may, however, take up to one hour to dry off.

- Never attempt to play a disc which is damaged in any way.
- When not in use, the discs should be stored in their covers. Avoid storing discs in excessive heat, direct sunlight or dusty locations.

pg. 204 Audio

HomeLink® Universal Transceiver



Hand-held transmitter

HomeLink® Universal Transceiver

HomeLink® is an advanced system that can be programmed to learn the codes of three different remote controlled-devices (e.g., garage door openers, remote lighting, entry door lock). HomeLink®'s sun visor-mounted transceiver, powered by your vehicle's electrical system, may then be used in place of your hand-held remote controls.

NOTE: For your security, the HomeLink® Universal Transceiver is designed to not function if you lock your vehicle from the outside.

Programming the transceiver

1. The ignition switch must be turned to the "accessory" position (II) before programming the HomeLink® Universal Transceiver.

2. Begin by erasing all 3 factory default channels. Hold down the two outside buttons (buttons 1 and 3 in the illustration) on the HomeLink® Universal Transceiver for about 20 seconds, until HomeLink®'s indicator light begins to flash. Then release the buttons.

3. Hold your hand-held transmitter (garage door opener, for example) 2 to 5 in. (5 to 12 cm) away from the HomeLink® surface, keeping the indicator light in view. For placement questions, contact HomeLink® toll-free 1-800-355-3515 (Internet: www.HomeLink.com).
4. Using two hands, push and hold both your hand-held transmitter's button and the transceiver button you wish to program. The indicator light will flash first slowly, then rapidly. Rapid flashing tells you the HomeLink® button has been successfully programmed. Release both buttons.
5. If you are programming a rolling code-equipped device (e.g., garage door opener or entry door lock), refer to "Programming rolling codes" on the next page to complete the programming process.

Repeat steps 3 and 4 to program the other two transceiver buttons.

If, after several attempts, you are unable to successfully train the HomeLink® Universal Transceiver to learn your hand-held transmitter's signal, contact HomeLink® toll-free 1-800-355-3515 (Internet: www.HomeLink.com).

pg. 205 Audio



WARNING!

- If you use HomeLink® to open a garage door or gate, be sure no one is near the gate or door while it is in motion.
- Do not use the HomeLink® Universal Transceiver with any garage door opener that lacks safety "stop" and "reverse" features as required by federal safety standards. (This includes any garage door opener model manufactured before April 1, 1982). A garage door opener that cannot "detect" an object, signalling the door to "stop" and "reverse" does not meet current federal safety standards. Using a garage door opener without these features increases the risk of serious injury or death. For more information on this matter, call toll-free 1-800-355-3515 (Internet: www.HomeLink.com).

NOTE: Canadian residents:

During programming, your hand-held transmitter may automatically stop transmitting. To successfully train HomeLink®, continue to hold the HomeLink® button. At the same time, repeatedly press and hold your hand-held transmitter's button at two-second intervals until HomeLink® has learned your transmitter's code. The HomeLink® indicator light will flash first slowly, and then rapidly to indicate that the button has been successfully programmed.

Determining if your garage door uses a rolling code

Determine, in one of the following ways, if your garage door uses a rolling code system and is

manufactured after 1996:

- Refer to the garage door opener owner's manual for verification.
- If your hand-held transmitter appears to program the HomeLink® Universal Transceiver but the programmed button does not activate the garage door, your garage door opener may have a rolling code.
- Press the programmed HomeLink® button. If the garage door opener has the rolling code feature, the HomeLink® indicator light flashes rapidly and then glows steadily after approximately 2 seconds.

To train a rolling code garage door opener,

follow these instructions after programming the desired transceiver button according to "Programming the transceiver." The help of a second person may make training easier.

1. Locate the training button on the garage door opener motor head unit. The location and color of the training button may vary. If you encounter difficulty, refer to the garage door opener owner's manual or call toll-free 1-800-355-3515 (Internet: www.HomeLink.com).
2. Press the "training" button on the garage door opener motor head unit until the "training" light comes on.
3. Press and release the programmed HomeLink® button. Press and release the programmed HomeLink® button a second time to complete the training process.
4. Some garage door openers may require you to do this procedure a third time to complete the training.
5. The programmed button on your HomeLink® Universal Transceiver should now operate your garage door opener. The original hand-held transmitter can also be used, as desired, to operate the garage door. The remaining two HomeLink® buttons can be programmed in the same way. In the event of any problems in programming the HomeLink® Universal Transceiver, call toll-free 1-800-355-3515 (Internet: www.HomeLink.com).

Operating the HomeLink® Universal Transceiver

Once programmed, the HomeLink® Universal Transceiver can be used in place of your handheld transmitters.

To operate, the key must be turned to the "accessory" position (II) or the engine must be running. Press the programmed HomeLink® button to activate the garage door, driveway gate, security lighting, home security system, etc.

pg. 206 Audio

Your original hand-held transmitters may, of course, be used at any time.

Erasing programmed buttons

Individual buttons cannot be erased. To erase all three programmed buttons:

1. Turn the ignition key to the "accessory" position (II).
2. Hold down the two outside buttons on the HomeLink® Universal Transceiver for about 20 seconds,

until HomeLink®'s indicator light begins to flash.

3. Release both buttons.

The HomeLink® buttons can be reprogrammed using the procedures described on the previous page.

Reprogramming a single HomeLink® button

1. Press and hold the desired HomeLink® button. Do not release the button until step 3 has been completed.
2. When the indicator light begins to flash slowly (after approximately 20 seconds), position your hand-held transmitter 2 to 5 in. (5 to 12 cm) away from the HomeLink® surface.
3. Press and hold the hand-held transmitter button. The HomeLink® indicator light will flash first slowly, then rapidly. When the indicator light flashes rapidly, release both buttons.

The previously programmed device has now been erased and the new device can be activated by pressing the HomeLink® button that has just been programmed. This procedure will not affect any other programmed HomeLink® buttons.

NOTE:

- Retain the original transmitter(s) for future programming procedures (e.g., if you purchase a new vehicle).
- For your own security, erase all programmed buttons on the HomeLink® Universal Transceiver when you sell your vehicle.
- Metallic sun protection films should not be used on any windows in a vehicle equipped with HomeLink® Universal Transceiver. This could interfere with the transceiver's function.



[Contents](#) | [Top of Page](#)

2 0 0 6 VOLVO XC90

Index

pg. 207-211 Index

</t

A

A/C (air conditioning) [55](#)

ABS [ii](#), [23](#), [97](#)

Air cleaner [147](#)

Air distribution [52](#), [55](#)

Air Quality sensor [56](#)

Air vents [52](#)

Alarm [82](#)

All Wheel Drive [95](#)

All Wheel Drive - towing [102](#)

Anchorage, for child seats [20](#)

Anti-lock Brake System (ABS) [ii](#), [23](#)

Approach lighting [77](#)

Ashtray [40](#), [68](#)

Audio system [183](#)

AUTO (climate control) [54](#)

Automatic climate control, ECC [53](#)

Automatic gearbox [91](#)

Autostart [90](#)

Auxiliary 12-volt sockets [40](#)

Auxiliary lights [27](#)

Average speed [37](#)

AWD [95](#)

B

Bass [189](#)

Battery [145](#), [152](#), [179](#)

Battery - replacing [154](#)

Battery drain - avoiding [92](#)

Battery maintenance [153](#)

Belt check [146](#)

Black box (Vehicle Event Data) [142](#)

Blower (fan) [54](#)

Booster cushion, integrated [18](#)

Brake system [24](#), [96](#)

Bulbs, list of [156](#)

Bulbs, replacing [157](#)

C

Capacities [175](#)

Capacity weight [121](#)

Carbon Monoxide - Important Warning [87](#)

Cargo capacity [174](#)

Catalytic converter [178](#)

CD changer [201](#)

CD eject [200](#)

CD Pause [199](#)

CD player [199](#)

Ceiling lighting [162](#)

Center console - storage compartments [68](#)

Central locking system - remote control [77](#)

Changing a wheel [128](#)

Changing coolant [146](#)

Check Engine warning light [25](#)

Child booster cushion [18](#)

Child restraint anchorages [20](#)

Child safety locks [81](#)

Child seat anchors [20](#)

Cleaning the upholstery [138](#)

Climate control systems - general information [50](#)

Clock [22](#)

Coat hanger [70](#)

Coin compartment [68](#)

Cold tires, definition [114](#)

Cold weather precautions [108](#)

Coolant - changing [146](#), [150](#)

Coolant - checking level of [146](#)

Cooling system [177](#)

Courtesy light [65](#)

Cruise control [38](#)

Cup holder [68](#), [69](#)

Cup holder in rear seat [68](#)

Curb weight [121](#)

Current fuel consumption [37](#)

D

Defroster [54](#)

Dimensions [174](#)

Dolby Pro Logic II (DPL II) [189](#)

Door mirror defroster [36](#)

Driving economically [91](#)

DSTC [27](#), [98](#)

E

ECC [53](#)

Economical driving [91](#)

Electric socket [27](#)

Electrical current - conserving [92](#)

Electrical sockets, 12-volt [40](#)

Electrical system [179](#)

Electronic Brake Force Distribution [97](#)

Emergency Brake Assistance [97](#)

Emission inspection readiness [144](#)

Engine - starting [89](#)

Engine compartment [147](#)

Engine oil, changing [149](#)

Engine oil, specifications [148](#), [176](#)

Engine oil, volume [176](#)

Engine specifications [180](#)

Environment [iii](#)

F

Fader [189](#)

Federal Clean Air Act [142](#)

FIX NEXT SERVICE [26](#)

Flat tire, changing [125](#)

Flat tire, tire sealing system [130](#)

Floor mats [66](#)

Fog light symbol (rear) [25](#)

Folding sideview mirrors [27](#)

Front park assist [100](#)

Front seat, folding backrest [59](#)

Front seats [58](#)

Front seats - heated [36](#)

Front seats - manual adjustment [58](#)

Front seats - power [60](#)

Front suspension [177](#)

Fuel [ii](#), [86](#)

Fuel filler cap [ii](#), [88](#)

Fuel filler door [ii](#), [88](#)

Fuel filler door - unlocking manually [30](#)

Fuel Formulations [87](#)

Fuel gauge [22](#)

Fuel tank, capacity [175](#)

Fuses [164](#)

G

Gasoline [86](#)

Geartronic [93](#)

Geartronic - manual shifting [94](#)

General information [ii](#)

Generator warning light [25](#)

Glove compartment [69](#)

H

Handling [92](#)

Hazard warning flashers [36](#)

Headlight washer [34](#)

Headphones [186](#)

Heated front seats [36](#), [55](#)

High beam indicator [22](#)

High/low beam headlights [32](#)

High/low beams - replacing [157](#)

Hoisting the car [145](#)

HomeLink® Universal Transceiver [204](#)

Hood - opening [41](#)

I

Immobilizer (start inhibitor) [76](#)

Indicator and warning symbols [22](#), [23](#)

Inflatable Curtain [13](#)