

Sunbeam

Sunbeam

Washable Personal Groomer

Instruction Booklet
MG4200

Please read these instructions carefully
and retain for future reference.



Sunbeam's Safety Precautions

SAFETY PRECAUTIONS FOR YOUR WASHABLE PERSONAL GROOMER.


- Keep out of the reach of children.
- Do not use the appliance if the rotating cutting blade is damaged.
- The appliance must only be used as described in this booklet.
- Do not insert the appliance further than 6mm into the ear or nose.
- This appliance is for household use only.
- Do not immerse the unit in water or any other liquid.
- Switch the appliance on before inserting into the ear or nose.
- If the appliance is not to be used for long periods, remove the battery before storing.
- Once the battery is dead, remove immediately and replace.

Sunbeam are very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:


- Read carefully and save all the instructions provided with an appliance.
- Close supervision is necessary when your appliance is being used near children or infirm persons.
- Never leave an appliance unattended while in use.
- Young children should be supervised to ensure that they do not play with the appliance.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven.
- Do not place on top of any other appliance.
- For safety reasons and to avoid maintenance by unskilled persons, some appliances are 'sealed' using tamperproof screws. Such appliances should always be returned to the nearest Sunbeam Appointed Service Centre for adjustment or repair if required.
- Do not immerse the appliance in water or any other liquid unless recommended.

If you have any concerns regarding the performance and use of your appliance, please visit www.sunbeam.com.au or contact the Sunbeam Consumer Service Line. Ensure the above safety precautions are understood.

Features of your Washable Personal G



roomer



Protective cap

Using your Washable Personal Groomer

Inserting the Battery

- Open the battery compartment by turning it anticlockwise and pulling it off.
- Insert one AA Alkaline battery.
- The label in the battery compartment clearly shows the direction to insert the battery.
- Replace the battery compartment and turn clockwise to lock back into position.

Using your Washable Personal Groomer.

- Remove the protective cap and switch the appliance on.
- Insert the appliance into the ear or nose but no more than 6mm.
- Rotate in a circular movement.
- The appliance can also be used to trim stray eyebrow hairs. Move the appliance slowly and carefully keeping the unit away from the eye socket.

Care and cleaning

- Do not immerse the appliance in water or any other liquid.
- The appliance can be wiped with a cloth dampened in water and a mild detergent. Rinse and dry thoroughly. The blade can be washed under a running tap. To do this, turn the blade holder anti-clockwise to remove from the unit. Ensure that the blade and casing are dry before reattaching.
- Do not rinse the entire unit in running water – only the blade section.
- Click the blade holder back into place by turning clockwise.
- Store in a cool, dry place.

Help line

If you have any additional questions about using the Washable Personal Groomer, please call the Sunbeam help line in Australia on 1800 025 059. In New Zealand, please call 09 912 0747.

'Sunbeam', is a registered trademark of Sunbeam Corporation. Made in China. Due to minor changes in design or otherwise, the product may differ from the one shown in this leaflet. Backed by Sunbeam's 2 Year Replacement Guarantee and National Service Network.

© Copyright. SUNBEAM CORPORATION LIMITED 2003.

(INCORPORATED IN N.S.W.) A.C.N. 000 006 771

Sunbeam Corporation is a division of GUD Holdings Ltd.

For more information or advice on this or any other Sunbeam appliance, visit www.sunbeam.com.au or contact the Sunbeam Consumer Service Line.

Australia 1800 025 059

New Zealand (09) 912 0747.

Service Centre Listing Australia and New Zealand

We recommend that you contact your nearest Service Centre before posting or forwarding an appliance.
When requesting replacement parts always quote the model number of your appliance.

NEW SOUTH WALES/ACT

ALBURY	Mid State Small Appliance Service 435 Dean Street NSW 2640 Ph: 02 6021 7410 Fax: 02 604 12349 Contact: Les Mather
ARMIDALE	Spark & Co. 210 Barney Street NSW 2350 Ph: 02 6772 9112 Fax: 02 6772 5411 Contact: Lyn Moore
ASHFIELD	Ashfield Appliances 126 Parramatta Road NSW 2131 Ph: 02 9798 5590 9798 6133 Fax: 02 9716 6393 Contact: Michael Wroblewski
BANKSTOWN	Adams Appliances 11 Apian Way NSW 2200 Ph: 02 9791 6655 Fax: 02 9791 6655 Contact: Anne & Adam
BATHURST	Serv U Appliance Centre Pty Ltd Unit 1/94a Bentnick St NSW 2795 Ph: 02 6331 1356 Fax: 02 6331 2102 Contact: Grahame Kilby
BEGA	Sapphire Electronics Unit 3B 85 Bega St NSW 2550 Ph: 02 6492 2522 Fax: 02 6492 2522 Contact: Larry Lockerbie
BONDI JUNCTION	BJ Appliance Repairs 240 Oxford Street NSW 2025 Ph: 02 9389 7396/7897 Fax: 02 9369 1796 Contact: Suzanne or John
BROKEN HILL	Visual Audio 510 Chapel Street NSW 2880 Ph: 08 8087 4055 Fax: 08 8087 4055 Contact: Lorna Trappel
CAMPBELLTOWN	Viking Appliance Centre 5/9 Mill Rd NSW 2560 Ph: 02 4625 3540 Fax: 02 4625 3540 Contact: Glenn Small
CANBERRA	United Electronics 66 Maryborough Street Fyshwick ACT 2609 Ph: 02 6239 1622 Fax: 02 6239 1624
CARLTON	Parker Electrical 49-51 Andover Street Carlton NSW 2218 Ph: 02 9588 5044 Fax: 02 987 9805 Contact: John Parker
CHARLESTOWN	Charlestown TV & Video Service Shop 2 163 Pacific Hwy NSW 2290 Ph: 02 4943 7756 Fax: 02 4943 7511 Contact: Graeme Motum
COFFS HARBOUR	Beatons Home Appliances 1b GBT Seccombe Close Off Orlando Street NSW 2450 Contact: Jill Beaton Ph: 02 6651 2551 Fax: 02 6652 8587

DUBBO	Mid State Washer Service 5 Hopkins Pd NSW 2830 Ph: 02 6882 4821 Fax: 02 6884 2245 Contact: David Payne
GLADESVILLE	Able Repairs 1 Massey Street NSW 2111 Ph: 02 9879 6433 Fax: 02 9879 6146 Contact: Kerri Hay
GOSFORD	Gerry's Electrical Appliance 225 Albany St NSW 2250 Ph: 02 4324 1499 Fax: 02 4324 7407 Contact: Edgar Griesberg
GRAFTON	Big River Appliance Repairs 53 Armidale St NSW 2460 Ph: 02 6643 2722 Fax: 02 6642 5150 Contact: Michael Tattis
GRIFFITH	Luke's Appliance Service Level 1/ 144 Banna Ave NSW 2800 Ph: 02 6962 7611 Fax: 02 6962 7611 Contact: Luke Parisotto
GUNNEDAH	Hartley Electrical 37 Chandos Street Gunnedah NSW 2380 Contact: Ken Hartley Ph: 02 67420 222 Fax: 02 67420 222
KEMPSEY	Chris Conn Electrics & Appliances 31 Forth St NSW 2440 Ph: 02 6563 1998 Fax: 02 6562 2944 Contact: Chris Conn
KIAMA	Lou's Appliances 4 Tingira Cres NSW 2533 Ph: 02 4232 3525 Fax: 02 4232 3038 Contact: Lou Anthony
LISMORE	Lismore Appliance Rep 72 Keen St NSW 2480 Ph: 02 6621 9432 Contact: Mark Hart
LIVERPOOL	Liverpool Washing Machine Service Pty Ltd Shop 6, 11 Grimson Crescent NSW 2170 Ph: 02 9821 1281 Fax: 02 9821 1314 Contact: Max Jones
MACKSVILLE	Webbers Retraction 9 Wallace Street Ph: 02 656 81122 Fax: 02 656 82410 Contact: Doug Webber
NOWRA	Ewing Electrical 97 Plunkett Street NSW 2541 Contact: Graehame Ewing Ph: 02 4421 8412 Fax: 02 4422 1267
PARKES	Wilson's Services Centre 98 Clarinda Street NSW 2870 Ph: 02 6862 6261 Fax: 02 6862 3056 Contact: David Wilson

PENNANT HILLS	Teletronic TV & Video 290 Penmant Hills Road Ph: 02 9980 7346 Fax: 02 9980 7347 Contact: Juliette
PENRITH	Young's Appliance Spares Shop 10, 98 Henry St NSW 2750 Ph: 02 47 323 594 Fax: 02 47 211091 Contact: Ernie Fayle
PENSHURST	Masis Electronics 17 Penshurst Street NSW 2222 Ph/Fax: 02 9580 2288 Contact: Mathew Masis
PORT MACQUARIE	Bellbowrie Appliance Unit 24 Bellebowrie Park NSW 2444 Ph/Fax: 02 6584 3838 Contact: Dan Thompson
ROSEVILLE	Chatswood Appliance Spare Parts 486 Panshurst St NSW 2069 Ph: 02 9417 3999 Fax: 02 9417 8817 Contact: Ian Johnson
SEVEN HILLS	O'Brien Electrical 3/14 Abbot Road NSW 2147 Ph: 02 9620 8188 Fax: 02 9620 8866 Contact: Tien Dao
ST IVES	St Ives Electronics Shop 26 St Ives Village NSW 2075 Ph: 02 9986 4642 Fax: 02 9449 8808 Contact: Janet & Peter Collins
SINGLETON	Electrical Spares & Repairs 1 Pitt Street NSW 2330 Contact: Stanley Gould Ph: 02 6571 1644 Fax: 02 6572 2755
SUTHERLAND	Southside Elements 752 Old Princess Hwy NSW 2232 Ph: 02 9521 8288 Fax: 02 9545 1982 Contact: Steve Lawson
TAMWORTH	Appliance Care 4/154 Bridge St NSW 2340 Ph: 02 6765 2865 Contact: Arnold Brockman
TAREE	Emertons Home Appliance 35 Manning St NSW 2430 Ph: 02 6552 3444 Fax: 02 6552 7351 Contact: Noel Emerton
WAGGA WAGGA	Millers Appliance Repairs & Sales 108 Kincaid Street Ph: 02 6921 2628 Fax: 02 6921 1111 Contact: Graham Atkinson
WOLLONGONG	Upton's Appliances 1/233 Crown St NSW 2500 Ph/Fax: 02 4229 6632 Contact: Rob/Lanelle

VICTORIA

MARIBYRNONG Sunbeam Factory Outlet
8 Sloane St VIC 3082
Ph: 03 9319 4965
Fax: 03 9317 8123
(DO NOT REFER REPAIRS HERE)
Contact: Paul Borg

BAIRNSDALE Porters
132 Main St VIC 3875
Ph: 03 5152 4540
Fax: 03 5152 1755
Contact: Jack Porter

BALLARAT John Thomas & Co
4 Dawson St VIC 3350
Ph: 03 5331 3099
Fax: 03 5333 3850
Contact: John Thomas

BENDIGO Sumner Electronics Pty Ltd
66 Garsed St VIC 3550
Ph: 03 5443 1977
Fax: 03 5441 5562
Contact: George Sumner

BOX HILL Mian Electronics
943-945 Whitehorse Rd
VIC 3128
Ph: 03 9890 9426
Fax: 03 9899 5427
Contact: Micheal Douglas

BRUNSWICK Kinnear Electrical Appliance Repairs
Cnr Brunswick & Grantham St
West Brunswick VIC 3055
Ph: 03 9387 9531
Fax: 03 9388 1583
Contact: John Kinnear

DANDENONG Ellis Electrical
323 Thomas St VIC 3175
Ph: 03 9791 1486
Fax: 03 9792 9222
Contact: Brian Dwyer

ECHUCA Vincent's Retravision
174 Annesley St VIC 3625
Ph: 03 5482 1966
Fax: 03 5482 5585
Contact: Greg Vincent

GEELONG Julian's Appliance Service
78 Pyrie St VIC 3220
Ph: 03 5229 1971
Fax: 03 5229 5959
Contact: Julian Lanning

HAMILTON Robert Linke Electrical
82 Lonsdale Street VIC 3300
Ph/Fax: 03 5572 5788
Contact: Robert Linke

HEIDELBERG All Appliance Service & Sales
154 Burgundy St VIC 3084
Ph: 03 9459 9848
Fax: 03 9459 1016
Contact: Marshall Dwyer

MALVERN Mian Electronics
196 Glenferrie Rd, VIC 3144
Ph: 03 9576 1600
Fax: 03 9576 1409
Contact: Mian

MILDURA Graylings Electrical
689-691 Fifteenth Street VIC 3500
Ph: 03 5021 4656
Fax: 03 5023 6551
Contact: Phillip Grayling

MILDURA Jack Abel
2-4 Tenth Street
Contact: George Riordan VIC 3502
Ph: 03 5023 0251
Fax: 03 5023 3598

MOORABBIN Barling Elements
Shop 2/8 Station Street VIC 3189
Ph: 03 9535 2612
Fax: 03 9555 2723
Contact: Keith Cope

MOOROPNA Chapmans TV & Video Repairs
81 McLennan Street VIC 3189
Ph/Fax: 03 5825 3644
Contact: Russell Chapman

MORWELL Webster's Appliance Service Centre
Bldg 2, Lot 5 Vestan Drive VIC 3840
Ph: 03 5134 3543
Fax: 03 5134 4097
Contact: Bruce Carne

SWAN HILL Swan Hill Appliance Service
257 Beveridge St, VIC 3585
Ph/Fax: 03 5032 3262
Contact: Robert Masters

WARRNAMBOOL Western Electrical Service
223 Lava Street VIC 3280
Ph/Fax: 03 5562 5060
Contact: Bill Stewart

QUEENSLAND

AYR Coral Coast Electrical
133a Edwards Street
Contact: Julie Jorgenson
QLD 4807
Ph: 07 4783 4711
Fax: 07 4783 4835

BEERWAH Beerwah Electronics
Turner Park Shopping Centre
Peacheater Road QLD 4519
Contact: Garth Stone
Ph: 07 5494 0466
Fax: 07 5494 0146

BUNDABERG Digger Theile Electric Pty Ltd
37 Perry St, QLD 4670
Ph: 07 4152 1522
Fax: 07 4153 2215
Contact: Digger Theile

CAIRNS Kennedys Electrical Centre
101 Mcleod St QLD 4870
Ph: 07 40 31 3155
Fax: 07 4031 9177
Contact: Mike Schram

CLEVELAND Patricks Electrical
Shop 10 Ross Court Centre
Cnr Bloomfield & Ross Court QLD 4163
Ph: 07 3821 1420
Contact: Ray McAlees

GYMPIE Shepherd's Electrical
56-58 Duke Street QLD 4570
Contact: John Shepard
Ph: 07 5482 7522
Fax: 07 5482 1437

HERVEY BAY Hervey Bay Home Appliance Repairs
90 Dayman Street QLD 4655
Contact: J. Murphy
Ph: 07 4125 3975
Fax: 07 4125 3374

MACKAY Appliance Spares & Repairs
151 Victoria St QLD 4740
Ph: 07 49 51 1644
Fax: 07 4951 1880
Contact: Steve Hayes

MAROOCHYDORE Suncoast Appliance Services
11 Kayleigh Dr QLD 4558
Ph: 07 54433644
Fax: 07 5443 2514
Contact: Robert Cook

MT GRAVATT Mr. Sparky Appliance Repairs
Garden City Shoppingtown
Logan Rd QLD 4122
Contact: Daniel Rowe
Ph: 07 3349 7607
Fax: 07 3849 2433

MT ISA P & R Electrical Servicing
31 Arline St QLD 4825
Ph: 07 47 43 3354
Fax: 07 4743 6766
Contact: Mr Mathews

NAMBOUR Nambour Electrical
60 Price Street QLD 4560
Ph: 07 5441 1677
Fax: 07 5441 6113
Contact: Sue Armstrong

NUNDAH Nundah Small Appliances & Service
2/8 Eton Street QLD 4012
Ph: 07 3266 1867
Fax: 07 3266 3111
Contact: Mike McCann

ROCKHAMPTON Leenders Electrical
13 Murray St QLD 4700
Ph: 07 49 27 2922
Fax: 07 4927 1187
Contact: Mike Molachan

SOUTHPORT Electric Care
1 Windmill Street Southport
Ph: 07 5527 0508
Contact: Don Douglas

STRATHPINE Starks Appliance Repair
Unit 4/167 Gympie Road
Strathpine Qld 4500
Ph/Fax: 07 320 51350
Contact: Sue & Les

STH TOWNSVILLE Mac's Electrix
51 Perkins St QLD 4810
Ph: 07 47 72 1519
Contact: Alan McMahon

TOOWOOMBA Toowoomba Appliance Parts
123 Campbell St QLD 4350
Ph: 07 4638 0311
Fax: 07 4638 4166
Contact: Brenda & Mark

TOOWOOMBA Week's Electrical Pty Ltd
233 Ruthven St QLD 4350
Ph: 07 46 32 7420
Contact: Alan Weekes

TOOWONG Spark's Small Appliances
40 High Street QLD 4066
Ph: 07 3871 2300
Fax: 07 3871 2400
Contact: Danny Birang

TWEED HEADS Nelson Appliances
59 Boyd Street NSW 2485
Ph: 07 5536 3711
Fax: 07 5536 3719
Contact: Dan Hayden

WOOLLOONGABA Brisbane Appliance Service Centre
55 Ipswich Road QLD 4102
Ph: 07 3391 0360
Fax: 07 3391 0361

SOUTH AUSTRALIA

ADELAIDE Adelaide Shaver Centre
21 Twin St SA 5000
Ph: 08 8223 1094
Fax: 08 8224 0511
Contact: David Flavel or Joe Vella

MODBURY Adelaide Shaver Centre
Shop 8, Tea Tree Plus Shopping Centre
SA 5095
Ph: 08 8396 6311
Fax: 08 8396 6322
Contact: Bruce Penny

MT GAMBIER Moulden's Home Appliance Service
35 Percy St, SA 5290
Ph: 08 8725 1244
Fax: 08 8723 2065
Contact: David or Meredith

PARK HOLME Adelaide Shaver Centre
Park Holme Shopping Centre
319 Oaklands Road SA 5043
Ph: 08 8357 5800
Fax: 08 8357 5833
Contact: Bill Riddle or Brian Bishop

WEST LAKES Adelaide Shaver Centre
Shop 202 West Lakes Mall
West Lakes SA 5021
Ph: 08 8353 0655
Contact: Brian & Jan Holloway

WESTERN AUSTRALIA

ALBANY	Microwave Electrical Service Terrace Centre Arcade 96 Stirling Street WA 6330 Ph: 08 9842 2168 Contact: Geoff Collins
BELMONT	Anything Electrical 50 Belvedere Street WA 6104 Ph: 08 9479 6116 Contact: Phil Hawkins Fax: 08 9479 6117
GERALDTON	Geoff's Electrical 3/213 Place Road WA 6530 Ph/Fax: 08 9964 5655 Contact: Geoff Perks
KARDINYA	Elements & Appliance Unit 5/21 Weatherburn Way Fremantle WA 6163 Ph: 08 9314 1022 Fax: 08 9314 2299 Contact: Kevin Ingram
MANDURAH	Discount Appliance Unit 2/19 Rafferty Road WA 6210 Ph: 08 9535 3244 Fax: 08 9535 2144 Contact: Kristy Pitcher
MANJIMUP	Warren Electrical 7 Rose Street WA 6258 Ph: 08 9771 8220 Fax: 08 9771 2744 Contact: Robert
MIDLAND	B & J.L. Woodcock 4 Stafford Street WA 6056 Ph: 08 9274 5122 Fax: 08 9274 4824 Contact: Gary Woodcock
ROCKINGHAM	Rocky City Electrical 1/4 Ambrose Street WA Ph: 08 9527 3599 Fax: 08 9592 1819 Contact: Tracey Panizza
WANGARA	Electrical Spares & Service 2/12 Buckingham Drive WA 6947 Ph: 08 9409 8411 Fax: 08 9309 3830 Contact: Ken Stokes
WEMBLEY	Goddens Electrical Pty Ltd 332B Cambridge St WA 6014 Ph: 08 9387 4444 Fax: 08 9383 7003 Contact: Steve or Dennis
NORTHERN TERRITORY	
WINNELLIE	Mr. Vac 18 Menmuir Street NT 0821 Ph: 08 8947 1838 Fax: 08 8947 2868
TASMANIA	
BURNIE	The Appliance Clinic Pty Ltd 14 North Terrace TAS 7320 Ph: 03 6431 6857 Contact: Ross Arnold
DEVONPORT	Quickserv TV & Electrical Pty Ltd 4 Elisabeth St TAS 7310 Ph: 03 6424 1033 Fax: 03 6424 3545 Contact: Steve Posthumus
HOBART	B&W Appliances Sales & Service 284B Argyle Street TAS 7000 Ph: 03 6234 8989 Fax: 03 6231 1512 Contact: Max & Ken
LAUNCESTON	Northern Electrical Services 126 Charles Street TAS 7250 Ph: 03 6331 3971 Contact: Rhys Harding Fax: 03 6331 3992
LAUNCESTON	United Customer Service 127 Wellington Street TAS 7250 Ph: 03 6334 0066 Fax: 03 633 3215

NEW ZEALAND – NORTH ISLAND

NORTHLAND KERI KERI	Adtech Services Ltd. Keri Keri Road Ph: 09 407 6370 Fax: 09 407 6920
WHANGAREI	Mc Kay Electrical Whangarei Ltd 38 Water Street Ph: 09 438 2879 Fax: 09 438 3429
AUCKLAND	
MT ROSKILL	Rankin McManus Electrical 758 Dominion Road Mt Roskill Ph: 09 620 9006 Fax: 09 6204334
TAKAPUNA	Westmere Radio & Electrical 327A Wairau Rd, Takapuna Ph/Fax: 09/444 8324
MANUKAU	Manukau Appliance Serv Centre 6 Mana Place, Wiri Ph: 09 262 3388 or 09 262 3170
HENDERSON	Henderson TV & Electrical 103 Lincoln Rd Ph: 098386940
WAIKATO	
HAMILTON	Kings Radio Service 36 Harwood Street Ph: 07 839 3912 Fax: 07 834 2475
BAY OF PLENTY	
TAURANGA	Chaps Complete Home Service 173 Chadwick Rd, Greerton Ph: 07 578 4182
MT MAUNGANUI	The Electrical Home Service Co. 512 Maunganui Rd, Mt Maunganui Ph: 07 574 0298
NORTH ISLAND	
WAIHI	Waihi Electrical Box 64 Seddon St, Waihi Ph: 07 863 8742 Fax: 07 963 6863
ROTORUA	Robertson Home Appliances 1180 Haupapa Street Rotorua Ph: 07 348 0313
OPOTIKI	Opotiki Appliance Service 19 Elliot Street Ph/Fax: 07 315 6445
HAWKES BAY	
GISBORNE	GISBORNE Electrical 155 Grey Street Ph: 06 867 6319 Fax: 06 868 6132
NAPIER	Duckworth's Customer Service Cnr Cadbury Austin St Onekawa Ph: 06 843 3292 Fax: 06 843 3287
HASTINGS	Hector Jones King Street North Ph: 06 843 3292 Fax: 06 876 0800
KING COUNTRY	
TAUMARUNUI	Taumarunui Electrical Service 91 Hakiaha Street Ph/Fax: 07 895 7993
TARANAKI	
WAITARA	Des O'Connor Electrical 8 Fox Street, Okato Ph/Fax: 06 752 4999

RANGITIKEI

WANGANUI	Home Appliance Doctors 27 Heads Road Ph: 06 348 8520 Fax: 06 348 8522
-----------------	--

NORTH ISLAND – MANAWATU

PALMERSTON NORTH	Leader & Watt Ltd 153-163 Rangitikei Street Ph: 06 356 5123 Fax: 06 356 8111 B&M Electrical Cnr Princess & Dahlia Street Ph: 06 356 4912 Fax: 06 356 9273
-----------------------------	--

PARAPARAUMU

HOROWHENUA	K&S Appliances 23 Ihakara Street Ph/Fax: 04 298 6783
-------------------	--

WELLINGTON

WELLINGTON	Capital Appliance Care 90 Abel Street Ph: 04 801 7590 Fax: 04 801 7592
-------------------	---

UPPER HUTT	Upper Hutt Electrical 208 Main Street Ph: 04 528 2195 Fax: 04 528 3195
-------------------	---

SOUTH ISLAND – MARLBOROUGH

BLENHEIM	Blenheim Electrical House 42 Main Street Ph: 03 578 3564 Fax: 03 577 8605
-----------------	--

NELSON	Nelson Appliance Repair Centre 36 Gloucester Street Ph/Fax: 03 548 8738
---------------	---

RICHMOND	Nelson Home Appliance 265 Queen Street Ph/Fax: 03 544 6317
-----------------	--

CANTERBURY

CHRISTCHURCH	Saxon Appliances 383 Wilson's Road Ph: 03 365 6792
---------------------	--

MID CANTERBURY

ASHBURTON	Smith & Church Retravision Kermode Street Ph: 03 308 9019 Fax: 03 308 5583
------------------	---

TIMARAU	Gabites Appliance Services 22 North Street Ph: 03 688 0949 Fax: 03 688 9490
----------------	--

NORTH OTAGO

OMARU	Hills Appliance Service 6 Tees Street Ph/Fax: 03 434 8557
--------------	---

OTAGO

DUNEDIN	Clarke Electrical 29 Leith Street Ph: 03 47702350 Fax: 03 47702309
----------------	---

SOUTH ISLAND – CENTRAL OTAGO

ALEXANDRIA	Appliance & Powertools Repairs 15 Tarbert Street Ph: 03 448 5217 Fax: 03 448 5217
-------------------	--

TE ANAU	Fiordland Electrical 120 Milford Rd Ph: 03 249 7319 Fax: 03 249 8327
----------------	---

SOUTHLAND

INVERCARGILL	P D Patton (1979) Ltd 96 Kelvin St Ph: 03 218 2159
---------------------	--

The Sunbeam logo is displayed in a white, cursive font within a red rectangular box.

2 Year Replacement Guarantee

We are so confident of the quality of our product, should this appliance develop any malfunction within 2 years of purchase (3 Months commercial use) due to faulty materials or manufacture, we will replace it for you absolutely free.

Should you experience any difficulties with your appliance, please phone our Free Call customer service line for advice on 1800 025 059 in Australia, or phone (09) 912 0747 in New Zealand.

Alternatively, simply return the faulty appliance to your place of purchase, along with your purchase receipt.

Your Sunbeam 2 Year Replacement Guarantee naturally does not cover misuse or negligent handling, and excludes breakables such as glass or ceramic items, and normal wear and tear.

In Australia, this guarantee is additional to the conditions and guarantees which are mandatory as

implied under the Trade Practices Act 1974 and State and Territory legislation.

Sunbeam Service Centres

Sunbeam has established a network of authorised service centres throughout Australia and New Zealand to provide quick, convenient service for our customers.

Should your appliance require repair or service, either during or after the guarantee period, take it to your nearest Service Centre (see over page for complete list of Service Centres). If it is not convenient for you to take the appliance to the Service Centre in person, send it to the nearest Service Centre.

To ensure quick service, prepare a tag stating your full name and address, and the nature of the complaint, and attach it to your appliance. Pack your appliance carefully in a strong carton surrounded by newspaper or other supportive packing material to prevent damage. Clearly address it to the selected service centre, and include your name, address and phone number on the outside of the package.


The Sunbeam logo consists of the word "Sunbeam" in a white, cursive script font, set against a solid red rectangular background.

Consumer Hotline

Australia
1800 025 059

New Zealand
(09) 912 0747

www.sunbeam.com.au

 is a registered Trademark of Sunbeam Corporation Limited. ACN 000 006 771.

© Sunbeam Corporation Limited 2004.