

- ITEM 8200 - CLAM 2000 - PORTABLE ICE SHELTER -



SPECIFICATIONS

Set-Up

Height: 60"

Width: 72"

Length: 48"

Collapsed

Height: 6"

Width: 72"

Length: 36"

Weight: 45 Lbs.

Congratulations on your recent purchase of a Clam Portable Ice Shelter. The following is included in the booklet:

- **Set-Up Instructions**
- **Safety Instructions**
- **Warranty Information**

ONCE USED THIS SHELTER CANNOT BE RETURNED TO THE STORE. IF YOU HAVE A WARRANTY CLAIM CONTACT CLAM CORPORATION CUSTOMER SERVICE DIRECTLY AT:


**Clam Corporation, Inc.
Attn: Customer Service
15600 28th Avenue North
Minneapolis, MN 55447**

**Hrs: 8am–5pm Central Standard Time
Phone: 763-231-4120
Fax: 763-231-4121
Email: customerservice@clamcorp.com**

Warranty does not cover cracked windows, tent tears, broken or bent hoops due to high wind, weather conditions, unattended use, or during the course of normal wear.


- SET-UP INSTRUCTIONS -

- Unfold the unit and unzip the doors at both ends. (*Tent not shown installed for clarity*).
- Through the doorway of one end, grasp the *Hoop Pole* that pivots near the corresponding end and lift, sliding the *Hoop Pole* up until it locks into the position. (You should hear the *Spring Buttons* of the *Lower Legs* engage the holes of the *Hoop Pole*.)
- Go around to the other doorway and do the same with the *Hoop Pole* located on the opposite end.



- SET UP INSTRUCTIONS -

- Locate the *Flexible Rods* and unfold them into the straightened position.
- Go into the unit and slide one end of a *Flexible Rod* into one of the corner pockets located on the corners of the *Hoop Tubes*.
- Slide the other end of the *Flexible Rod* into a pocket located on the opposite *Hoop Tube*, diagonally across the shelter. (*The Rods will form an "X" when assembled*).
- Do the same with the other *Flexible Rod* and then Velcro the two *Flexible Rods* together where they cross with the Velcro attached to the center of the tent roof. You are now ready to fish!!



- TAKE DOWN INSTRUCTIONS -

- Remove the *Flexible Rods* and fold them up. Place them on the side of the *Floor Half* without the bucket impressions. (*When used, the bucket impressions help steady a bucket while towing in the collapsed position*).
- Collapse both *Hoop Tube* assemblies and rotate them down onto their respective floors.
- Now fold the *Floor Half* with the bucket impressions onto the other. Tuck the tent material between the *Floor Halves* so that the material is protected.
- Attach the provided *Latch Clips* to hold the shelter in the closed portable position. (*The Eyelets of the Latch Clips may be used for roping down gear on top of the unit while on the go.*)



Latch Clip Eyelet

- SAFETY INSTRUCTIONS -

Please fully understand and follow all safety instructions outlined in this booklet. Failure to do so could result in severe injury or death.

Do not use open flame heaters in your ice shelter. Injury or death may result from fire if tent fabric is exposed to open flame. The tent is not fireproof, but the fabric is treated with a fire retardant that meets CPAI-84 specifications. Application of any foreign substance may render the flame retardant properties ineffective. Ice Armor fabric will melt when contact is made with hot surfaces (i.e., heaters).

BEFORE USING A HEATER, OPEN ALL VENTS FOR CROSS VENTILATION.

Death from asphyxiation may result from use of oxygen depleting heaters. Open all vents for fresh air ventilation.

- Never leave shelter unattended when set up.
- Due to the increase in traffic (snowmobiles, autos, etc.) on area lakes, ice fishing can be hazardous at night. If you choose to fish at night or in poor visibility conditions, be sure to take precautions with lights or reflectors to show drivers your whereabouts. Night time: exterior reflectors must be visible to reduce risk of collisions.

- WARRANTY INFORMATION -

Clam Corporation, Inc. warrants to the original retail purchaser that all Clams are free from manufacturer's defects for one (1) year from the date of the original purchase. Warranty does not cover cracked windows, tent tears, broken or bent hoops due to high wind weather conditions or unattended use. Clam Corporation will replace or repair any part found defective within the one (1) year time limit. All parts must be returned to Clam Corporation, Inc. Before returning any parts, you must first call or write and acquire a return authorization. All returns must be returned postage-prepaid and include the original cash register receipt (date and purchase price).

To obtain a return authorization, call or write:

Clam Corporation, Inc.
Attn: Customer Service
15600 28th Avenue North
Minneapolis, MN 55447

Phone: 763-231-4120
Fax: 763-231-4121
Email: customerservice@clamcorp.com

This warranty does not apply to any Ice Shelter that has been subjected to an accident, improper installation, modification, adjustment, repair, misuse, misapplication, neglect, including but not limited to improper maintenance, or use of unauthorized parts or attachments.

- LIMITATION OF LIABILITY -

It is expressly understood that Clam Corporation Inc, liability for its products, whether due to breach of warranty, negligence, strict liability, or otherwise, is limited to the repair of the product as stated above. Clam Corporation, Inc. is not liable for any injury, loss, damage, or expense, whether direct or consequential, including but not limited to loss of use, income, profit, or damage to material arising in connection with the sale, installation, use of, inability to use, or the repair or replacement of Clam Corporation, Inc. products. Clam Corporation, Inc. reserves the right to make alterations or modifications in its products at any time, which in its opinion, may improve the performance and efficiency of the product. It shall not be obligated to make such alterations or modifications to products already in service.