



Before operating the Refrigerator, please read this manual carefully and retain for future reference.




Refrigerator

Instruction Manual

The word "PEL" in a bold, blue, sans-serif font, centered within a white circle that has a thick blue border. A white curved line extends from the left side of the circle across the page.


PEL




All cautions & notes on this refrigerator are important: please pay attention to them.

REFRIGERATOR MODELS & SERIES


SL Series	WB Series	6 Series
2009	20145JF	6200
2010	20165	6300
2012	2017	6400
2300JF	20175	
2500JF	20185	




Slim Line Series
Crystal




Slim Line Series
Star Plus



Slim Line Series
Premier



6 Series



Wide Body Series

INSIDE YOUR STARTER PACK

Dear Valued Customer

We congratulate you on your choice. You now are a proud owner of a PEL product having joined millions of others who are benefitting from quality PEL products for more than 50 years.

We want to assure you that each PEL product is built to last with state-of-the-art, energy efficient technology adapted to suit our local environment.

Distinctive qualities that we are proud to share with all our valued customers providing high performance, reliability, durability and most of all prompt customer care whenever and wherever you need it.

Kindly fill out the Warranty Card and send the Company's Copy to the given address for Warranty Registration.


Please read this Instruction Manual carefully as it will guide you to install, operate and maintain this appliance in its original condition for years to come.

Welcome to the PEL family, and wishing you many years of ease and comfort that come with the PEL name.

Thank you


■ REFRIGERATOR MODELS & SERIES	01
■ PARTS IDENTIFICATION	03
■ INSTALLATION	04
Leveling the Appliance	
Personal safety	
■ GETTING STARTED	05
Food storage	
Vegetable / Fruit compartment	
■ ICE CUBES MAKING	06
■ TEMPERATURE CONTROL	06
■ DEFROSTING	07
Single Door Refrigerator	
Double Door Refrigerator	
■ GENERAL CARE AND CLEANING	09
■ DEODORIZER	10
■ TROUBLE SHOOTING TIPS	11
■ SAFETY PRECAUTIONS	13

PARTS IDENTIFICATION





NOTE: Specifications may vary from model to model.

INSTALLATION



1. Remove packing carton and all thermopore pieces from the refrigerator, specially one at the back of the compressor. Install the Appliance on a firm, flat surface or a Wooden Pedestal (Chowki).
2. For optimum performance install the refrigerator in a well ventilated place. Avoid installing the refrigerator near heat generating home appliances such as heater, stove and in small nooks / corners, direct sun light.
3. **Leveling the Appliance**
To compensate any floor unevenness, adjust the balance of Appliance by rotating the Leveling Screws clock wise or anti clock wise.
4. Always install your refrigerator in a tilted position as shown.
5. **For personal safety**, properly ground this Appliance.
Do not ground the refrigerator with a telephone line, gas pipe, etc. It is necessary that refrigerator should be connected to the proper earth point.



IMPORTANT:

The manufacturer will not be responsible for any loss or damage if precaution in this regard is not observed.

NOTE:


Retain the original packing in case you need to ship it at a later date.

GETTING STARTED

Clean the refrigerator before turning it ON. After plugging check that the light inside the cabinet is ON, when the door is opened. Turn the thermostat knob to the maximum position "8", close the refrigerator doors, let it run idle for 2 ~3 hours, then turn the thermostat knob to the medium position (4) in normal condition, now the refrigerator is ready to store food . If it is peak summer, set the thermostat position at (5 ~ 6).

FOOD STORAGE

1. Seal food in containers with lids or in plastic bags to prevent drying and mingling of odour.
2. In Freezer compartment keep food in small quantities for quick freezing.
3. Allow hot food and drinks to cool down before placing in the refrigerator or freezer.
4. Food should be arranged so as to ensure free circulation of cool air in the compartment, never cover grid shelves with plastic mats or sheets.
5. Food stored in the refrigerator compartment can be refrigerated up to a certain limit.
6. Wash and dry meat, fruits and vegetables before placing them in the refrigerator.



VEGETABLE / FRUIT COMPARTMENT

This compartment maintains the moisture of vegetables & fruits, to sustain their freshness for longer period.

**CAUTION:**

Do not freeze the meat again after getting it defrosted. It can be harmful for health.

NOTE:

Incase of prolonged power failures, it is recommended that stored food should be consumed within 6~8 hours.

ICE CUBES MAKING

When you want to make ice cubes, take out complete set of ice tray carrier, pour water in ice trays and slide it back.

After ice cubes have been formed in the ice trays, free the ice cubes from the ice trays by turning the ice tray's knob clockwise. Twist it again and allow ice cubes to drop into the ice cube container underneath.


PRECAUTION: Make sure that the ice cube container is beneath the ice trays.

NOTE: Ice tray design may differ in different models.

TEMPERATURE CONTROL

The temperature inside the refrigerator may vary according to the frequency of door opening, food status or the amount of food stored in the refrigerator. Adjust the thermostat knob to change the internal temperature according to the environmental temperature. For reference, please see the following table:

Position "0"	Off position	
Position "2 ~ 3"	When environmental temperature is below 15 C	<i>Winter season</i>
Position "4"	When environmental temperature is 15 C - 30 C	<i>Moderate season</i>
Position "5 ~ 6"	When environmental temperature is 30 C - 40 C	<i>Summer Season</i>
Position "7 ~ 8"	When environmental temperature is above 40 C	<i>In special cases, not recommended normally</i>



Thermostat Knob



DEFROSTING



Defrosting is necessary for efficient performance of the Appliance. When the layer of frost on the walls of freezer compartment becomes 5 ~ 8 millimeters or over, the Appliance needs to be defrosted.

Single Door Refrigerator

This refrigerator is equipped with a semi automatic defrosting thermostat with a Push-Button.

To defrost the refrigerator, follow these instructions:

1. Remove food and ice trays from freezer compartment.
2. Press Push-Button of thermostat knob, let the Refrigerator & Freezer doors open for defrosting.
3. Wait till the frost melts then remove it carefully with the help of Ice scraper.
4. Take out Drip tray carefully when it is filled with water, dispose of this water and slide it back to its original position. You may repeat this action till defrosting is completed.
5. Push-Button will automatically come back to its original position when defrosting is completed.



CAUTION:

Do not remove frost with knife or sharp metal tools.
Always use company provided Ice Scraper.

NOTE: Complete defrosting is recommended after every month.

DEFROSTING

Double Door Refrigerator

Refrigerator Compartment



This compartment defrosts automatically. Manual defrosting is not required.

Freezer Compartment

To defrost the freezer compartment, follow the instructions given below:

1. Remove food, ice trays set, ice cube container and grid shelves from Freezer compartment.
2. Turn the thermostat knob to position "0" unplug the Appliance and let the Freezer door open for defrosting.
3. Wait till the frost melts then remove it carefully with the help of Ice Scraper.
4. When frost is removed, take out protection plate carefully and detach the drain plug in order to drain out defrosted water.
5. (a) **(For 6 series only)** Place a container exactly under the drain to collect defrosted water.
(b) **In Slim Line series & Wide Body series** defrosted water will drain out and collect in the condensate tray provided at the back of the cabinet as shown in page # 9.
6. Now clean the whole compartment with a soft dry cloth. Insert drain plug back to its original position and place protection plate over it.
7. Close the Freezer door and let it run for about one hour before reloading the food.

Drain Hole 6 Series Models only




CAUTION:

Do not remove frost with knife or sharp metal tools. Always use company provided Ice Scraper.


NOTE:

Complete defrosting is recommended after every month.



GENERAL CARE AND CLEANING

This refrigerator does not require any special maintenance. It is however advised to keep your refrigerator neat and clean, this will increase the life of your refrigerator.





1. Always unplug the refrigerator before cleaning. Do not use liquid cleaners or aerosol cleaners.
2. Never apply water directly inside or outside the refrigerator. Water spoils the insulation of electric parts and may cause electrical shock.

Interior Cleaning

For inside cleaning take out all food and accessories from refrigerator, use a solution of 9 parts water and 1 part vinegar, rinse thoroughly with a sponge and fresh water. Finally dry whole cabinet with a soft cloth.

Door Gasket

Clean the gasket thoroughly in order to maintain its sticking quality.



Gasket

NOTE:


Dry all the accessories completely before putting them back at their original position.

Exterior Cleaning

To clean the external side of the refrigerator use only a slightly damp soft cloth.

Condenser

Clean the refrigerator condenser with a brush or vacuum cleaner, this maintains the efficiency of your refrigerator refrigerator.



DEODORIZER

DEODORIZER

Deodorizer removes odour from the refrigerator.

PRECAUTION:

Storing food or liquids which can pick up or transmit odour or flavors easily, must be kept in sealed container.


NOTE:

The deodorizer does not harm stored Food.


IMPORTANT:

If you are not using the refrigerator for more than 01 week, unplug the appliance, take out all the food stuffs, clean both Ref. & Frz. inner cabinets properly and keep the doors open. If you keep the doors in closed position, it will give foul smell.

6 Series



SL Series & WB Series



TROUBLE SHOOTING TIPS


PROBLEMS	CAUSES	SOLUTIONS
When the refrigerator does not operate at all.	There might be a power connection or electrical failure problem. The thermostat knob is at position "0".	Check the power cord and plug it properly. Select the appropriate thermostat position. See page # 6.
When the refrigerator does not operate well.	The refrigerator is exposed to direct sunlight or installed near a heating device. The appliance does not have enough clearance from the wall in all directions. The thermostat knob is at position 1 or 2. The refrigerator contains hot food or too much food? The refrigerator door opening is frequent or left open for long time.	Check the installation place. See page # 4. Set the thermostat position appropriately. See page # 6. Check the condition and quantity of stored food. See page # 5. Close the door and avoid opening it frequently.
When water comes out of the refrigerator.	The drain passage is blocked. Water accumulates under Fruit & Vegetable compartment. Refrigerator level is improper.	Check the drain passage and remove sludge. Take out Fruit & Vegetable compartment, remove water with a soft dry cloth. Adjust the level through Leveling Screws.

TROUBLE SHOOTING TIPS

PROBLEMS	CAUSES	SOLUTIONS
When there is a severe noise.	The refrigerator is installed on an uneven floor. The Leveling Screws are set incorrectly. The refrigerator is touching back wall. Compressor tubes are touching one another.	Check the installation place. See page # 4. Adjust the Leveling Screws. See page # 4. Give sufficient space as described on page # 4. Separate them softly.
When food freezes in the refrigerator compartment.	The thermostat knob is at its maximum position 7 or 8. The ambient temperature is too low.	Set the thermostat position appropriately. See page # 6.
When there are dewdrops in the Refrigerator interior.	The refrigerator door is being opened frequently or left open for longtime. High moisture air or humidity during monsoon season.	Keep the door closed and avoid frequent opening of door. Clean the interior with soft dry cloth.
When there are dewdrops on the Refrigerator exterior.	High moisture air or humidity during monsoon season.	Wipe with a soft dry cloth.
When outer cabinet gets warm.	Built-in heating system is used.	No remedial action required.

SAFETY PRECAUTIONS


Do not splash water directly on the refrigerator. Water impairs the insulation of electric parts and may cause an electric shock or a shock hazard



Do not allow anything to rest on the power cord. Do not locate this product where the cord will be abused by persons walking on it.




Avoid using flammable sprays such as lacquer and paint near the refrigerator.




Do not allow infants to hang on the door, they may get hurt or could damage the appliance.

Do not leave the doors open for longer period because it can affect the efficiency of the refrigerator.




Do not use extension cords as this can result in the risk of fire or electric shock.

Do not store volatile chemicals such as ether and benzene in the refrigerator. The fumes besides damaging food can buildup and cause an explosion.



Do not use the refrigerator if it is not operating correctly or has been damaged. Disconnect it from the power supply and call PEL Customers Service Center or PEL authorised work shops.





PEL Refrigerator Warranty

Sr. No. _____

(To be filled in by the customer & sent back to PEL for necessary registration.)

Ref. Serial No. _____ Compressor Serial No. _____

Model No. _____ Date of Purchase _____

Buyer's Name _____ Phone No. _____

Buyer's Address _____

E-mail _____ Authorized dealer stamp _____

This non-transferable warranty applies to the original buyer only and the unit must have been purchased from PEL or one of its authorised dealers to avail the warranty coverage.

PAK ELEKTRON LTD.

Customer Services Department

14 Km, Ferozpur Road, P.O Box 1614, Lahore, Pakistan.

Ph: 042- 5811951- 59, Fax: 042-5810156, 5822682

www.pel.com.pk



(Company's copy)

WARRANTY CERTIFICATE

WARRANTY FOR PEL REFRIGERATOR

PEL refrigerators are made par excellence and are free from all workmanship and material defects.

A. Compressor Warranty:

This warranty covers free replacement of a faulty COMPRESSOR with a new or functionally operative compressor only once within five years from the date of its production*.

B. Cabinet & Parts Warranty:

PEL refrigerators are also backed by a 1-year warranty against rust on cabinet, by either repair or replacement. Other parts of PEL refrigerator, which if found defective in material or workmanship within 1- year from the date of purchase, will be replaced or repaired free of cost, however, this does not cover bulbs, grid shelves, plastic and rubber accessories.

C. Terms and conditions:

1. * The Warranty period will commence from the date of production, which will be considered as date of purchase . However 06 months relaxation will be given from actual production date irrespective of the date of purchase.
2. Customer has to pay Rs. 150/- as visit fee in case of complaint after one month of date of purchase.
3. Transportation will be charged from the customers in case complaint is registered after one month of date of purchase.
4. In case of complaint after 01 year from the date of purchase, the cost of spare parts and labour will be borne by the customer.
5. Gas charges will be payable by the buyer, after one year of date of purchase.
6. No claim will be entertained unless the warranty certificate has been registered at our following office within fifteen days of purchase.
7. This non-transferable warranty applies to the original buyer only and the unit must have been purchased from PEL or one of its authorised dealers to avail the warranty coverage.
8. It is the obligation of the buyer to supply proper voltage and check the domestic electrical wiring before installation.
9. The warranty will become null & void in case of following:
 - a. Any defect arising out of improper wiring, high/low voltage, short-circuiting or use of a substandard voltage stabilizer.
 - b. The warranty does not cover any part of the refrigerator, which may have been subjected to misuse, neglect, breakage or accident.
 - c. If the unit is given to any un-authorized dealer/workshop or tampered with or it's serial numbers are illegible, Company's decision regarding any warranty claim would be considered as final.

PAK ELEKTRON LTD: Customer Services Department 14 Km, Ferozepur Road, P.O Box 1614, Lahore, Pakistan.

Ph: 042- 5811951- 59, Fax: 042-5810156.



PEL Refrigerator Warranty

Sr. No. _____

Ref. Serial No. _____ Compressor Serial No. _____

Model No. _____ Date of Purchase _____

Buyer's Name _____ Phone No. _____

Buyer's Address _____

E-mail _____ Authorized dealer stamp _____

This non-transferable warranty applies to the original buyer only and the unit must have been purchased from PEL or one of its authorised dealers to avail the warranty coverage.

PAK ELEKTRON LTD.

Customer Services Department

14 Km, Ferozepur Road, P.O Box 1614, Lahore, Pakistan.

Ph: 042- 5811951- 59, Fax: 042-5810156, 5822682

www.pel.com.pk



(CSD's copy)

WARRANTY CERTIFICATE

WARRANTY FOR PEL REFRIGERATOR

PEL refrigerators are made par excellence and are free from all workmanship and material defects.

A. Compressor Warranty:

This warranty covers free replacement of a faulty COMPRESSOR with a new or functionally operative compressor only once within five years from the date of its production*.

B. Cabinet & Parts Warranty:

PEL refrigerators are also backed by a 1-year warranty against rust on cabinet, by either repair or replacement. Other parts of PEL refrigerator, which if found defective in material or workmanship within 1- year from the date of purchase, will be replaced or repaired free of cost, however, this does not cover bulbs, grid shelves, plastic and rubber accessories.

C. Terms and conditions:

1. * The Warranty period will commence from the date of production, which will be considered as date of purchase . However 06 months relaxation will be given from actual production date irrespective of the date of purchase.
2. Customer has to pay Rs. 150/- as visit fee in case of complaint after one month of date of purchase.
3. Transportation will be charged from the customers in case complaint is registered after one month of date of purchase.
4. In case of complaint after 01 year from the date of purchase, the cost of spare parts and labour will be borne by the customer.
5. Gas charges will be payable by the buyer, after one year of date of purchase.
6. No claim will be entertained unless the warranty certificate has been registered at our following office within fifteen days of purchase.
7. This non-transferable warranty applies to the original buyer only and the unit must have been purchased from PEL or one of its authorised dealers to avail the warranty coverage.
8. It is the obligation of the buyer to supply proper voltage and check the domestic electrical wiring before installation.
9. The warranty will become null & void in case of following:
 - a. Any defect arising out of improper wiring, high/low voltage, short-circuiting or use of a substandard voltage stabilizer.
 - b. The warranty does not cover any part of the refrigerator, which may have been subjected to misuse, neglect, breakage or accident.
 - c. If the unit is given to any un-authorized dealer/workshop or tampered with or it's serial numbers are illegible, Company's decision regarding any warranty claim would be considered as final.

PAK ELEKTRON LTD: Customer Services Department 14 Km, Ferozepur Road, P.O Box 1614, Lahore, Pakistan.

Ph: 042- 5811951- 59, Fax: 042-5810156.



PEL Refrigerator Warranty

Sr. No. _____

Ref. Serial No. _____ Compressor Serial No. _____

Model No. _____ Date of Purchase _____

Buyer's Name _____ Phone No. _____

Buyer's Address _____

E-mail _____ Authorized dealer stamp _____

This non-transferable warranty applies to the original buyer only and the unit must have been purchased from PEL or one of its authorised dealers to avail the warranty coverage.

PAK ELEKTRON LTD.

Customer Services Department

14 Km, Ferozepur Road, P.O Box 1614, Lahore, Pakistan.

Ph: 042- 5811951- 59, Fax: 042-5810156, 5822682

www.pel.com.pk



(Customer's copy)

وارنٹی سرٹیفکیٹ

PEL فرنیچ کی وارنٹی: PEL کے فرنیچ نمائندوں سے پاک اور اعلیٰ معیار کو مدنظر رکھتے ہوئے تیار کیے جاتے ہیں۔

(ا) کپریس کی وارنٹی

PEL اپنے فرنیچ کے کپریس کی پانچ سالہ وارنٹی دیتا ہے۔ تاریخ پر وڈکشن* سے پانچ سال کے دوران کپریس خراب ہونے کی صورت میں ایک بار تبدیل کیا جائے گا، تاہم مملکت کا معاوضہ، گیس اور فرنیچ کو متعلقہ ورکشاپ تک لانے لے جانے کے اخراجات خریدار کو ادا کرنے ہوں گے۔ تاریخ پر وڈکشن* سے ایک سال کے اندر گیس خارج ہونے کی صورت میں بلا معاوضہ گیس چارج کی جائے گی، ایک سال کے بعد گیس چارج کے اخراجات خریدار کو ادا کرنے ہوں گے۔

(ب) کینٹ اور پڑھ جات (پارٹس) کی وارنٹی

PEL کا فرنیچ رنگ سے محفوظ ہے اور کمپنی 1 سال تک رنگ نہ لگنے کی وارنٹی دیتی ہے اس کے علاوہ پڑھ جات (پارٹس) کی وارنٹی بھی ایک سال ہے۔ (شیشہ، پلاسٹک اور ربڑ پارٹس کی کوئی وارنٹی نہیں ہے)

(پ) قواعد و ضوابط

- 1 * فرنیچ کی پروڈکشن کی تاریخ کو ہی تاریخ خرید تصور کیا جائے گا۔ جس میں چھ ماہ تک کی چھوٹ دی جاسکتی ہے۔
- 2 تاریخ خرید کے ایک ماہ بعد شکایت ہونے کی صورت میں کسٹمر کو 150 روپے بطور وزٹ فیس ادا کرنے ہوں گے۔
- 3 تاریخ خرید سے 15 دن کے اندر وارنٹی سرٹیفکیٹ درج ذیل پتہ پر رجسٹر کروائیں بصورت دیگر وارنٹی قابل قبول نہیں ہوگی۔
- 4 وارنٹی صرف اصل خریدار کے لیے ہی ہے بشرطیکہ فرنیچ PEL یا اس کے مقرر کردہ ڈیلر سے خریدا گیا ہو۔
- 5 خریدار کی ذمہ داری ہے کہ فرنیچ کو چلانے سے پہلے ہینجلی کی وارنٹنگ کو چیک کرے اور فرنیچ کو مطلوبہ ڈولٹیج فراہم کرے۔
- 6 درج ذیل وجوہات سے فرنیچ خراب ہونے کی صورت میں وارنٹی غیر موثر ہوگی۔

(ا) وارنٹنگ کی خرابی، کم یا زیادہ ڈولٹیج، غیر معیاری سٹیبلنائزر یا شارٹ سرکٹ سے ہونے والی خرابی کی وارنٹی نہیں ہوگی۔

(ب) فرنیچ کے غلط طریقے سے استعمال، ایکسیڈنٹ یا کسی بھی طرح ٹوٹے ہوئے پارٹس کی وارنٹی نہیں دی جائے گی۔

(پ) فرنیچ غیر متعلقہ ورکشاپ سے مرمت کروانے، سیریل نمبر نا قابل شناخت یا تبدیل کیے جانے کی صورت میں وارنٹی منسوخ قرار دی جائے گی۔

7 خراب فرنیچ کی مرمت کے لیے صارف کے گھر یا دفتر سے ورکشاپ اور واپسی کا کرایہ بذمہ خریدار ہوگا۔


8 فرنیچ کے استعمال کے دوران خدا نا خواستہ کسی قسم کا مالی نقصان ہونے کی صورت میں کمپنی ذمہ دار نہ ہوگی۔

9 کسی کلیم کی صورت میں کمپنی اور صارف کو لاہور کورٹ کا فیصلہ ماننا ہوگا۔


CUSTOMER CARE CENTERS

Bahawalpur	062- 2731281	2/2 Adil Town , Dubai Mehal road, Near City school, Bahawalpur.
D. G. Khan	064- 2467277	H. No. 43, St. No. 1, Model Town, X-Block, D.G. Khan.
D. I. Khan	0966- 730707	Madina tul Latif Colony, Near Grid Station, Sheikh Yousaf road, D.I. Khan.
Faisalabad	111-102-103	8-Z-1, Near Bank Morr, Madina Town, Faisalabad.
	041-8732485, 8546991	
Gujar Khan	0513-516214	Jinnah Shopping Center, Near TMA Office, GT Road, Gujar Khan.
Gujranwala	055-3846635	H. No. 2-C-1 St. No. 1, Session Court Road, Civil Line, Gujranwala.
Gujrat	053-3028140, 2111993	Kuchery Road, Near Malik Hotel Gujrat.
Hyderabad	111-102-103	H. No. 224, Block C, Unit No. 2, Latifabad, Hyderabad.
	0223-868571, 817547	
Karachi	111-102-103	189-E, Block II, P.E.C.H.S, Near Govt. Girls College, Karachi.
	021-4538217, 4538230	
	021-4986751	A- 120, Block No. 5, Behind Hamdani Hospital, Gulshan-e-Iqbal, Karachi.
	021-6027471, 6027472	33- Sector P, Near Chinot Hospital, Karachi.
Lahore	111-102-103	99- Shah Jamal, Near Shah Jamal Market, Opp. Takoni Park, Lahore.
	042-7552149, 7552643	
	042-6816336, 6816515	146-Crown Park, Behind Shell Petrol Pump, Baghbanpura G.T Rd Lahore.
Mandi Bahauddin	0546-520508	H. No. B-11/364, St. No.4, Usmania Muhalla, Kachari Rd, Mandi Bahauddin
Multan	111-102-103	11- A/1, Gulgusht Colony, Opp. Pizza Hut, Multan.
Peshawar	091-5853398	H. No. 44, St. No. 6, Gulshan-e-Iqbal Town, University road, Peshawar.
Quetta	081-2839944	141/B, Shahbaz Town, Phase 1, Quetta Cantt.
Rahim Yar Khan	068-5889837	12- Factory road, Near Sukkur Adda, Rahim Yar Khan.
Rawalpindi	111-102-103	223- Block B, Zumarrud Plaza , Sattelite Town, Near Chandni Chowk, Rawalpindi.
	051-4454757, 4456077	538- Jail Road, Sahiwal.
Sahiwal	040-4467575	Rehmat Center, Main Rd, Shaheen Park, Gate No. 2, Plot No.4, Sargodha.
Sargodha	048-3725110	H. No. 2, Defence road, Opp. Azam CNG Station, Sialkot.
Sialkot	0523-254455	H. No. C-447-2-5-6, Opp. Attma Ram Clinic, Wallice Rd, Gari Ahata, Sukkur
Sukkur	071-5620832	Chachi Mohalla, Near Barrier # 2, Near G T Road, Wah Cantt.
Wah Cantt.	051-4542242	
HEAD OFFICE:	14-Km, Ferozepur Road, Lahore. Ph: 042-5811952-59, 5822853, Fax: 042-5822682, 5810156	


SL Series	WB Series	6 Series
2009	20145JF	6200
2010	20165	6300
2012	2017	6400
2300JF	20175	
2500JF	20185	




Slim Line Series
Crystal




Slim Line Series
Star Plus



Slim Line Series
Premier



6 Series



Wide Body Series

برائے مہربانی ریفریجریٹرز کو استعمال کرنے سے پہلے تمام ہدایات اور احتیاطی تدابیر کا اچھی طرح مطالعہ کر لیں۔

معزز صارف

صفحہ نمبر

- 01 ریفریجریٹر ماڈلز اور سیریز
- 03 ریفریجریٹر پارٹس کی شناخت
- 04 ریفریجریٹر کی تنصیب
- ریفریجریٹر کا توازن
ذاتی تحفظ
- 05 آغاز
- خوراک محفوظ کرنا
وہیجینیل / فروٹ کمپارٹمنٹ
- 06 آئس کیوبز کی تیاری
- 06 ٹمپریچر کنٹرول
- 07 فراسٹ صاف کرنے کا طریقہ
- ڈبل ڈور ریفریجریٹر
سنگل ڈور ریفریجریٹر
- 09 عمومی حفاظت اور صفائی
- 10 خوشبو / مہک زائل کرنے کا آلہ
- 11 عمومی نقصان کا تدارک
- 13 حفاظتی تدابیر

ہم آپ کے انتخاب پر آپ کو مبارکباد پیش کرتے ہیں اب آپ PEL پروڈکٹ کے معزز صارف ہیں اور آپ ان لاکھوں صارفین میں شامل ہو چکے ہیں جو پچھلے 50 سال سے PEL کی مصنوعات سے مستفید ہو رہے ہیں۔

ہم آپ کو یقین دلاتے ہیں کہ PEL ریفریجریٹر اعلیٰ ٹیکنالوجی اور خوبصورتی کا شاہکار ہے جو پاکستان کے موسمی حالات کو مدنظر رکھ کر بنایا گیا ہے۔

PEL ریفریجریٹر کی امتیازی خصوصیات مثلاً اعلیٰ کارکردگی، پائیداری، مضبوطی اور بالخصوص بعد از فروخت خدمات کی سہولت اپنے صارفین کو پیش کرتے ہوئے فخر محسوس کرتے ہیں۔


برائے مہربانی وارنٹی کارڈ کو مکمل کر کے درج کئے گئے پتہ پر ارسال کر دیں تاکہ وارنٹی کی رجسٹریشن کی جا سکے۔

اس کتابچے کا بغور مطالعہ کریں۔ اس میں ریفریجریٹر کی تنصیب، استعمال اور آئندہ سالوں میں دیکھ بھال کے لیے مکمل معلومات فراہم کی گئی ہیں تاکہ آئندہ سالوں میں ریفریجریٹر بعد از استعمال بھی اپنی اصلی حالت میں رہے۔


ہم آپ کو PEL فیملی کی طرف سے خوش آمدید کہتے ہیں اور آپ کے لیے آئندہ سالوں میں آسودگی و اطمینان کی دعا کرتے ہیں جو کہ آپ کو PEL ریفریجریٹر سے میسر آئے گا۔

شکریہ

ریفریجریٹر پارٹس کی شناخت




نوٹ: مختلف ماڈلز میں مختلف پارٹس ہو سکتے ہیں



1 گتے کے ڈبے اور تمام تھر مو پور کے ٹکڑوں کو ریفریجریٹر سے علیحدہ کر لیں خاص طور پر کپریسر کے پیچھے لگے ہوئے تھر مو پور کو ضرور علیحدہ کریں۔ ریفریجریٹر کو سخت اور ہموار سطح یا لکڑی کی مضبوط چوکی پر رکھیں۔



2 بہترین کارکردگی کے لیے ریفریجریٹر کو ہوا دار جگہ پر رکھیں، اس کے نزدیک کسی قسم کی گرمی پیدا کرنے والی گھریلو مصنوعات یعنی چولہا، ہیٹر وغیرہ نہیں ہونی چاہیں۔ اسے تنگ کونوں میں، براہ راست سورج کی روشنی میں نصب کرنے سے پرہیز کریں۔



3 ریفریجریٹر کا توازن

3 کسی بھی ناہموار سطح پر ریفریجریٹر کو رکھنے کے لیے ریفریجریٹر کا توازن لیولنگ سکریو کے ذریعے درست کر لیں۔ ریفریجریٹر کو ہمیشہ تھوڑا سا پچھلی جانب جھکا کر رکھیں جیسا کہ دکھایا گیا ہے۔


4 ذاتی تحفظ کے لیے ریفریجریٹر کو ضرور ارتھ کریں۔ ریفریجریٹر کو ٹیلی فون کی تار، گیس پائپ لائن وغیرہ کے ساتھ بالکل ارتھ نہ کریں۔ ہمیشہ ریفریجریٹر کو صحیح طریقے سے ارتھ کریں۔



اہم بات : اگر دی گئی ہدایات کے مطابق عمل نہ کیا گیا تو ساخت کنندہ کسی قسم کے نقصان کا ذمہ دار نہ ہوگا۔


نوٹ : اصل پیکنگ کو سنبھال لیں تاکہ بعد ازاں نقل و حمل کی صورت میں کام آسکے۔

ریفریجریٹر کو ”آن“ کرنے سے پہلے اسے اندر سے صاف کر لیں۔ پلگ کرنے کے بعد دیکھیں کہ دروازہ کھلنے پر کیبنٹ کے اندر لائٹ جل رہی ہے۔ تھر موٹیٹ ناب کو پوزیشن ”8“ پر لے جائیں اور دروازے بند کر دیں ریفریجریٹر کو اسی حالت میں 2 سے 3 گھنٹے تک خالی چلنے دیں۔ اس کے بعد تھر موٹیٹ ناب کو میڈیم پوزیشن یعنی ”4“ پر لے آئیں اب یہ ہر قسم کی خوراک محفوظ کرنے کے لیے تیار ہے۔ گرم موسم میں تھر موٹیٹ ناب کی پوزیشن کو ”5“ یا ”6“ پر رکھیں۔



خوراک محفوظ کرنا

- 1 غذا کو پلاسٹک کے تھیلوں یا مضبوطی سے بند ہونے والے برتنوں میں رکھیں تاکہ دوسری غذا کی مہک اس میں شامل نہ ہو سکے۔
- 2 فریزر میں خوراک چھوٹے چھوٹے پیکٹ کی صورت میں محفوظ کریں تاکہ جلد جم سکے۔
- 3 گرم غذا اور مشروبات کو ریفریجریٹر یا فریزر کمپارٹمنٹ میں رکھنے سے پہلے ٹھنڈا کر لیں۔
- 4 غذا کو اس ترتیب سے رکھیں تاکہ ٹھنڈی ہو ا کمپارٹمنٹ میں آسانی سے گردش کر سکے، گرڈ شیلف کو پلاسٹک شیٹ / امیٹ سے کبھی نہ ڈھانپیں۔
- 5 ریفریجریٹر کمپارٹمنٹ غذا اور مشروبات کو مناسب حد تک ٹھنڈا رکھ سکتا ہے۔
- 6 گوشت، سبزیاں اور پھل وغیرہ ریفریجریٹر میں رکھنے سے پہلے دھو کر خشک کر لیں۔



فروت / ویکمیل کمپارٹمنٹ



یہ کمپارٹمنٹ پھلوں اور سبزیوں کی نمی کو برقرار رکھتا ہے تاکہ ان کی تازگی دیر تک قائم رہ سکے۔

احتیاط : گوشت کو ایک مرتبہ ڈی فراسٹ کرنے کے بعد دوبارہ فریز نہ کریں یہ مضر صحت ہو سکتا ہے۔

نوٹ : زیادہ دیر تک بجلی فیمل ہونے کی صورت میں محفوظ کی گئی خوراک کو 6 سے 8 گھنٹوں کے اندر اندر استعمال کر لیں۔

آئس کیوبز کی تیاری

جب آپ آئس کیوبز بنانا چاہتے ہوں تو آئس ٹرے کیرنر کا مکمل سیٹ باہر نکال کر اس میں پانی بھر لیں اور واپس اپنی جگہ پر لگا دیں۔
جب آئس کیوبز بن جائیں تو ٹرے کی ناب کو کلاک وائز گھمائیں تاکہ آئس کیوبز آئس ٹرے سے علیحدہ ہو جائیں۔
اس کو ایک مرتبہ پھر گھمائیں تاکہ کیوبز نیچے آئس کیوب کنٹینر میں گر جائیں۔



احتیاط : یہ اطمینان کر لیں کہ آئس کیوب کنٹینر آئس ٹریز کے نیچے موجود ہے۔

نوٹ : آئس ٹرے کا ڈیزائن مختلف ماڈلز میں مختلف ہو سکتا ہے۔

ٹیمپریچر کنٹرول


ریفریجریٹر کے اندرونی درجہ حرارت کا اس بات سے گہرا تعلق ہے کہ ریفریجریٹر کا دروازہ دن میں کتنی مرتبہ کھلتا ہے اور اس میں رکھی گئی اشیاء کی مقدار کتنی ہے لہذا تھرمو اسٹیٹ ناب کو اس کے مطابق ایڈجسٹ کریں۔ ریفریجریٹر کے لئے درج ذیل ٹیبل ملاحظہ کریں۔

پوزیشن "0"	بند حالت	پوزیشن "0"
پوزیشن "2-3"	جب باہر کا درجہ حرارت 15°C سے کم ہو	سر موسم میں
پوزیشن "4"	جب باہر کا درجہ حرارت 15°C سے 30°C تک ہو	معتدل موسم میں
پوزیشن "5-6"	جب باہر کا درجہ حرارت 30°C سے 40°C تک ہو	زیادہ گرم موسم میں
پوزیشن "7-8"	جب باہر کا درجہ حرارت 40°C سے زیادہ ہو	مخصوص حالات یا انتہائی گرم موسم میں



فراست صاف کرنے کا طریقہ

ریفریجریٹر کی بہترین کارکردگی کیلئے ڈی فراسٹنگ ضروری ہے جب فریزر کی سطح پر برف کی تہہ 5 سے 8 ملی میٹر یا اس سے زیادہ ہو جائے تو اس کو ڈی فراسٹ کرنا ضروری ہے۔



سنگل ڈور ریفریجریٹر

اس ریفریجریٹر میں تھرمواسٹیٹ کے ساتھ ایک ڈی فراسٹنگ پش بٹن دیا گیا ہے۔

ریفریجریٹر کی فراست کو صاف کرنے کے لئے درج ذیل ہدایات پر عمل کریں۔

1 غذا اور آئس ٹرییز فریزر کمپارٹمنٹ سے باہر نکال لیں۔

2 تھرمواسٹیٹ کے پش بٹن کو دبا دیں۔ ریفریجریٹر اور فریزر کا دروازہ ڈی فراسٹنگ کے لیے کھول دیں۔


3 برف کے پگھلنے تک انتظار کریں اور پھر اسے احتیاط سے آئس سکریپر کی مدد سے صاف کر دیں۔

4 ڈریپ ٹرے پانی سے بھر جائے تو اسے نکال کر پانی پھینک دیں اور اسے واپس اپنی جگہ پر لگا دیں۔

یہ عمل ڈی فراسٹنگ کے مکمل ہونے تک جاری رکھیں۔

5 جب ڈی فراسٹنگ مکمل ہو جائے گی تو پش بٹن اپنی اصل حالت میں واپس آجائے گا۔

6 اب خوراک واپس رکھ کر دروازے بند کر دیں۔



احتیاط: برف کو چاقو یا کسی تیز دھار آلے سے صاف نہ کریں اور ہمیشہ گھنٹی کا فراہم کردہ آئس سکریپر ہی استعمال کریں۔

نوٹ: مکمل ڈی فراسٹنگ ہر ماہ بعد کر لینا چاہئے۔

فراسٹ صاف کرنے کا طریقہ

ڈبل ڈور ریفریجریٹر

ریفریجریٹر کمپارٹمنٹ

اس کمپارٹمنٹ میں آٹومیک ڈی فراسٹنگ سسٹم موجود ہے جو ضرورت پڑنے پر خود بخود ریفریجریٹر کو ڈی فراسٹ کر دیتا ہے۔

فریزر کمپارٹمنٹ

فریزر کمپارٹمنٹ کو ڈی فراسٹ کرنے کے لئے درج ذیل ہدایات پر عمل کریں۔

1. تھرموسٹیٹ ناب کو پوزیشن "0" پر لے جائیں، پلگ نکال دیں اور فریزر کا دروازہ ڈی فراسٹنگ کے لئے کھول دیں۔

2. فریزر سے غذا، آئس ٹریز سیٹ، آئس کیوب کنٹینر اور گرڈ شیلفز وغیرہ نکال لیں۔

3. جب برف پگھل جائے تو اسے آئس سکرپری کی مدد سے صاف کر لیں۔

4. جب برف صاف ہو جائے تو احتیاط سے پروٹیکشن پلیٹ باہر نکال کر ڈرین پلگ نکال لیں تاکہ برف کا پانی نکل جائے۔

5. **(صرف 6 سیریز کیلئے)** ڈرین کے بالکل نیچے برتن رکھیں تاکہ ڈی فراسٹنگ پانی اس میں اکٹھا ہو جائے۔

سلم لائن سیریز اور وائنڈ باؤی سیریز میں برف کا پانی ڈرین ہو کر کنڈنسیٹ ٹرے میں جمع ہو جائے گا جو کہ




کیبنٹ کے پیچھے کمپرہس کے اوپر لگی ہوئی ہے۔ صفحہ نمبر 9 پر ملاحظہ کریں۔

6. اب کمپارٹمنٹ کو نرم خشک کپڑے سے صاف کر لیں۔ ڈرین پلگ واپس لگا کر اس کے اوپر پروٹیکشن پلیٹ رکھ دیں۔

7. فریزر کا دروازہ بند کر لیں اور غذا واپس رکھنے سے قبل ریفریجریٹر کو تقریباً ایک گھنٹہ تک خالی چلنے دیں۔

احتیاط: برف کو چاقو یا کسی تیز دھارا آلے سے صاف نہ کریں اور ہمیشہ کپنی کا فراہم کردہ آئس سکرپری ہی استعمال کریں۔


نوٹ: مکمل ڈی فراسٹنگ ہر ماہ بعد کر لینا چاہئے۔



اس ریفریجریٹر کو کسی خاص دیکھ بھال کی ضرورت نہیں۔ لیکن یہ تاکید کی جاتی ہے کہ آپ ریفریجریٹر کو صاف رکھیں۔ اس سے ریفریجریٹر کی عمر بڑھ جاتی ہے۔




- 1 صفائی کرنے سے قبل ہمیشہ ریفریجریٹر کا پلگ نکال دیں۔ صفائی کیلئے مائع کلیینرز (کیمیکل) استعمال نہ کریں۔
 - 2 ریفریجریٹر کی اندرونی یا بیرونی صفائی کے لیے براہ راست پانی کا استعمال ہرگز نہ کریں۔
- پانی ریفریجریٹر کے مختلف حصوں کو خراب کرتا ہے اور بجلی کا جھٹکا لگنے کا باعث بن سکتا ہے۔



اندرونی صفائی

1/9 فیصد سفید سرکہ پانی میں ڈال کر محلول تیار کر لیں۔ اس محلول کو فوم / سپونج کی مدد سے تمام حصوں کو اچھی طرح صاف کر لیں۔ آخر میں تمام اشیاء کو اچھی طرح خشک کرنے کے بعد اپنی جگہ پر نصب کر دیں۔



ڈور گیس کٹ

گیس کٹ کو اچھی طرح سے صاف کریں تاکہ اس کے چسپنے کی صلاحیت برقرار رہے۔


نوٹ: تمام پارٹس کو ان کی اصل جگہ پر لگانے سے پہلے اچھی طرح خشک ضرور کر لیں۔

بیرونی صفائی

ریفریجریٹر کی بیرونی سطح کی صفائی کیلئے ہلکا نم اور نرم کپڑا استعمال کریں۔

کنڈینسر


ریفریجریٹر کنڈینسر کو برش یا ویکیم کلیینر کی مدد سے صاف کریں۔ اس سے ریفریجریٹر کی کارکردگی بہتر رہتی ہے۔



خوشبو/ مہک ختم کرنے کا آلہ


خوشبو/ مہک ختم کرنے کا آلہ ریفریجریٹر سے آنے والی بو کا خاتمہ کرتا ہے۔

تھرموسٹیٹ بکس (6 سیریز)



احتیاط : ایسی اشیاء جو خوشبودار ہوں یا جن کی خوشبو آسانی سے دوسری اشیاء میں منتقل ہو سکتی ہو۔ انہیں لازماً بند ڈبوں یا بند برتنوں میں رکھیں۔

تھرموسٹیٹ بکس (سلیم لائن اور وائڈ باڈی سیریز) ڈی اوڈر رائزر کور




نوٹ : ڈی اوڈر رائزر ریفریجریٹر میں محفوظ کی گئی غذا کیلئے نقصان دہ نہیں ہے۔

خاص بات : اگر آپ ایک ہفتہ سے زائد عرصہ کے لئے ریفریجریٹر استعمال نہیں کرنا چاہتے تو اس کا پلگ نکال دیں۔ تمام کھانے پینے کی اشیاء نکال کر ریفریجریٹر اور فریزر کیبنٹ کو اچھی طرح صاف کریں اور دروازے کھلے رکھیں۔ دروازے بند رکھنے کی صورت میں ریفریجریٹر کے اندر بو پیدا ہو سکتی ہے۔


علامات	دجومات	حل
جب ریفریجریٹر بالکل کام نہ کرے -	بجلی کے کنکشن یا بجلی کا فیئل ہونا - تھر موٹیٹیٹ ناب کا پوزیشن '0' پر ہونا -	پلگ چیک کریں اور اسے ٹھیک طریقے سے لگائیں - تھر موٹیٹیٹ پوزیشن کو صحیح کریں - صفحہ نمبر 6 ملاحظہ کریں -
جب ریفریجریجریٹر صحیح طریقے سے کام نہ کرے -	ریفریجریجریٹورسورج کی روشنی میں، ہیٹر یا چولہے کے قریب ہے - ریفریجریجریٹورسورج سے ہر سمت سے مناسب فاصلے پر نہیں ہے - تھر موٹیٹیٹ ناب '1' یا '2' پر ہے - ریفریجریجریٹورسورج میں گرم اشیاء یا بہت زیادہ اشیاء ہیں - ریفریجریجریٹورسورج کا دروازہ بار بار کھولا جا رہا ہے یا دیر تک کھلا رہا ہے -	اس جگہ کا معائنہ کریں جہاں ریفریجریجریٹر رکھا گیا ہے - صفحہ نمبر 4 ملاحظہ کریں تھر موٹیٹیٹ کی پوزیشن چیک کریں - صفحہ نمبر 6 ملاحظہ کریں محفوظ شدہ اشیاء کی حالت اور مقدار چیک کریں - صفحہ نمبر 5 ملاحظہ کریں دروازہ بند رکھیں اور اسے حسب ضرورت ہی کھولیں -
جب پانی ریفریجریجریٹر سے باہر بہ رہا ہو -	پانی کے نکاس کی نالی بند ہوگئی ہے - پھل اور سبزیوں کے کمپارٹمنٹ کے نیچے پانی جمع ہو گیا ہے - ریفریجریجریٹورسورج کا لیول ٹھیک نہیں ہے -	پانی کے نکاس کی نالی چیک کریں اور کائی وغیرہ صاف کریں - پھل اور سبزیوں کے کمپارٹمنٹ کو باہر نکالیں اور خشک کپڑے سے پانی کو صاف کریں - لیولنگ سکریو سے ریفریجریجریٹورسورج کا توازن درست کریں -

علامات	دجومات	حل
جب ریفریجریٹر بہت آواز دے رہا ہو -	ریفریجریٹر غیر ہموار جگہ پر نصب ہے - لیولنگ سکریو سے لیول کو ٹھیک نہیں کیا گیا - ریفریجریٹر پچھلی دیوار سے ٹکرا رہا ہے - کمپرےسریٹو بڑا ایک دوسرے کو چھو رہی ہیں -	انسٹالیشن کی جگہ کو چیک کریں - صفحہ نمبر 4 ملاحظہ کریں لیولنگ سکریو کو ایڈجسٹ کریں - صفحہ نمبر 4 ملاحظہ کریں ریفریجریٹر کو دیوار سے مناسب فاصلہ پر رکھیں - صفحہ نمبر 4 انھیں احتیاط سے علیحدہ کر دیں
جب ریفریجریٹر کمپارٹمنٹ میں غذا جم رہی ہو -	تھرمو سٹیٹ ناب کی پوزیشن 7 یا 8 پر ہے - بیرونی درجہ حرارت بہت کم ہے -	تھرمو سٹیٹ پوزیشن کو صحیح کر لیں - صفحہ نمبر 6 ملاحظہ کریں
جب ریفریجریٹر کی اندرونی کینیٹ میں شبنم کی طرح کے قطرے موجود ہوں -	ریفریجریٹر کا دروازہ بار بار کھولا جا رہا ہے یا دیر تک کھلا رہا ہے - ہوا میں نمی کی موجودگی یا مومن سون موسم -	دروازہ بند رکھیں اور اسے حسب ضرورت ہی کھولیں - خشک کپڑے سے اسے صاف کر لیں -
بیرونی سطح پر شبنم کی طرح کے قطرے نظر آ رہے ہوں -	ہوا میں نمی کی موجودگی یا مومن سون موسم -	خشک کپڑے سے اسے صاف کر لیں -
جب ریفریجریٹر کی بیرونی سطح گرم ہو -	بلٹ ان ہیٹنگ سسٹم کی وجہ سے کینیٹ گرم محسوس ہو رہی ہے	یہ عام بات ہے کسی حل کی ضرورت نہیں -




زیادہ دیر کے لئے دروازہ کھلا نہ رہنے دیں کیونکہ
یہ ریفریجریٹر کی کارکردگی کو متاثر کر سکتا ہے۔


ایکسٹینشن کی تار استعمال نہ کریں کیونکہ اس سے
آگ لگ سکتی ہے یا بجلی کا جھٹکا لگ سکتا ہے۔



ایتھر یا ہینزین جیسے خطرناک کیمیکل ریفریجریٹر میں
کے اندر نہ رکھیں۔ فیومز غذا کو نقصان پہنچانے
کے علاوہ دھماکے کا سبب بن سکتے ہیں۔



اگر ریفریجریٹر صحیح کام نہیں کر رہا تو اسے استعمال نہ
کریں اس کی پاور سپلائی کو بند کر دیں اور PEL
کسٹمر سروس سینٹر یا PEL آتھورائزڈ ورکشاپ
سے رجوع کریں۔



ریفریجریٹر پر براہ راست پانی نہ ڈالیں یہ الیکٹرک
انسولیشن کو خراب کرتا ہے اور بجلی کے جھٹکے کا باعث
بن سکتا ہے۔

بجلی کی تار پر کوئی چیز نہ رکھیں اور تار چلنے والے
راستے کے درمیان نہ آئے۔



ریفریجریٹر کے قریب فوری آگ پکڑنے والی
اشیاء کا ہرگز سپرے نہ کریں۔



چھوٹے بچوں کو ریفریجریٹر کے دروازے
سے جھولنے مت دیں اس سے بچہ زخمی ہو
سکتا ہے یا اپلائنس کو نقصان پہنچ سکتا ہے۔

احتیاط: آگ یا بجلی کے جھٹکے سے بچنے کے لئے ریفریجریٹر کو بارش، نمی اور گیلی جگہ پر نہ رکھیں۔