

Boost Mobile[®]

i855 Phone

User's Guide

DECLARATION OF CONFORMITY

Per FCC CFR 47 Part 2 Section 2.1077(a)



Responsible Party Name: Motorola, Inc.

Address: 8000 West Sunrise Boulevard
Plantation, FL 33322 USA

Phone Number: 1 (800) 453-0920

Hereby declares that the product:

Product Name: 855

Model Number: H65XAN6RR4AN,
H65XAN6RR4DN

Conforms to the following regulations:

FCC Part 15, subpart B, section
15.107(a), 15.107(d) and section
15.109(a)

Class B Digital Device

As a personal computer peripheral, this device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference,

and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Getting Started

Introduction

Welcome to Boost Mobile®

With Boost Mobile you pay up front, stay in control of your monthly costs, and get all the mobile freedom you want. No contracts, no bills, no credit checks. Our phones have the latest features including Nationwide Boost™ Walkie-Talkie, Wireless Web, Instant Messaging, Text and Multi-Media Messaging and GPS technology.

Make your phone all your own

Boost Mobile® offers the best in wireless entertainment services such as Boost™ Call Tones, Instant Messaging, and Boost™ Loopt as well as the latest games, applications, real music ringtones, wallpapers and more.

Two easy ways to purchase content and get information on the latest services:

- From your handset: **boostLIVE** from the Main Menu
- On the web: Check out **boostmobile.com**

Purchases are deducted from your Boost Mobile account. No credit card needed.

Re-Boost™

You can recharge your account directly from your handset using the **Re-Boost** menu option. On your phone, launch the service from the Main Menu. You will then be able to log on and recharge your account using your credit card or Re-Boost® Card. You can also view

your account balance and call credit expiration date. The account pass code is the same one that you use to access your account.

Important: Before using your phone please read the "Terms and Conditions of Service", "Driving Tips" and "Safety and General Information".

Instant Re-Boost™

You can recharge instantly by dialing the letters A-D-D (2-3-3) from your mobile phone and press Send. You are not required to enter your personal telephone number (PTN) or passcode.


If you select Prepaid Card, you will be asked to enter the 14-digit card number printed on the Re-Boost® Card. If you've selected credit card, you will be asked simply to confirm your purchase. You will need to have a credit card already on file to use it for purchasing airtime. Call 1-888-BOOST-4U to have your credit card added to your account.

Boost Customer Care


1-888-BOOST-4U (1-888-266-7848) or dial 6-1-1 from your i855 phone.

Check it out


Introducing your Motorola i855 wireless phone. Here is a quick anatomy lesson.




Home Screen





② Press the  key to open the **Main Menu** screen

① Press and hold the **Power Key**  for a few seconds, or until the screen lights up, to turn on your phone.

Main Menu



③ Press the Navigation Key **up, down, left or right**  to highlight a menu feature.

④ Press the  key to select.

Motorola, Inc.
Consumer Advocacy Office
1307 East Algonquin Road
Schaumburg, IL 60196

www.hellomoto.com

1-800-331-6456 (United States)
1-888-390-6456 (TTY/TDD United States for hearing
impaired)
1-800-461-4575 (Canada)

Product Support:

www.motorola.com/iden/support

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

© Motorola, Inc., 2007.

Manual Number NNTN7304A
Software Version Number: R3D.01.00
CP Version: 5D.00/19.00
USR Version: U3DC.27.23








Contents






Getting Started	1	Main Attractions	19	Customize	40
Introduction	1	Multi-Media		Ringtones	40
Re-Boost™	1	Messages	19	Time & date	41
Instant Re-Boost™	2	Walkie-Talkie calls	25	Change the look of your phone	42
Boost Customer Care	2	Walkie-Talkie send	26	Hide or show location information	43
Check it out	3	Camera	27	Calls	44
Menu Map	8	Media Center	29	Turn off a call alert	44
Use and Care	10	DRM Items	30	Recent calls	44
Essentials	11	Pictures	30	Redial	44
About this Guide	11	Basics	34	Return a call	44
SIM chip	12	Display	34	Caller ID	45
Battery	14	Text entry	35	Emergency calls	45
Turn it on & off	17	Volume	37	International calls	46
Make a call	17	Navigation key	38	Speed dial	46
Answer a call	17	Hands-free	38	Voicemail	47
Store a phone number	17	Codes & passwords	38		
Call a stored phone number	18	Lock & unlock phone	38		
Your phone number	18	Boost Mobile® Services 39			
		Accessories	39		
		Wireless local number portability: Bringing your phone number from another carrier	39		






Other Features	48
Advanced calling.	48
Contacts	48
Datebook.	49
GPS	50
Hands-free	52
Messages	53
Personalize	54
Security.	55
Safety and General	
Information	57
Motorola Limited	
Warranty for the United	
States and Canada	64
Hearing Aid	
Compatibility	69
Information From the	
World Health	
Organization	71
California Perchlorate	
Label	73
Privacy and Data	
Security	74
Smart Practices While	
Driving	75
Index	77

Menu Map

Main Menu

-  **Re-Boost**
-  **Web**
-  **boostLIVE**
-  **Java Apps**
-  **Ringtones**
 - Buy Tones
 - VibeAll
 - [available ring-tones]
 - Vibrate
 - Silent
-  **Camera**
-  **Media Center**
 - Media: All
 - Media: Pictures
 - Media: Audio
-  **Recent Calls**
-  **Settings**
 - (see next page)
-  **My Info**
 - My Name
 - Line 1
 - Walkie-Talkie #
 - Group ID
 - Carrier IP
 - IP1 Address
 - IP2 Address
 - Circuit Data
-  **Contacts**
 - [New Contact]

-  **Messages**
 - [Create Message]
 - Voice Mail
 - Inbox
 - Drafts
 - Sent Items
 - Net Alert
 - SMS
-  **Datebook**
-  **Profiles**
 - [New Profile]
 - Standard
 - Car
 - at Work/in Class
 - At Concert
 - On a Date
 - using Headset
 - Rec WT Only
 - Rec Cntcs Only
-  **Voice Notes**
 - [New VoiceRec]
-  **Call Forward**
 - Forward: All Calls
 - To: On/Off

-  **Memo**
-  **Shortcuts**
 - [New Entry]
 - 1) Shortcuts
 - 2) Cntcs[New Contact]
 - 3) Recent Calls
 - 4) Contacts
 - 5) Re-Boost
 - 6) Messages
 - 7) VoiceRecord
 - 8) Web
 - 9) Ring-tones
-  **Call Timers**
 - Last Call
 - Phone Reset
 - Phone Lifetime
 - Walkie-Talkie Reset
 - Walkie-Talkie Lifetime
 - Circuit Reset
 - Circuit Lifetime
 - Kbytes Reset
-  **GPS**
 - Position
 - Privacy
 - Interface
-  **Call Alert**

This is the standard main menu layout. Your phone's menu may be a little different.

Settings Menu

Display/Info

- Wallpaper
- Text Size
- Theme
- Home Icons
- Backlight
- Clock
- Menu View
- Large Dialing
- Language

Phone Calls

- Any Key Ans
- Auto Redial
- Call Waiting
- Auto Ans
- Minute Beep
- Call Duration
- TTY
- Notifications

WT Options

- Tkgrp Silent
- Tkgrp Area
- One Touch WT
- Alert Type
- WT Send Alert

Personalize

- Menu Options
- Up Key
- Down Key
- Left Key
- Right Key
- Center Key
- Left Softkey
- Right Softkey
- Power Up

Volume

- Line 1
- Messages
- Earpiece
- Speaker
- Keypad
- Java Earpiece
- Java Speaker
- Data

Security

- Phone Lock
- Keypad Lock
- SIM PIN
- GPS PIN
- Change Passwords

Advanced

- Alert Timeout
- Headset/Spkr
- Disco Lights
- Connectivity
- Reset Defaults
- Return to Home
- Airplane Mode
- Baud Rate

Use and Care

To care for your Motorola phone, please keep it away from:



liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture.



dust and dirt

Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



extreme heat or cold

Avoid temperatures below -10°C/14°F or above 45°C/113°F.



cleaning solutions

To clean your phone, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



microwaves

Don't try to dry your phone in a microwave oven.



the ground


Don't drop your phone.

Essentials


CAUTION: Before using the phone for the first time, read the *Important Safety and Legal Information* included in the gray-edged pages at the back of this guide.



About this Guide

This guide shows how to locate a menu feature as follows:

Find it:  > **Settings.**

This means that, from the home screen:

- 1 Press the *menu button*  to open the main menu.

- 2 Press the *navigation key*  to scroll to **Settings**, and press the *center key*  to select it.

symbols



This means a feature is network/subscriber dependent and may not be available in all areas. Contact your service provider for more information.




This means a feature requires an optional accessory.

SIM chip

Your Subscriber Identity Module (SIM) chip can be found attached to a piece of plastic about the size of a credit card inside the “Starter Kit” that came with your phone. Your SIM chip contains personal information like your phone number and phonebook entries.

To activate your phone, you will need the SIM ID and the Activation Number located on the back of the plastic.




Caution: Don't bend or scratch your SIM chip. Keep it away from static electricity, water, and dirt.

Installing the SIM chip


Turn off your phone and remove your battery before you install or remove a SIM chip.

- 1 Open the SIM chip holder.




Pop out the SIM chip from the plastic card and insert it into the back of your phone as described next.

- 2 Carefully slide your SIM chip into the SIM chip holder.



- 3 Close the SIM chip holder.



Warning: To avoid loss or damage, do not remove your SIM chip from your phone unless absolutely necessary.

Battery

Battery Use & Battery Safety

- Motorola recommends you always use Motorola-branded batteries and chargers. The warranty does not cover damage caused by non-Motorola batteries and/or chargers. Caution: Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard. Improper battery use, or use of a damaged battery, may result in a fire, explosion, or other hazard.
- Battery usage by children should be supervised.
- Important: Motorola mobile devices are designed to work best with qualified batteries. If you see a message on your display such as Invalid Battery or

Unable to Charge, take the following steps:

- Remove the battery and inspect it to confirm that it bears a Motorola “Original Equipment” hologram;
- If there is no hologram, the battery is not a qualified battery;
- If there is a hologram, replace the battery and retry charging it;
- If the message remains, contact a Motorola Authorized Service Center.
- New batteries or batteries stored for a long time may take more time to charge.
- **Charging precautions:** When charging your battery, keep it near room temperature. Never expose batteries to temperatures below 0°C (32°F) or above 45°C

(113°F) when charging. Always take your mobile device with you when you leave your vehicle

- When storing your battery, keep it in a cool, dry place.
- It is normal over time for battery life to decrease, and for the battery to exhibit shorter runtime between charges or require more frequent or longer charging times.
- **Avoid damage to battery and mobile device.** Do not disassemble, open, crush, bend, deform, puncture, shred, or submerge the battery or mobile device. Avoid dropping the battery or mobile device, especially on a hard surface. If your battery or mobile device has been subjected to such damage, take it to a Motorola Authorized Service Center before using. **Do not**

attempt to dry it with an appliance or heat source, such as a hair dryer or microwave oven.

- **Use care when handling a charged battery**—particularly when placing it inside a pocket, purse, or other container with metal objects. Contact with metal objects (e.g., jewelry, keys, beaded chains) could complete an electrical circuit (short circuit), causing the battery to become very hot, which could cause damage or injury.

Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling center for proper battery disposal.




Never dispose of batteries in a fire because they may explode.


Battery installation

Make sure your phone is powered off.


- 1 Pull down the battery door latch located at the bottom of the battery door.




- 2 Allow the battery door to pop up, slide it forward, and remove it from the back of your phone.



- 3 Insert the battery into the battery area and press it down to secure it as shown in the image below.




- 4 Replace the battery door and press it gently until you hear a click.



Battery charging

New batteries are not fully charged. Plug the battery charger into your phone and an electrical outlet. Your phone might take several




seconds to start charging the battery. Your display shows **Charge Complete** when finished.

When you charge the battery, the battery level indicator at the upper right of the screen shows charging progress. At least one segment of the indicator must be visible to ensure full phone functionality while charging.

Motorola batteries have circuitry that protects the battery from damage from overcharging. Of course, unplugging the charger from the wall will avoid current drain.


Turn it on & off


To turn on your phone, press and hold  for a few seconds or until the display turns on. If prompted, enter your four-digit unlock code.




To turn off your phone, press and hold  for three seconds.


Make a call

Enter a phone number and press  to make a call.

To hang up press .

Answer a call


When your phone rings and/or vibrates press  to answer.

To hang up press .

Store a phone number

You can store a phone number in your **Contacts**:

Find it:  > **Contacts** > **[New Contact]**


- 1 Enter a name and other details for the phone number. To select a highlighted item, press .

2 Press **Save** to store the number.

To edit or delete a **Contacts** entry, see page 48.


Shortcut: From the home screen, press **Contcs**.

Call a stored phone number

Find it:  > **Contacts**.


1 Scroll to the **Contacts** entry.

Shortcut: In **Contacts**, press keypad keys to enter the first letters of an entry you want.

2 Press  to call the entry.

Your phone number

Find it:  > **My Info**.

Tip: Want to see your phone number while you're on a call? Press  > **My Info**.

Main Attractions

Multi-Media Messages



You can send and receive messages that may include text, pictures and audio recordings.

Create a message

Find it:  > **Messages** > **[Create Message]**

- 1 Press keypad keys to enter text on the page. For details about text entry, see page 35.
- 2 To insert a picture, sound, or video on the page, select **Attach**. Select the file type and select an existing file or create a new one.

Note: A message must contain a recipient and message text.

Optional fields are visible when you select **More**.

- 3 Select **Send**.

Shortcut: From the home screen, press **Mesg** > **[Create Message]**

Note: You can also create a message from **Contacts** and **Recent Calls**.

Reply to a message

- 1 View the message.
- 2 To reply to the sender only, press **Reply** or **Reply All**.
- 3 Select **[Create Reply]** or a short phrase from the list.
- 4 Edit any message fields you want to change.
- 5 Select **Send**.

Drafts

You can save an unsent message as a draft. Once it is saved, you can view, edit, send, or delete it.

save a draft

Find it: [Menu] > **Save In Drafts**

view, edit, send, or delete a draft

Find it: [Menu] > **Messages > Drafts**

- Press OK to view and/or edit the draft.
- Press [Menu] > **Send** to send the message as is.
- Select **Delete** to delete the selected draft only or press [Menu] > **Delete All** to delete all drafts in the drafts folder.

Sent items

Messages you have sent or tried to send are stored in **Sent Items**.

Forward sent items

You can forward a sent item to a new recipient.

Find it: [Menu] > **Messages > Sent Items**.

- 1 Scroll to the message you want to forward.
- 2 Press [Menu] > **Forward**.
- 3 Edit and send your message.

Resend

If a message was not successfully sent from your handset, you can try to resend it.

Find it: [Menu] > **Messages > Sent Items**.

- 1 Scroll to the message you want to resend.
- 2 Press [Menu] > **Resend**.

Note: If your message was sent successfully, **Resend** will not appear as an option.


Check delivery status

If a message was successfully sent and you set the message to give a report confirming delivery, you can check the delivery status:


Find it:  > **Messages** > **Sent Items**.

- 1 Scroll to the message you want to view.
- 2 Press  > **Delivery Status**.

Delete a message

- 1 Scroll to the message you want to delete.
- 2 Press  > **Delete**.

Receive a message

When you receive a message, your phone plays an alert and the display shows New Message with a message indicator such as .

To view the message:

- 1 Press .

View received messages from the message center


- 1 Press  > **Messages** > **Inbox**.
- 2 Select the message.

If the message has not yet been downloaded from the message server, it is downloaded now.

Delete unread messages


- 1 Scroll to the message you want to delete.
- 2 Press **Delete**.

Forward a message

- 1 Press  > **Forward**.
- 2 Create and send your message. Embedded objects and attachments are included when you forward a message.

Lock and unlock messages


Locked messages cannot be deleted until you unlock them.

- 1 View the message you want to lock or unlock.
- 2 Press .
- 3 Select **Lock Message** or **Unlock Message**.

Call a number in a message

If a message you receive contains a phone number, Walkie-Talkie number, or Talkgroup ID in the From field, the To field, the Cc field, the subject line, or the body of the message, you can call or send a call alert to that number.


Send a call alert

- 1 View the message.
- 2 Highlight the Walkie-Talkie number or Talkgroup ID you want to alert.
- 3 Press .

- 4 Select **Alert**.


- 5 Press the WT button.

Store message information to contacts

- 1 View the message.
- 2 Highlight the number or email address.
- 3 Press .
- 4 Select **Save Number** or **Save Email**.
- 5 To store the number or email address as a new entry, select **[New Contact]**.
To store the number or email address to an existing entry, select the entry.
- 6 Press **Save**.


Go to a website

If a message contains one or more website URLs, you can go to that website.

- 1 View the message.
- 2 Highlight the website address.
- 3 Press .
- 4 Select **Go To Website**.

Note: The entire address must appear in the message.


Save an embedded picture or audio recording

- 1 View the message.
- 2 Highlight the item you want to save.
- 3 Press .
- 4 Select **Save Picture** or **Save Audio**.

The item will save in the default storage location.


Note: Some types of pictures and audio recordings can be viewed or played, but not saved.

Delete an embedded picture or audio recording

- 1 View the message.
- 2 Highlight the picture or audio recording.
- 3 Press .
- 4 Select **Delete Picture** or **Delete Audio**.

Note: You may save or delete pictures and audio recordings from slide shows individually as you view or listen to them.


Save attachments

- 1 View the message.
- 2 Highlight the attachment.
- 3 Press .
- 4 Select **Save Attachment**.


Selected items save to the default storage location.

Note: Some types of pictures and audio recordings can be viewed or played, but not saved.


Delete attachments

- 1 View the message.
- 2 Highlight the attachment.
- 3 Press .
- 4 Select **Delete Attachment**.

Save a picture


- 1 View the slide show.
- 2 When the picture you want appears, press .
- 3 Select **Save Picture**.

Save audio



- 1 View the slide show.
- 2 Press .
- 3 Select **Save Audio**.

- 4 If the slide show contains more than one audio recording, select the item you want from the list.

Delete a slide show

- 1 Highlight or view the slide show.
- 2 Press .
- 3 Select **Delete Slideshow**.

Message transmission

After you start to send a message you have created or start to download a message you have been sent, you can still stop the message transmission from being completed by pressing  or .

Customize message settings

Find it:  > **Messages** >  > **Setup**

Friendly Name — Your friendly name is the name displayed in the From field on other iDEN handsets when they receive messages from you.

Signature — Your signature is inserted at the end of all messages you create. You can edit the text before sending the message.

Quick Notes — Lets you create new Quick Notes and edit or delete Quick Notes you have created.

Replies — Lets you create new reply phrases and edit or delete reply phrases you have created.

Cleanup — Controls how long messages remain in the Inbox and Outbox before they are deleted.

Memory Size — Shows you how much used, free, and total memory you currently have on the phone.

Walkie-Talkie calls

With Boost™ Walkie-Talkie calls, you use your phone as a long-range, digital walkie-talkie.

Every Walkie-Talkie number has 3 parts—an area ID, a network ID, and a member ID—with an asterisk between each of these parts. For example: 999*999*9999.

When you place a WT call, you must enter the whole Walkie-Talkie number including the asterisks.

Make Walkie-Talkie calls:



- 1 From the home screen enter the Walkie-Talkie number you want to call, or if you have stored contacts with Walkie-Talkie numbers, browse your contacts list.
- 2 Press and hold the WT button on the side of your phone. Begin talking after your phone emits a chirping sound.
- 3 Release the WT button to listen.

A Boost Walkie-Talkie call ends automatically if there is no activity on the call for a few seconds.

Tip: To let someone know you want to talk to them on a Walkie-Talkie call, press the soft key under **Alert**.

Walkie-Talkie send

Send My Info during a call

- 1 While in a Boost™ walkie-talkie call, press .
- 2 With **WT Send My Info** highlighted, press .
- 3 When **Ready to Send** appears on the display, press the Boost™ walkie-talkie button to send the information.


Start a call by sending information

Find it:  > **My Info** >  **WT Send My Info**


Enter or select the recipient you want to send it to.

Tip: To send your complete contact information, create an entry for yourself in Contacts and send it.

Send contact information during a call

- 1 While in a Boost™ walkie-talkie call, press .
- 2 Select **Contacts** or **Recent Calls**.
- 3 Scroll to the **Contacts** entry or item in the recent calls list you want to send.
- 4 When **Ready to Send** appears on the display, press the Boost™ walkie-talkie button.


Start a call by sending contact information

- 1 Select the **contacts** entry.
- 2 Press  > **WT Send Contact**.

- 3 Enter the Boost™ walkie-talkie number or select the contact name you want to send to.
- 4 When Ready to Send appears on the display, press the Boost™ walkie-talkie button to send the information.


Receive my info or contact information



When you receive My Info or contact information from another phone, an icon appears on the display.

To view the information while still in the Boost™ walkie-talkie call press  > **View Contact**.

Camera

Take pictures

- 1 Press .
- 2 Aim the camera lens on the flip.

- 3 Press .
- 4 Press  to save the picture or select **Delete** to discard the picture.

Set picture options

You can set several picture options to meet your needs.

Find it:  > .

Following is a list of the options:

Zoom — 1X, 2X, or 4X

Lighting — Normal or Low Light

Self Timer — Off, 10, 15, or 20 seconds

Picture Quality — Normal or Fine.

Picture Size — Xlarge (640x480), Large (320x240), Medium (160x120), Small (128x96), and Wallpaper (176x220).

Camera Setup — Ask for Name, Shutter Sound, Default Size, and Default Quality options.

More actions for captured pictures


Send a multi-media message

- 1 After you capture a picture, select **Send**.


Note: There is a size limit on pictures which can be sent via MMS.

- 2 Enter the message recipient and any other message data.
- 3 Select **Send**.

Assign pictures to contacts

- 1 After you have captured a picture, press  > **Set as Caller ID**.
- 2 Choose an existing contact name or [New Contact] and then enter and save new contact details.

Set pictures as wallpaper

- After you have captured a picture, press  > **Set as Wallpaper**.

Access the media center

You can access the media center from the camera at any time, except when you are or using the Camera Setup menu or viewing the memory screen.

Find it: press  > **Media Center**

Manage memory

While you are taking pictures, the percentage of free memory appears on the screen.

To view your used memory, free memory, and memory capacity:

Find it:  > **Memory Usage**

To free memory, delete items from the media center.

Media Center

The Media Center lets you access pictures and audio recordings.

All pictures saved in your phone can be accessed through the media center.

The following audio recordings can be accessed through the media center:

- Voice records created when your phone was not in a call
- Musical ring-tones in the list of ringtones
- Audio recordings saved from multi-media messages you received
- Audio recordings you downloaded to your phone

Pictures and audio recordings in the media center can be sent in multi-media messages.

Pictures in the Media Center can be sent in Boost™ Walkie-Talkie calls using Walkie-Talkie Send.

View the media center

Find it:  > **Media Center**

To change views:

- 1 Press  > **Set View**.
- 2 Select **Plain List View** or **Thumbnail List View**.

Filter by media type

You can set the media center to show all items, only pictures, or only audio recordings.

Set filtering

- 1 Press  > **Filter**.
- 2 Select **All**, **Pictures**, or **Audio**.

Keep the last filter setting

To keep the filtering setting you had when you last viewed the media center:

- 1 Press  > **Filter**.
- 2 Select **Remember Filter**.

Sort by time or name

- 1 Press  > **Setup** > **Sort**.
- 2 Select **By Time** or **By Name**.

Forward locked items

Some items saved to the media center cannot be forwarded because they are locked to protect them from being unlawfully copied. You cannot remove forward locking from an item.

DRM Items

When you download multimedia content available online, such as audio, images, or Java applications, these items may be subject to DRM restrictions. DRM, or Digital Rights Management, is a system that defines how copyrighted multimedia content can be distributed and used.

Except for Java applications, which download to Java Apps, the default location for any DRM items that you download is the media center.

Depending on how a given third-party vendor has set rights for an item, the item may include the following status icons.

All DRM items are forward locked. As with other items in media center, you can lock DRM items.


Note: While your phone supports gifting and Tell-A-Friend services for DRM items, these services may not be offered by Boost Mobile®. Please contact Boost Mobile® for more information.

Pictures


The media center lets you view pictures, send them in multi-media messages or in Boost™ walkie-talkie calls, assign them to Contacts entries, or set them as your phone's wallpaper.

View pictures

To view a picture, select it from the list of items in the media center.

If your phone is set to show thumbnails, a thumbnail of each picture appears next to the picture in the list of items. If your phone is not set to show thumbnails, this icon  appears next to the picture.

To see a larger or smaller view of the picture you are viewing:

- 1 Press  > **Zoom**.
- 2 Select the zoom option you want.


If the picture does not fit in the display, scroll left and right and up and down to view different parts of the picture.

Send pictures in a message


- 1 Scroll to or select the picture you want to include in a message.
- 2 Select **Send**.

- 3 Create and send the message. The picture you selected is automatically included as an attachment.

Assign pictures to contacts

- 1 Scroll to or select the picture.
- 2 Press  > **Set As Caller ID**.
- 3 Choose an existing contact or [New Contact] and then enter and save new contact details.

Set pictures as wallpaper



- 1 Scroll to or select the picture.
- 2 Press  > **Set As Wallpaper**.

Audio recordings

You can play audio recordings, send them in multi-media messages, and assign them to Contacts entries.

Play audio recordings

To play an audio recording, select it from the list of items in the media center.

Tip: When viewing the list of items in the media center, you can scroll left or right, or press  or , to change the type of media that is displayed in the list.

- Scroll left to stop the audio recording.
- Scroll right to resume the audio recording

Send audio recordings in a message

- 1 Scroll to or select the audio recording.
- 2 Select **Send**.
- 3 Create and send the message.

Rename items

- 1 Select the item.


- 2 Press  > **Rename**.

- 3 Delete the item's name and enter a new name.

- 4 Press .

Lock items

When you lock an item in the media center, it cannot be deleted until you unlock it.

- 1 Access the media center.
- 2 Scroll to or select the item.
- 3 Press  > **Lock**.


Delete items

Deleting items from the media center deletes them from all parts of your phone, including the list of ring-tones, the list of voice records, and Contacts.


Under certain conditions, some DRM vendors will not charge you if you download an item multiple times within a given time frame. Please contact the

DRM vendor to learn more about their download regulations.

Delete an item

- 1 Scroll to or select the item.
- 2 Press  > **Delete**.

deleting all items

- 1 Access the Media Center.
- 2 Press .
- 3 Select Delete All.


Access the camera

You can access the camera from the Media Center at any time, except when you are viewing a list of audio recordings, playing an audio recording, or using the Setup menu.

Find it:  > **Media Center** > **[Camera]**.

Manage memory

To view your used memory, free memory, and memory capacity:

- 1 Access the Media Center.
- 2 Press  > **Memory Usage**.

To free memory, delete items in the media center.

Basics

See page 3 for a basic phone diagram.


Display


The *home screen* shows when you turn on the phone.


Note: Your home screen may look different.



Soft key labels show the current soft key functions. For soft key locations, see page 3.


To dial a number from the home screen, press number keys and .

Press  up, down, left, or right in the home screen to open basic menu features.



Press  to open the menu. Soft Key Labels show the current soft key functions. For soft key locations, see page 3.


Status indicators

Status indicators can show at the top of the home screen:



- 1 **Signal Strength Indicator** – Vertical bars show the strength of the

network connection. You can't make or receive calls when  or  shows.


- 2 Active Phone Line** – 1 indicates phone line 1 is ready to make calls.
- 3 Speaker Off** – Sounds associated with Walkie-Talkie calls are set to come through the earpiece rather than through the speaker.
- 4 Ringer Off** – Your phone is set to not ring.
- 5 Message Indicator** – Shows when you receive a text message. 
- 6 Packet Data** – Your handset is ready to transfer or is transferring packet data.
- 7 Battery Charge Indicator** – A fuller battery indicates a greater charge. Recharge the battery when your phone shows **Low Battery**.

Text entry

Some features let you enter text.


Your phone provides convenient ways to enter words, letters, punctuation, and numbers whenever you are prompted to enter text (for example, when adding a Contacts entry or when SMS text messaging).

To change the character input mode:

- 1 When you display a screen where you can enter text, press  to change the character input mode.
- 2 Select one of the following options:

entry modes	
Alpha	Press a key several times for each character.
Word	Enter words using a predictive text entering system that lets you enter a word with fewer keypresses.

entry modes	
Symbols	Enter symbols.
Numeric	Enter numbers by pressing the numbers on the keypad.

Tip: When entering text, press  to change letter capitalization (**Abc** > **ABC** > **abc**).









Word mode

Word English Text Input lets you enter text into your phone by pressing keys just once per letter.

Word English Text Input analyzes the letters you enter using an intuitive word database and creates a suitable word. (The word may change as you type.)





To enter a word using Word Character Input:

- 1 Select the **Word** character input mode.

- 2 Press the corresponding keys once per letter to enter a word (for example, to enter the word **Jeff**, press    ). (If you make a mistake, press  to erase a single character. Press and hold  to delete an entire entry.)
- 3 To accept a word and insert a space, press .
To accept a word completion (such as Jeffrey when you entered Jeff), press  **right**.

Alpha mode

To enter characters by tapping the keypad:

- 1 Select the **Alpha** mode.
- 2 Press the corresponding keys repeatedly until the desired letter appears. (For example, to enter the word **Jeff**, press  once,  two times,  three times, and  three times again. If you make a mistake,

press **Delete** to erase a single character. Press and hold **Delete** to erase an entire word.)

By default, the first letter of an entry is capitalized and the following letters are lowercased. After a character is entered, the cursor automatically advances to the next space after two seconds or when you enter a character on a different key.

Characters scroll in the following order:


characters	
1	? ! , @ ' - _ : ; () & " 1 0 ^ ` % + * / \ ~ [] = > < #
2	A B C 2
3	D E F 3
4	G H I 4
5	J K L 5
6	M N O 6
7	P Q R S 7
8	T U V 8
9	W X Y Z 9

characters	
0	(no characters)
#	Space
*	Shift

Volume



Press the volume keys to:

- turn off an incoming call alert
- change the earpiece volume during calls
- change the ringer volume from the home screen



Tip: Sometimes silence really is golden. That's why you can quickly set your ringer to **Vibrate All** by holding the down volume key in the home screen.

Navigation key

Press the *navigation key*  up, down, left, or right to scroll to items in the display. When you scroll to something, press .



Hands-free

You can use your phone's hands-free speaker to make calls without holding the phone to your ear.

During a call, select **Speaker** to turn the hands-free speaker on.

The hands-free speaker stays on until you select **Speaker** or turn off the phone.

Codes & passwords

The Security menu lets you turn security features on and off and change passwords:

SIM PIN — Enables and disables your phone's SIM PIN security feature.


GPS PIN — Enables and disables your phone's GPS PIN security feature.

Change Passwords — Changes your phone unlock code, security code, SIM PIN, and GPS PIN.

Lock & unlock phone

You can lock your phone to keep others from using it. To lock or unlock your phone, you need the four-digit unlock code.

To manually lock your phone: Press  > **Settings** > **Security** > **Phone Lock** > **Lock Now**.

To automatically lock your phone whenever you turn it off: Press  > **Settings** > **Security** > **Phone Lock** > **Automatic Lock** > **On**.

Note: You can make emergency calls on a locked phone (see page 45). A locked phone still receives incoming calls.

Boost Mobile® Services

Accessories

Your phone comes with a Lithium Ion Battery and travel charger.

Various accessories are available for use with your **i855** phone, cases, vehicle power charger, data cables, Hands-Free accessories and more.

To order additional accessories, go to **boostmobile.com** or call 1-888-Boost-4U (188-266-7848). You can also contact your Boost Authorized Dealership. For information on Boost retail store locations, go to **boostmobile.com**.

Wireless local number portability: Bringing your phone number from another carrier

Please contact **Boost Customer Care** for information about this service.

Boost Customer Care

1-888-BOOST-4U (1-888-266-7848) or dial 6-1-1 from your i855 phone.

Customize

Ringtones


To set the ringtone your phone makes when you receive phone calls, call alerts, message notifications, pictures sent using Send via WT or Datebook reminders:

Note: Only ringtones stored in your phone's memory are available in the ringtones list. Not all audio files can be assigned as ringtones.

- 1 From the main menu, select **Ringtones**.
- 2 Make sure **Vibrate All** is set to **Off**.
- 3 Scroll through the list of ringtones and select the one you want to assign. **Vibrate** sets your phone to vibrate instead of making a sound; **Silent** sets your phone to neither vibrate nor make a sound.

Tip: Highlighting a ringtone lets you hear it.

- 4 Select the features you want to assign the ringtone to.
- 5 When you are finished, press **Done**.

Note: This icon  appears on the display if you set your phone to neither vibrate nor make a sound for phone calls.

Set your phone to vibrate

You can set your phone to vibrate instead of making a sound when you receive all phone calls, Private calls, group calls, call alerts, messages notifications, pictures sent using Send via WT, and Datebook reminders.

- 1 Press  > **Ringtones** > **Vibrate All**
- 2 Set this option to **On** or **Locked**.

Setting this option to **On** lets you turn **Vibrate All** off by pressing the up volume control. Setting this option to **Locked** requires you to press and hold the up volume control to turn **Vibrate All** off. The **Locked** option helps prevent you from accidentally turning **Vibrate All** off.

Tip: To set **Vibrate All** to **On** or **Locked** using the volume controls: Press the volume controls to turn down the volume as far as possible to set **Vibrate All** to **On**. Continue to hold the down volume control to set **Vibrate All** to **Locked**.


To set your phone to vibrate instead of making a sound for some features but not others:

- 1 From the main menu, select **Ringtones**.
- 2 Make sure **Vibrate All** is set to **Off**.
- 3 Select **Vibrate** from the list of ringtones.

- 4 Select the features you want to set to make no sound.
- 5 When you are finished, press **Done**.

Time & date

To access Datebook set up options:

- 1 From the main menu, select **Datebook**.
- 2 Press  > **Setup**.

You can view or change these options:

Start View — Sets Datebook to start in day view, week view, or month view when you access Datebook.

Daily Begin — Sets the beginning of your day. This is the earliest time of day displayed in week view, if you have a 12-hour day view.

Delete After — Sets the amount of time Datebook waits to delete an event after it occurs.

Time Shift — Lets you shift the times of all Datebook events. This is useful if you are traveling to a different time zone.

Alert Timeout — Sets the amount of time a tone continues to sound when you receive a Datebook reminder.

Clock — Controls whether the time and date appear on the idle screen; sets time and date format; sets year.

Change the look of your phone

Wallpaper

A wallpaper is an image that appears on the idle screen.

Note: Some themes may prevent you from changing your wallpaper.

Find it:  > **Settings** > **Display/Info** > **Wallpaper**

Select the wallpaper you want or select Auto Cycle. If you select Auto Cycle,

select how often you want the wallpaper to change and then put a check mark next to the name of each wallpaper you want in the cycle.

Screen text size

Find it:  > **Settings** > **Display/Info** > **Text Size**

Select **Zoom**, **Standard**, or **Compressed**.

Dialing text size

You can set your phone to briefly display very large digits when you enter numbers at the idle screen:

Find it:  > **Settings** > **Display/Info** > **Large Dialing**

Select on **On** or **Off**.

Menu view

You can set the items on your main menu and Java applications menu to appear as large icons or a list:

Find it:  > **Settings** > **Display/Info**
> **Menu View**

Select **Icon View** or **List View**.

Backlight

You can change how the backlight functions.

Find it:  > **Settings** > **Display/Info**
> **Backlight**

Hide or show location information



Your phone is equipped with a Location feature for use in connection with location-based services that may be available in the future.

The Location feature allows the network to detect your position. Turning Location off will hide your location from everyone except 911.

Note: Turning Location on will allow the network to detect your position using

GPS technology, making some applications and services easier to use. Turning Location off will disable the GPS location function for all purposes except 911, but will not hide your general location based on the cell site serving your call. No application or service may use your location without your request or permission. GPS-enhanced 911 is not available in all areas.

To set your Privacy Options:

- 1 Press  > **GPS** > **Privacy**.
- 2 Select **Restricted, Unrestricted**, or **By Permission** > press .

Calls

To make and answer calls, see page 17.

Turn off a call alert

You can press the volume keys to turn off a call alert before answering the call.

Recent calls

The recent calls list contains information associated with calls you have made and received and call alerts you have received.


When you send or receive Private calls, the recent call list contains the following WT items with those calls:

- Contact information received
- My Info received
- Pictures sent or received

The recent calls list displays up to 20 of the most recent calls and call alerts.

- 1 Press  > **Recent Calls**.
- 2 Scroll through the list.


Redial

To redial your last outgoing call, press  twice.



Return a call

When an incoming call is not answered, the **Missed Call** log is displayed on your screen.

To display the **Missed Call** entry from the notification screen:

- Highlight the entry and press .
To dial the phone number, press the soft key under **Call**.

To display a Missed Call entry from standby mode:

- 1 Press  > **Recent Calls**
- 2 Scroll to the item containing the number you want to call.
 - If you scroll to a call, you can make a call to the number that made the call. If the number is stored in Contacts, you can make a call to any of the numbers stored with it.
 - If you scroll to contact information from another phone, you can make a call to any of the numbers in the contact information.
- 3 To place the call now, go to step 4.
- 4 To make a phone call, press .





Caller ID

Caller ID allows people to identify a caller before answering the



phone by displaying the number of the incoming call. If you do not want your number displayed when you make a call, just follow these easy steps.

To block your phone number from being displayed for a specific outgoing call:

- 1 Press   .
- 2 Enter the number you want to call.
- 3 Press .

To permanently block your number, call Boost Customer Service.

Emergency calls

Your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked or the SIM card is not inserted.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency

call cannot be placed due to network, environmental, or interference issues.

Your phone supports emergency calling. Emergency phone calls can be made even when your SIM card is blocked or not in your phone.

Dial 911 or your local emergency number to be connected to an emergency response center. If you are on an active call, you must end it before making an emergency call.

When you make an emergency call, your phone's GPS Enabled feature can help emergency service personnel find you, if you are in a location where your phone's GPS antenna has established a clear view of the open sky and your local emergency response center has the equipment to process location information. Because of the limitations of this feature, always provide your best knowledge of your location to the emergency response center when you make an emergency call.

Note: If you have not registered on the network, emergency calls cannot be placed while your SIM card is in your phone.

International calls



Call Boost Customer Care to activate international dialing. Press and hold 0 to insert your local international access code (indicated by +). Then, press the keypad keys to dial the country code and phone number.

Speed dial

Each phone number stored in Contacts is assigned a **Speed Dial** number, which you can use to call that number.

- 1 From the idle screen, use the keypad to enter the **Speed Dial** number assigned to the phone number you want to call.
- 2 Press .
- 3 Press .

Turbo dial

From the idle screen, press and hold the **Speed Dial** number (1 through 9) assigned to the phone number you want to call.

Voicemail


Note: To receive voice mail messages, you must first set up a voice mail account with your service provider.




receiving a message

When you receive a voice mail message, **New Voice Mail Message** appears on the display.



To call your service provider's voice mail system and listen to the message:

- To check voicemail messages, select **Call**.
- To dismiss the message notification, press .


If the caller leaves a message, this icon  appears on the display, reminding you that you have a new message.







Other Features

Advanced calling

feature	
call waiting	To accept the second call and put the active call on hold:  Press Yes . To accept the second call and end the active call: Press  Your phone rings with the second call for you to answer.

Contacts

feature	
voice name command	To make a call with voice name command:  Press and hold the speaker phone key > wait to see Say Name on the display > say the name of the person you'd like to call.

feature	
edit/delete contact entry	<p>Display a Contacts entry:</p> <p>Press  > Edit</p> <p>> select content to be edited >  > add and/or edit the desired information</p> <p>> </p>
set ringtone ID	<p>Display a Contacts entry:</p> <p>Press  > Edit</p> <p>> Ringtone/Picture</p> <p>>  > select desired ringer/picture >  > Back</p> <p>> Save</p>

Datebook



feature	
create datebook events	<p>To create a new Datebook event:</p> <p>Press  > Datebook</p> <p>> New.</p>
add new calendar event	<p>To add a new calendar event:</p> <p>Press  > Datebook</p> <p>> [New Event] > Done</p>
see calendar event	<p>To see a calendar event:</p> <p>Press  > Datebook</p> <p>>  left or right to day >  up or down to event > </p>
event reminder	<p>When an event reminder happens:</p> <p>To see the event details, press View</p> <p>> Back (to close the reminder)</p>

GPS

To improve GPS performance:

- Stay in the open,
- Extend your phone's antenna
- Move away from other electrical or electronic devices
- Try to remain stationary.



feature	
make an emergency call	Dial 9-1-1 to be connected to an emergency response center. If you are on an active call, you must end it before calling 911.

view approximate location	To see where you currently are: Press  > GPS > Position Scroll to view the entire screen. To recalculate position: press Refresh . This may take several minutes.
set GPS privacy options	To set the level of privacy for your GPS system: Press  > GPS > Privacy If your GPS PIN security feature is enabled, enter your GPS PIN and select the privacy option you want.

feature



set GPS PIN security

To set up a PIN to access your GPS:

Press  > **Settings**
> **Security** > **GPS PIN**
> **On** or **Off** > Enter the current GPS PIN
> 

Note: When you receive your phone, your GPS PIN is 0000.

To change your GPS PIN:

Press  > **Settings**
> **Security** > **Change Passwords** > **GPS PIN** > enter the current GPS PIN
>  > enter the new 4- to 8-digit GPS PIN
>  > re-enter the new 4- to 8-digit GPS PIN to confirm > 

feature

use GPS with map software

Connect your phone to your laptop (or other device) with a serial data cable and set your phone to transmit data.

Open the connector cover.

With the phone's display facing up, insert the serial data cable's connector into the accessory connector, until you hear a click.

Insert the data plug into the COM port of your laptop or other device. Make sure no other application is using the COM port selected.

feature

Set the COM port settings of your laptop or other device as follows:

- Bits per second: 4800
- Data bits: 8
- Parity: None
- Stop bits: 1
- Flow control: Hardware

To set your phone to send location information to your laptop or other device:

Press  > **GPS**
> **Interface** > set
NMEA OUT to **On**

Hands-free

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

feature

speaker-phone


Activate the speakerphone while driving:



Press and hold the smart/speakerphone key or press **Options** > **Speaker**.


feature


auto answer Automatically answer calls when connected to a car kit or headset:

Press  > **Settings** > **Phone Calls** > **Auto Ans** > select the amount of rings before answering





Messages

feature





read messages When you receive a text message, it will automatically appear on your phone's main display screen. To view the entire message press  down. If the message is urgent, the message icon blinks in your display. 

reply to messages While the message is open: 





Press **Reply** > type message > **Send**

feature	
send preset messages	Press   > Messaging > Create Message > Preset Messages > New Preset Msg >  or Scroll to a message to edit, press Options > Edit >  > Save

Personalize

feature	
language	Set menu language: Press  > Settings > Display/Info > Language
backlight time length	Select how long the display screen and keypad are backlit: Press  > Settings > Display/Info > Backlight
menu style	Show the main menu as graphic icons or a text-based list: Press  > Settings > Display/Info > Menu View
clock display	Press  > Settings > Display/Info > Clock

Security

feature	
lock feature	To lock the phone: Press  > Security > Phone Lock >  > Lock Now or Auto Lock To lock the keypad: Press  > 



MOTOROLA

Important Safety and Legal Information

Safety and General Information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your integrated multi-service portable radio.*

Exposure to Radio Frequency (RF) Energy

Your phone contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.

Your Motorola phone is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Portable Radio Product Operation and EME Exposure

Your Motorola radio product is designed to comply with the following national and international standards and guidelines regarding exposure of human beings to radio frequency electromagnetic energy (EME):

- United States Federal Communications Commission, Code of Federal Regulations; 47 CFR part 2 sub-part J.
- American National Standards Institute (ANSI) / Institute of Electrical and Electronics Engineers (IEEE). C95. 1-1992.
- Institute of Electrical and Electronics Engineers (IEEE). C95. 1-2005 Edition.*
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998.
- Ministry of Health (Canada). Safety Code 6. Limits of Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999.
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation - Human Exposure) Standard 2003.
- ANATEL, Brasil Regulatory Authority, Resolution 303 (July 2, 2002) "Regulation of the limitation of exposure to electrical, magnetic, and electromagnetic fields in the

* The information provided in this document supersedes the general safety information in user's guides published prior to May 1, 2006

radio frequency range between 9 kHz and 300 GHz." Attachment to Resolution 303 from July 2, 2002."

Operational Precautions

To assure optimal radio product performance and to be sure that human exposure to RF does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions :

Two-way radio operation

Your radio product has been designed and tested to comply with national and international standards and guidelines regarding human exposure to RF electromagnetic energy, when operated in the two-way mode (at the face, or at the abdomen when using an audio accessory) at usage factors of up to 50% talk/50% listen.

Transmit no more than the rated duty factor of 50% of the time. To transmit (talk), push the Walkie-Talkie (WT) button. To receive calls, release the WT button. Transmitting 50% of the time or less, is important because this radio generates measurable RF energy only when transmitting (in terms of measuring for standards compliance).

When using your radio product as a traditional two-way radio, **hold the radio product in a vertical position with the microphone one to two inches (2.5 to 5 cm) away from the lips.**



Product Operation

When placing or receiving a phone call, hold your radio product as you would a wireline telephone. **Speak directly into the microphone.**

If you wear a radio product on your body when transmitting, always place the radio product in a Motorola approved clip, holder, holster, case or body harness. If you do not use a body-worn accessory supplied or approved by Motorola and are not using the radio product in the intended use positions along side the head in the phone mode or in front of the face in the two-way radio mode—or if you hang your device from a lanyard around your neck—keep the device at least 2.5 centimeters (1 inch) from your body when transmitting.

ALL MODELS WITH FCC ID AZ489FT5844 MEET THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg.¹ Tests for SAR are conducted using standard operating positions reviewed by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are

to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is 1.05 W/kg and when tested on the body, as described in this user guide, is 1.15 W/kg during packet data transmission. (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements.)²

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID AZ489FT5844.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at <http://www.wow-com.com>.

¹ In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

² The SAR information reported to the FCC includes the FCC-accepted Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

Approved Accessories

For a list of approved Motorola accessories call 1-800-453-0920, or visit our website at www.motorola.com/iden.

RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed or otherwise configured for RF energy compatibility. In some circumstances your handset may cause interference with other devices.

Follow Instructions to Avoid Interference Problems

Turn OFF your radio product where posted notices instruct you to do so.

In an aircraft, turn off your radio product whenever instructed to do so by airline staff. If your radio product offers an airplane mode or similar feature, consult airline staff about using it in flight.

Implantable Medical Devices

If you have an implantable medical device, such as a pacemaker or defibrillator, consult your physician before using this radio product.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the phone more than 20 centimeters (8 inches) from the the implantable medical device when the phone is turned ON.
- DO NOT carry the phone in a breast pocket;
- Use the ear opposite the implantable medical device to minimize the potential for interference.
- Turn OFF the phone immediately if you have any reason to suspect that the interference is taking place.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using your wireless phone with your implantable medical device, consult your health care provider.

Hearing Aids

Some mobile devices may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer or physician to discuss alternatives.

Other Medical Devices and Health Care Facilities

If you use any other personal medical devices, consult your physician or the manufacturer or your device to determine if it is adequately shielded from RF energy. Turn off your radio product when instructed to do so in hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

Driving Precautions

Check the laws and regulations on the use of radio products in the area where you drive. Always obey them.

When using your radio product while driving, please:

- Give full attention to driving and to the road. Using a mobile device may be distracting. Discontinue a call if you can't concentrate on driving.
- Use handsfree operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

- Do not place a handset in the airbag deployment area.

Responsible driving practices can be found in the "Smart Practices While Driving" section at the end of this guide and/or at the Motorola Web site: www.motorola.com/callsmart.

Note: The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving. Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Operational Warnings

Obey all posted signs when using mobile devices in public areas.

Potentially Explosive Atmospheres






Areas with potentially explosive atmospheres are often but not always posted, and can include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain, dust or metal powders.



When you are in such area, turn off your handset, and do not remove, install, or charge batteries unless it is a radio product type especially qualified for use in such areas as "Intrinsically Safe" (for example, Factory Mutual, CSA, or UL approved). In such areas, sparks can occur and cause an explosion or fire.

Batteries and Chargers

Caution: Improper treatment or use of batteries may present a danger of fire, explosion, leakage, or other hazard. For more information, see the “Battery Use and Battery Safety” section in this user’s guide.

Your battery, charger, or portable radio may contain symbols, defined as follows:

Symbol	Definition
	Important safety information follows.
	Do not dispose of your battery or mobile device in a fire.
	Your battery or mobile device may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Do not throw your battery or mobile device in the trash.
	Your mobile device contains an internal lithium ion battery.

Symbol	Definition
	Do not let your battery, charger, or mobile device get wet.
	Listening at full volume to music or voice through a headset may damage your hearing.

Choking Hazards

Your portable radio or its accessories may include detachable parts, which may present a choking hazard to small children. Keep your device and its accessories away from small children.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour, and stop use if you are very tired.

Caution About High Volume Usage



Listening at full volume to music or voice through a headset may damage your hearing.

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician.

Service & Repairs

If you have questions or need assistance, we're here to help.

Go to www.motorola.com/iden/support, where you can select from a number of customer care

options. You can also contact the Motorola Customer Support Center at 1-800-453-0920 (United States), 1-877-483-2840 (TTY/TDD United States for hearing impaired).

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Note: FOR IDEN SUBSCRIBER PRODUCTS, ACCESSORIES AND SOFTWARE PURCHASED IN THE UNITED STATES OR CANADA

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its Motorola iDEN Digital Mobile and Portable Handsets ("Products"), Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-Roms or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below.

This limited warranty is a consumer's exclusive remedy, and applies as follows to new Products, Accessories and Software purchased by consumers in the United States or Canada,

which are accompanied by this written warranty:

Products Covered	Length of Coverage
Products as defined above.	One (1) year from the date of purchase by the first consumer purchaser of the product.
Accessories as defined above.	One (1) year from the date of purchase by the first consumer purchaser of the product.
Products or Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

Products Covered	Length of Coverage
Software as defined above. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

What is not covered? (Exclusions)

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Ornamental Decorations. Ornamental decorations such as emblems, graphics, rhinestones, jewels, gemstones and their settings, and other decorative elements, are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d)

other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, including without limitation, software changes, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, antennas, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products, Accessories or Software is excluded from coverage.

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that

all defects in the software products will be corrected.

Software NOT Embodied in Physical Media.

Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

Who is covered? This warranty extends only to the first consumer purchaser, and is not transferable.

What will Motorola Do? Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information?

To obtain service or information, please call:

Motorola iDEN Customer Services 1-800-453-0920 or 954-723-4910

TTY-877-483-2840

Or visit us online at <http://www.motorola.com/iden/support>

You will receive instructions on how to ship the Products, Accessories or Software, at your

expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There? ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR

SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

Patent and Software Provisions

MOTOROLA will defend, at its own expense, any suit brought against the end user purchaser to the extent that it is based on a claim that the Product or parts infringe a United States patent, and Motorola will pay those costs and damages finally awarded against the end user purchaser in any such suit which are attributable to any such claim, but such defense and payments are conditioned on the following:

- a. That MOTOROLA will be notified promptly in writing by such purchaser of any notice of such claim;
- b. That MOTOROLA will have sole control of the defense of such suit and all negotiations for its settlement or compromise; and
- c. Should the Product or parts become, or in MOTOROLA'S opinion be likely to become, the subject of a claim of infringement of a United States patent, that such purchaser will permit MOTOROLA, at its option and expense, either to procure for such purchaser the right to continue using the Product or parts or to replace or modify the same so that it becomes non-infringing or to grant such purchaser a credit for the Product or parts as depreciated and accept its return. The depreciation will be an equal amount per year over the lifetime of the Product or parts as established by MOTOROLA.

MOTOROLA will have no liability with respect to any claim of patent infringement which is based upon the combination of the Product or parts furnished hereunder with software, apparatus or devices not furnished by MOTOROLA, nor will MOTOROLA have any liability for the use of ancillary equipment or software not furnished by MOTOROLA which is attached to or used in connection with the Product or any parts thereof.

Laws in the United States and other countries preserve for MOTOROLA certain exclusive rights for copyrighted MOTOROLA software, such as the exclusive rights to reproduce in copies and

distribute copies of such MOTOROLA software. MOTOROLA software may be used in only the Product in which the software was originally embodied and such software in such Product may not be replaced, copied, distributed, modified in any way, or used to produce any derivative thereof. No other use including, without limitation, alteration, modification, reproduction, distribution, or reverse engineering of such MOTOROLA software or exercise or rights in such MOTOROLA software is permitted. No license is granted by implication, estoppel or otherwise under MOTOROLA patent rights or copyrights.

Hearing Aid Compatibility

A number of Motorola phones have been tested for hearing aid compatibility. When some wireless phones are used with certain hearing aids, users may detect a noise which can interfere with the effectiveness of the hearing aid.

Some hearing aids are more “immune” than others to this interference noise, and phones can also vary in the amount of interference noise they may generate. ANSI standard C63.19 was developed to provide a standardized means of measuring both mobile phone and hearing aids to determine usability rating categories for both.

Ratings have been developed for mobile phones to assist hearing aid users find phones that may be compatible with their hearing aid. Not all phones have been rated for compatibility with hearing aids. Phones that have been rated have a label with the rating(s) located on the box, and at www.motorola.com/iden.

These ratings are not guarantees of compatibility. Results will vary depending on the user’s hearing aid and individual type and degree of hearing loss. If a hearing aid is particularly vulnerable to interference, even a phone with a higher rating may still cause unacceptable noise levels in the hearing aid. Trying out the phone with your hearing aid is the best way to evaluate it for your personal needs.

“M” Rating: Phones rated M3 or M4 meet FCC requirements for hearing aid compatibility and are likely to generate less interference to hearing aids than unrated phones. (M4 is the “better” or higher of the two ratings.) On those models with an extendable antenna, this rating is determined only with the antenna extended.

“T” Rating: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing aid’s telecoil (“T Switch” or “Telephone Switch”) than unrated phones. (T4 is the “better” or higher of the two ratings.) On those models with a telecoil mode setting, this rating is determined only with the phone so set. For setting instructions, see “Features for the Hearing Impaired” in the section entitled “Advanced Calling Features”. Note that not all hearing aids have telecoils in them.

Hearing aids may also be measured for immunity to interference from wireless phones and may have ratings similar to wireless phones. Ask your hearing healthcare professional for the rating of your hearing aid. Add the rating of your hearing aid and your phone to determine the estimated usability:

- Any combined rating equal to or greater than six offers excellent use.
- Any combined rating equal to five is considered normal use.

- Any combined rating equal to four is considered usable.

Thus, if you use an M3 phone with a M3 hearing aid you will have a combined rating of six for “excellent use.” This methodology applies equally for T ratings.

More information about hearing aid compatibility may be found at:

www.motorola.com/accessibility, www.fcc.gov, www.fda.gov, and www.hearingloss.org/learn/cellphonetech.asp

Information From the World Health Organization

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using

hands-free devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information: <http://www.who.int./peh-emf>

Product Registration

Online Product Registration:

<http://direct.motorola.com/hellomoto/Motosupport/source/registration.asp>

Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your product require an update or other service. Registration is for U.S.

residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the

U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Wireless: The New Recyclable

Your wireless mobile device can be recycled. Recycling your mobile device reduces the amount of waste disposed in landfills and allows recycled materials to be incorporated into new products.

The Cellular Telecommunications Industry Association (CTIA) and its members encourage consumers to recycle their mobile devices and have taken steps to promote the collection and environmentally sound recycling of end-of-life devices.

As a mobile device user, you have an important role in ensuring that this device is recycled properly. When it comes time to give this mobile device up or trade it in for a new one, please remember that the mobile device, the charger, and many of its accessories can be recycled. It's easy. To learn more about CTIA's Recycling Program for Used Wireless Devices, please visit us at:
<http://recycling.motorola.young-america.com/index.html>

California Perchlorate Label

Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. In such cases, California law requires the following label:

“Perchlorate Material - special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate.”

There is no special handling required by consumer.

Privacy and Data Security

Motorola understands that privacy and data security are important to everyone. Because some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access**—Keep your mobile device with you and do not leave it where others may have unmonitored access. Lock your device’s keypad where this feature is available.
- **Keep software up to date**—If Motorola or a software/application vendor releases a patch or software fix for your mobile device which updates the device’s security, install it as soon as possible.
- **Erase before recycling**—Delete personal information or data from your mobile device prior to disposing of it or turning it in for recycling. For step-by-step instructions on how to delete all personal information from your device, see the section entitled “master clear” or “delete data” in this user’s guide.

Note: Note: For information on backing up your mobile device data before erasing it, go to www.motorola.com and then navigate to the “downloads” section of the consumer Web page

for “Motorola Backup” or “Motorola Phone Tools.”

- **Understanding AGPS**—In order to comply with emergency caller location requirements of the FCC, certain Motorola mobile devices incorporate Assisted Global Positioning System (AGPS) technology. AGPS technology also can be used in non-emergency applications to track and monitor a user’s location—for example, to provide driving directions. Users who prefer not to permit such tracking and monitoring should avoid using such applications.

If you have further questions regarding how use of your mobile device may impact your privacy or data security, please contact Motorola at privacy@motorola.com, or contact your service provider.

Smart Practices While Driving

Drive Safe, Call Smart SM

Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas. Go to www.motorola.com/callsmart for more information.

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.
- **When available, use a hands-free device.** If possible, add an additional layer of convenience to your mobile device with one of the many Motorola Original hands-free accessories available today.
- **Position your mobile device within easy reach.** Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at



an inconvenient time, if possible, let your voice mail answer it for you.

- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.
- **Use your mobile device to call for help.** Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies.*

- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 911 or other local emergency number, as you would want others to do for you.*
- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*

* Wherever wireless phone service is available.

Index

A

- accessories 11, 39, 52
- active phone line 35
- advanced calling 48
- alert
 - set 37, 40
 - turn off 37, 44
- answer a call 17

B

- battery 16
- battery indicator 35
- battery life, extend 14

C

- call
 - answer 17
 - end 17
 - make 17
- call waiting 48
- caller ID 45

- calls 44
- center key 38
- center select key 11
- codes 38
- combined power/end/home key 17
- contacts 48

D

- datebook 49
- dial a phone number 17
- dialed calls 44
- display 34
- DRM
 - definition 30

E

- earpiece volume 37
- emergency number 45
- end a call 17
- export regulations 71

F

frequently asked questions
service and repairs 63

G

GPS 50
GPS enabled
emergency calls 46
GPS PIN 38
GPS, see GPS enabled

H

hands-free 52
hands-free speaker 38
Hearing Aid Compatibility 69
home screen 34

I

incoming call message 45
international calls 46
iTAP text entry mode 36

L

lock
phone 38

78 Index

low battery message 35

M

make a call 17
Media center 29
message indicator 35
messages 53
missed calls message 44
MMS 19

N

navigation key 11, 38

O

optional accessory 11, 52
optional feature 11

P

packet data 35
passwords 38
passwords. See codes
personalize 53, 54
phone number 18
pictures
send 31

view 31

R

- radio frequency 57
- received calls 44
- recent calls 44
- recycling 72
- redial 44
- return a call 44
- ring style indicator 35
- ring style, setting 37
- ring tones
 - off 40
 - vibrate 40
- ringer volume 37
- ringtone, setting 40
- ringtones
 - off 40
 - setting 40
 - vibrate 40, 41

S

- safety
 - radio frequency 57
 - RF energy interference 60

- safety information 57
- safety tips 75
- security 38, 55
- security code 38
- send key 17
- SIM chip 12
 - installation 12
- SIM PIN 38
- soft keys 34
- speaker 35
- speed dial 46
- store your number 18

T

- tap text entry mode 36
- text entry 35
- time & date 41
- turn on/off 17

U

- unlock
 - phone 38
- unlock code 38

V

voice mail

receiving 47

setting up 47

voicemail 47

voicemail message indicator 47

volume 37

W

Walkie-Talkie

calls 25

send 26

WHO information 71

Y

your phone number 18