

UV-C Vacuum Cleaner U60 / U60 Pro MANUAL



MONEUAL

Examples of Use / Specification	3
Safety Instructions	4
Storage & Operational Instructions	5
Parts ·····	6
How to Use & Air Freshener function	7
Cleaning Filter / Suction Hole	8
How to Store	9
Troubleshooting	10
Warranty	11

## **Examples of Use / Specification**

### Do MONEUAL RYDIS for your Health!

MONEUAL RYDIS is a UV-C vacuum cleaner that uses UV-C sterilization to clean bedding, sofa/cushions, carpets and clothes. Thanks to a larger suction hole and suction power generated by 600W motor, the device offers a perfect solution for removal of dust and mites.









>> Bedding

>> Sofa / Cushion

>> Carpet

>> Clothes / Fabric

### **Specification**

MODEL	MONEUAL RYDIS U60	MONEUAL RYDIS U60 Pro
COLOR	Green	Black
UNIT WEIGHT	4.87lb	
MOTOR POWER	600W	
CLEANING MODE	3steps [Vacuum-Vibration-UV Sanitizing / Vacuum-UV Sanitizing / UV Sanitizing]	
UNIT DIMENSION (W x D x H)	13.4" x 8.7" x 6.7"	
UV LAMP	Ultraviolet Rays Lamp	
UV LAMP CONTROL	Sensor	
DISPLAY	LED Icon Display	
FILTER	High-efficiency Filter	
VOLTAGE	120V, 50/60Hz	
AIR FRESHENER	X	Lavender
SMART HANDLE SENSOR	X	Touch Handle Sensor
PLACE OF ORIGIN	The Republic of Korea	

## **Safety Instructions**

### Caution!

Please follow the safety instructions to prevent death or injury.



Do not touch the power plug with wet hands. There is a risk of electric shock.



Do not bend, damage or place any heavy object on a power cable. There is a risk of electric shock.



Do not use multiple plugs in a single socket. There is a risk of fire.



Do not touch the metal pins of a plug. There is a risk of electric shock.



Unplug the power cable from the outlet when the unit is not used for a long period of time. There is a risk of electric shock or fire.



Keep the pins clean and free of any unwanted materials using a dry cloth to clean them. There is a risk of electric shock.



Do not disassemble or modify the unit unless it is to replace parts. There is a risk of electric shock or fire.



Please contact our service center to replace damaged power cable. There is a risk of electric shock or fire.



This appliance is provided with double insulation. Use only identical replacement parts. See instructions for Servicing of Double-Insulated Appliances.



This appliance has a polarized plug(one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug.

## **Storage & Operational Instructions**

### Caution!

Please follow the instructions to prevent injury or damage to property.



Make sure that the filter cartridge is in place before use. Do not use without dust bag and/or filters in place.



Do not operate the unit with wet filter or dustbin, There is a risk of damage to the unit.



Do not use the unit with the suction hole or exhaust hole clogged. It can overheat and cause damage or



Make sure to power off the unit during operation when you carry it around. The unit or lamp can overheat and cause damage or fire.



Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes. It can cause deformation of the unit or fire.



Do not vacuum any liquid, blade, pin or volatile material. There is a risk of damage, electric shock or fire.



Do not touch the bottom of the unit with your hands during operation.
There is a risk of injury.



Keep out of reach of infants or children.
There is a risk of injury.



If any unusual noise, smell or smoke is detected, unplug the power cable and contact the service center immediately. (note:bead rolling sound is normal when the lamp is on)




Do not shine UV ray directly into eyes or skin of a person/ animal. It can damage the eyes or skin.

## **Parts**



## How to Use & Air Freshener function

#### **Mode Selection**



- 1. Power On: Press the Power button for 1 second and grab the handle to start operation.
- Press the Mode button to select mode.The (LED) of the mode screen turns on to indicate the cleaning mode.
- 3. Press the Mode button to switch cleaning modes. [Vacuum + UV + Vibration] / [Vacuum + UV] / [UV]
- 4. Power Off: Press the Power button for 1 second.
- \* You can switch to other mode during operation by pressing the Mode button. (Without pause)
- \* The UV LAMP is deactivated if the sensor detects that the unit is lifted from the floor
- \* Touch handle sensor (RYDIS U60 Pro Only): Operation pauses automatically if you release your hand from the handle and resumes when you grab it again. (Pause is temporary for convenience)
- \* Lab Test: Based on testing by Korea Conformity Laboratories, an independently certified lab, 99% of the Staphylococcus aureus, Escherichia coil, and Pseudomonas aeruginosa bacteria were eliminated.

### Air Freshener (RYDIS U60 Pro Only)



The unit uses the exhaust hole for air freshening and sterilization.

\* Lavender

## **Cleaning Filter / Suction Hole**

### Cleaning & Replacing the Filter



 Remove the dustbin from the unit by the knob



Separate the filter from the dustbin



Separate the Pre-filter from the High Efficiency filter



 Wash the dustbin and Prefilter with water (Dry the dustbin and Pre-filter in a well-ventilated area)



 Brush off the dust from the High Efficiency filter with enclosed brush



 Assemble the filter and dustbin, and return them to the unit

- \* Do not wash the High Efficiency filter with water. The High Efficiency filter is not washable.
- \* Recommended to clean the filter every 1-3 uses.
- \* Replace the filter every 6 months. (depending on the environment or frequency of use)

### **Cleaning the Suction Hole**



# Remove any unwanted materials if the suction hole is clogged.

- \* If the suction hole is clogged, the suction power is reduced and the unit makes a noise which can lead to overheating, damage or fire.
- \* Do not vacuum any sharp objects such as blades, pins and toothpicks.
- \* Unscrew the screws and remove the rolling bin to remove unwanted objects.

## **How to Store**


#### **How to Store**



Use a Velcro tape to tie the power cable to the handle to prevent any damage to the power plug and cable after use.

#### **Certifications & Awards**

























#### MONEUAL RYDÁS

## **Troubleshooting**

### O1 The unit does not operate at all.

- Please make sure to check the voltage.
- Please check the power outlet for proper electricity. Use other electrical device to check power supply.
- Please make sure to grab the handle. (U60 Pro Only)
  The touch handle sensor requires you to touch the handle to operate the unit.

### 02 The unit stops during operation.

- Please check whether the dustbin is full.
- Please make sure the suction hole is not clogged.
- Please make sure not to use the unit for more than 30 minutes. The motor overheat protector shuts down the operation temporarily in the case above. Clear the clogged suction hole and use after 2-3 hours.

### The suction power is reduced and it makes a vibrating noise.

- ▶ Please check whether any large object is lodged in the suction hole or dustbin.
- Please check whether the dustbin is full.
  Remove any unwanted objects lodged in the suction hole / dustbin and empty the dustbin.

### O4 The UV lamp turns off during operation.

- ▶ Please make sure the unit is on the floor.
- Please check whether the target object is a dark color. (e.g. black, dark blue) Rydis uses a floor detection sensor that deactivates the UV lamp if an object is a dark color or the unit is lifted from the floor more than 2inch(5cm).

#### 05 Additional information

- ▶ The exhaust hole may have a certain smell and it does not mean the product is defective.
  The unit can have a rubber smell for up to 3 months after purchase as it is a new product.
- It is recommended to replace the filter earlier than advised if it smells due to dust particles and unwanted materials.
- Please do not use the unit on hard surfaces as it may damage the Vibration Pads.

#### Moneual UV-C Vacuum Cleaner Limited Warranty

#### A. Limited Warranty

Moneual USA, Inc. (\*Moneual") warrants the product line of Moneual UV-C Vacuum Cleaner ("The Product") you have purchased, from Moneual or from a Moneual Authorized Reseller, to be free from defects in materials and workmanship under normal use during the period specified below. The warranty period begins on the date of purchase. Your original purchase invoice(sales receipt), is your proof of the date of purchase. If you cannot provide the original purchase invoice (sales receipt), the warranty period will be based on the manufacture date-code shown on the Product. A Product that has been exchanged is warranted starting at the original date of purchase.

The Warranty period for the product line is as follows: Parts One (1) Year / Labor One (1) Year

This warranty extends only to you, the original purchaser. It is not transferable to anyone who subsequently purchases, leases, or otherwise obtains the Product from you. It excludes expendable parts. During the warranty period, Moneual will repair or replace defective hardware with factory refurbished parts and products. All exchanged parts and Products replaced under this warranty will become the property of Moneual. During the warranty period, there will be no charge for labor or parts. If, after repeated efforts, Moneual is unable to repair the Product to good working order, you may get a replacement unit from Moneual, please note the replacement model may not be the exact same model, Moneual will always replace with equal or better spec Product.

To ensure timely response to a service request, please be sure to register your Product at http://www.moneualusa.com. Within ten (10) calendar days from the time you purchase the Product, be sure to put in the purchase date, location, and serial number associated with the Product purchase, tech support may randomly ask for sales receipt or other proof of purchase to determine warranty coverage.

#### B. Warranty Limitation; Exclusion; Exclusive Remedies

This Limited Warranty does not extend to any Product that has been damaged (a) during or as a result of use other than for its normal intended purpose, failure to use the Product in accordance with the User's Manual which accompanies it, misuse, abuse, or negligence; (b) by the use of parts not manufactured or sold by Moneual; (c) by modifications of the Product; (d) as a result of services by anyone other than Moneual or Moneual's Service Center; (e) improper transportation or packing when returning the Product to Moneual or Moneual's Service Center; (b) unusual physical or electrical stress or interference, failure or fluctuation of electrical power, lighting, static electricity. fire, or nature disaster.

Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages for consumer products, and some states or provinces do not allow limitation on how long an implied warranty lasts. In such states and provinces, the exclusion or limitation of this limited warranty may not apply to you.

This Limited Warranty gives you specific legal rights. You may also have other rights that vary from state to state. You are advised to consult applicable state or provincial laws for full determination of your rights.

#### C. Obtaining Carry-In or Mail-In Warranty Services

Subject to the following terms and conditions, you are entitled to mail-in repair service during the applicable warranty period.

- Prior to obtaining service you must contact the Moneual Customer Service Center at (877) 450-0105. Please have the model number, serial number, place of purchase, and date of purchase, ready when you call. The serial number (S/N) and model number are located on the back of the Product
- Moneual Technical Support will attempt to help you resolve your problem over the telephone. During problem resolution, Moneual will require your assistance in performing routine diagnostic procedures. If appropriate, Moneual will then issue you a Return Merchandise Authorizations (RMA) number to be used as a means of identifying the Product.
- 3. After calling (877) 450-0105 to obtain a Return Merchandise Authorization number. Mail-In Repair service is available for Products purchased and located in the continental United States, you are responsible for the shipping charge to ship the Product to the Service Center, Moneual will pay for the shipping to ship the Product back to you. Product purchased in Canada, Alaska, Hawaii and Puerto Rico, you are responsible for the shipping charges to and back from the repair center.
- 4. All Mail-In service must take place by returning the Product to the Moneual Service Center. You must prepay any shipping charges, export taxes, custom duties and taxes or any other charges associated with transporting the Product. In addition, you are responsible for insuring the Product during shipment. You assume the risk of loss during shipment.
- 5. Use the original shipping and packing materials and include a description of the symptoms of the problem. If the original shipping and packing materials and boxes are not available, please make sure the Product is properly packaged and secured inside a shipping container. The Return Merchandise Authorization (RMA) number must be placed on the exterior of the shipping container. Physical damage occurred during shipment is not warranted.
- Include your name and address, proof of the place and date of purchase (Sales Receipt), and the serial number and model number of the Product. The serial number and the model number are located on the back of the Product.
- 7. Moneual is not responsible for a Product shipped to the Moneual Service Center that is scratched, including but not limited to, scratches on the Product, the Product will be repaired or replaced with a similar refurbished Product in similar condition as the original Product that was returned. Products shipped to the Moneual Service Center with missing parts will be replaced without those parts. Products that are beyond repair will be replaced with refurbished Products in equal or better spec as the original Product that was returned should the same model not be available.
- 8. Cross-shipping. For customers that need the replacement Product as soon as possible to reduce down time and loss productivity, cross-shipping can be arranged with a Credit Card on file as collateral. The value of the Product will be authorized on the customer's credit card and held as collateral upon the shipment of the replacement Product from Moneual Service Center, the amount authorized will be cancelled upon receipt of the defective Product back from the customer. The same terms and conditions applied to this paragraph (#8) as are stated in paragraph #4-#7. Please see above. The authorization is valid for 30 days, and will be processed for payment if the defective Product is not received. (Caution for Debit Cards, upon authorization, the amount may be deducted from your balance, so the use of credit card is strongly suggested).

#### **Additional Information**

You may request additional information on how to obtain warranty Services by contacting Moneual or any Moneual Service Center. You may also request information on how to obtain warranty service or the location of the Moneual Service Provider by calling or contacting:

#### **Moneual Customer Service Center**

Tel: (877) 450-0105 / Outside of USA: (909) 334-7500 / e-mail: support@moneual.com

13825 Norton Ave Chino, CA 91710

Please note:

Warranty is only valid for the Original Owner purchased from an authorized reseller. Second owners or eBay purchase carry no warranty. All returns, exchanges, refunds, or repairs should be referred back to the origin of purchase.

Proof of purchase (Receipt) will be required for warranty services.

# RYDİS

